Price List of Parts

Thomas Six Forty Model M.C. 1912



ERThomas Motor Car Company
BUFFALO NY USA



Plant of the E. R. Thomas Motor Car Company

Price List of Parts

Thomas Six Forly Model M.C. 1912



E. R. Thomas Motor Car Company

FACTORY AND GENERAL OFFICES: BUFFALO, N.Y.

Subsidiary Selling Agencies

Thomas Motor Company of New York
Thomas Motor Car Co. of Boston
Thomas Motor Car Co. of Chicago
Michigan Ave., Cor. 23rd St., Chicago Ill. E. R. Thomas Motor Car Co. Buffalo Branch - 1227-1229 Main St., Buffalo, N. Y. Thomas Motor Car Co., of Cal., 1058-60 S. Flower St., Cor. Eleventh, Los Angeles, Cal.

STANDARD WARRANTY

Adopted May 4, 1910, National Association of Automobile Manufacturers, Inc.

E warrant the motor vehicles manufactured by us for ninety days after the date of shipment, this warranty being limited to the furnishing at our factory of such parts of the motor vehicle as shall, under normal use and service, appear to us to have been defective in material or workmanship.

This warranty is limited to the shipment to the purchaser, without charge, except for transportation of the part or parts intended to replace the part or parts claimed to have been defective, and which, upon their return to us at our factory for inspection, we shall have determined were defective, and provided the transportation charges for the parts so returned have been prepaid.

We make no warranty whatever in respect to tires or rims.

The condition of this warranty is such that if the motor vehicle to which it applies is altered, or repaired, outside of our factory, our liability under this warranty shall cease.

The purchaser understands and agrees that no warranty of the motor vehicle is made, or authorized to be made, by the Company other than that herein set forth.

HOW TO ORDER THOMAS PARTS

In order to avoid delay, unnecessary correspondence and have your orders filled correctly, it is absolutely necessary that you read the following:

- When ordering parts, specify: Shipping Directions, Code Word, or number found on plate, Model of Car, Number of Car, Name of Part, Color, if painted.
- Always Order from this Parts Price List. Code words are provided for convenience and economy in ordering by telegraph, or otherwise. When ordering Standard Parts found in Group 17, give symbol. Please specify style of Car for which part is ordered.
- Whenever possible, Parts and Supplies should be ordered through a Thomas Dealer.
- When returning Parts for any purpose. Have box properly tagged with your Name and Address, and prepay charges; also write us giving particulars concerning same, regardless of any previous correspondence you may have had on the subject.
- **Terms.** All prices are Net F. O. B. factory, Buffalo. Our responsibility ceases when goods are delivered in good condition to the Transportation Companies. All quotations on Parts or Supplies are subject to change without notice.
- Accounts are opened only with Thomas Dealers. Orders from individuals which are not accompanied by cash will be sent C. O. D.
- Thomas Parts. Close interchangeability and continued efficiency are best assured by making replacements only with Parts made by the Thomas Motor Car Company. Owners are advised to consult Thomas Dealers about all repairs, adjustments and replacements, especially with regard to accessories furnished with Thomas Cars, but not manufactured by us, such as Lamps, Springs, etc.

Factory. Buffalo, N. Y.

Technical Department. The Technical Department of the Thomas Motor Car Company will furnish, at any time, especially desired information concerning the operation and maintenance of Thomas Cars.

PARTS PRICE LIST

THOMAS MOTOR CARS

For 1912-6-40 Model MC

To locate Parts observe following arrangement:


Code Letter	Group Number	NAME OF GROUP	Begins on Page
A	1*	MOTOR	8
В	2	GASOLINE SYSTEM	17
C	3	EXHAUST SYSTEM	21
D .	4	COOLING SYSTEM	23
E	5	IGNITION SYSTEM	27
F	6	OILING SYSTEM	33
G	7	CLUTCH	33
H	8	TRANSMISSION	36
J	9	DRIVE	39
L	10	CONTROL	40
M	11	REAR AXLE	49
N	12	FRONT AXLE	57
P_	13	SPRINGS	60
R	14	FRAME	62
		Designating	
S	15	BODY (Touring Car) T	64
	13	" (Phaeton) P	70
		" (Surrey) S	71
		" (Runabout) R	72
		" (Limousine) Li.	73
		" (Landaulet) La.	
Т	16		74
1	10	EQUIPMENT (Touring Car)	74
		(Filaetoli)	
		(Surrey)	74
		(Runabout)	74
		(Limousine)	74
		" (Landaulet)	14
	17	STANDARD OR X PARTS	78
		Included in this group are all the Standard or Special Parts which are given in the other groups without code words and prices. They are listed here in numerical order, so that when an X part is listed in any assembly it can be ordered, if desired, from Group No. 17.	

TELEGRAPH SHIPPING CODE

TACEG	Thomas MC 1912 Touring Car
TBDFH	Thomas MC 1912 Phaeton
TCEGI	Thomas MC 1912 Surrey
TDFHK	Thomas MC 1912 Runabout
TEGIK	Thomas MC 1912 Limousine
TEHKL	Thomas MC 1912 Landaulet
TUXYA	For Car Number
TVXZB	Ship to me (us) by Express
TXYAC	Ship to me (us) by Express in care of
TXZBD	Ship by Express to
TYCEG	Ship by American Express
TZDFH	Ship by American Express in care of
TADGK	Ship by American Express to
TBEHK	Ship by U. S. Express
TCFIL	Ship by U. S. Express in care of
TDGKM	Ship by U. S. Express to
TEHKN	Ship by Adams Express
TFILO	Ship by Adams Express in care of
TGJMP	Ship by Adams Express to
THKNO	Ship by National Express
TILOR	Ship by National Express in care of
TKMPS	Ship by National Express to
TKNOI	Ship by Pacific Express
TLORU	Ship by Pacific Express in care of
TMPSV	Ship by Pacific Express to
TNQTX	Ship by Wells-Fargo Express
TORUX	Ship by Wells-Fargo Express in care of
TPSVY	Ship by Wells-Fargo Express to
TQTXZ	Ship with next carload
TRUXA	Ship by freight
TSVYB	When and how did you ship parts called for in my (our) telegram of
TTXZC	When and how will you ship parts called for in my (our) telegram of
TUXAD	When and how did you ship parts called for in my (our) letter of
TVYBE	When and how will you ship parts called for in my (our) letter of
TXZCF	When and how did you ship parts called for in my (our) order No.
TXADG	When and how will you ship parts called for in my (our) order No.
TYBEH	When and how will you ship balance of parts called for in my (our)
TAEIM	Do not send parts called for in my (our) telegram of
TBFJN	Do not send parts called for in my (our) letter of
TCGKO	Do not send parts called for in my (our) order No
TDHLP	Add to my (our) telegraph order of
TEIMQ	Add to my (our) letter order of
TEKNR	Add to my (our) order No.
TGKOS	Parts ordered in your telegram were shipped by Express on
THLPT	Parts ordered in your letter were shipped by Express on
TZCFI	Parts ordered in your order Nowere shipped by Express on
TIMQU	Parts ordered were shipped by American Express on
TKNRV	Parts ordered were shipped by U. S. Express on
TLPTX	Parts ordered were shipped by National Express on
TNRVB	Parts ordered were shipped by Adams Express on
TPTXC	Parts ordered were shipped by Pacific Express on
TRVZD	Parts ordered were shipped by Wells-Fargo Express on

MOTOR

Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Selling Price
Aback Abaft Abase Abash Abate		1MCA418 1MC46 1MCA35 1M22 1M123	CYLINDER Cylinder, with parts to Miscellany Cylinder Piston with rings and pin (see below) Cylinder cover "" stud		8 8 8	3A 5A 6A	\$72.00 40.00 7.50 1.50




When ordering parts use Code Word
GROUP 1—MOTOR

8

MOTOR

Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Sellin Price
			CYLINDER—Continued				
		10X81	Cylinder cover stud nut				
Abatis		1M165	" " " melet				\$.0
bbess		1M166	" " nut gasket				
Abbey		1M112	" " gasket				
Abbot		1M11	Inlet valve cap		8	10A	1.
bdomen		1MF18	Exhaust valve cap				1.
bduct		1M110	Valve cap gasket			7277	
bhor		1MX1177	Valves		8	15A	2.
bide		1M116	Valve springs		8	16A	
biding bigail		1M178	" stem collar		0	17A	
DIGUII		19X12	Gas and water manifold stud				
		19X16	Stud				
		19X15	Exhaust manifold stud				
		21X51	5/8 washer				
			CYLINDER MISCELLANY				
bility		1M216	Cylinder gasket				\$0.
		22/12/10	See crank case for base bolts 1MC118 and				Ψ0.
			1MX1179		1		
		10X46	Cylinder base bolt nut				
		21X25	washer				
bject		1M167	Priming cock		8	25A	
bjure blative		5MC130 5M16	Spark plug with switch nut		28	26A	1.
Diative		4X14	" " gasket Cylinder carburetor pipe cock				- 1
blaze		1MX1264	Timing indicator		8	29A	
Diuze		IMAILOI	PISTON		0	2711	
base		1MCA35	Piston, with rings and pin				\$7.
board		1MC32	Piston		8	35A	3.
bode bolish		1MO129 1M124	" ring		8	36A 37A	
bound		1M174	" pin " set screw		0	SIA	
bound		111111					
			CONNECTING ROD				
bsolve		1MA227	Connecting Rod Assembly		8	7.5	\$7.
bstain		1M32 1M17	" with cap		8	46A	
bstract		1M18	" " lower bushing " cap bushing		8	47A 48A	
bstruse		1M16	" upper bushing		8	49A	1.
bsurd		1M128	" cap bolt				-
		10X79	nut				
bundant		1M195	" " shim .0285				
buse		1M196	.032				
busive		1M197	.0339				
butment		1M198	.003				
buttal		1M1229	.003				
			CRANK CASE				
byss		1MCA416	Crank Case Upper Half Assembly				\$150.
bysmal		1MC41	Crank case, upper half		10	61A	100.
cacia		1MC118	Cylinder bolts (when compres. block is used)				
cademy		1MX1179	County shoft fromt have one with hu-14-		10	610	
cantnus		1MC162 1MC163	Crank shaft front brg. cap with bushing "front center brg. cap with bush'g		10 10	64A 65A	
carpous		1MX1215	" rear center brg. cap with bush'g		10	66A	:
caulous		1MX238	" rear brg, cap with bushing		10	67A	1.
ccede		1MX1216	" rear brg. cap with bushing brg. bolt (long)		10	68A	1.
ccent		1MX1218	(SHOFT)		10	69A	
ccept		1MX1217	" " " washer				
		10X14			INI		
ccess		1MX1206 1MX1207	Crank shaft front and center brg. shim .003		24		
ccident		1MX1207 1MX1208		-4			:
ccost		1MX1208	" " rear bro shim 003				
ccosted		1MX1210	" " " " 065				
ccount		1MX1211	11 11 11 11 11 032				
ccoutre		1MC128	" front bearing upper bushing				
ccrue		1MC129	" " lower bushing				
ccuracy		1MC130	" " ctr. brg. upper bushing				
ccurse		1MC131					
ccusant		1MC132	rear ctr. brg. upper bushing				
ccuse		1MC133 1MC134	lower pushing				
		1MC134 1MC135	" bearing upper bushing lower bushing				
		11410133					
cetify		11X421	" " bushing pin				


When possible, order through Thomas Dealer




When ordering parts use Code Word GROUP 1—MOTOR

10

			MOTOR				
Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Selling Price
			CRANK CASE—Continued				
Acetous		1R119	Pump bracket cap		10	84A	\$0.50
		14X37	" screw				
Aching		1MC1106	Magneto and pump shaft bushing				1.50
Acidity		1MX1213	Cam shifting shaft bushing				.25
Aciform		6MC152	Oil inlet elbow				.35
Acolyte		7M121	Filling plug with gasket		34	88A	.15
Aconite		7M140	" gasket				.05
Acorn		1MCA417	Crank Case Lower Half Assembly				51.00
Acquit		1MF414	" ' lower half		11	96A	47.00
Acreage		1MC153	" rear cover		11	97A	1.00
Acrid		1MC177	" " front cover		11	98A	.90
		1MC154	" oil tube 5% dia. x 43		11	99A	
Across		1MC1108	" oil tube plug		11	100A	.05
		23X97	Oil inlet elbow in rear cover				
		23X514	" outlet nipple to sight feed	7			
		1MX425	Crank case, lower half gasket				
			CRANK CASE LOWER HALF MISC.				
Action		1MCA199	Crank case drain cock		11	110A	\$0.80
Active		1MCA1101	Safety handle, with stem				.40
Actor		1MC175	" stem only		11	112A	.15
Actress		1MC173	" " only		11	113A	.15
Actual		1MCA1100	Full handle, with stem		8	114A	.40
Actuate		1MC176	" stem only			115A	.15
Acumen		1MC174	" " only		11	116A	.15
Acute		1MC151	Drain cock stem bracket				.10
		14X338	Attaching screw				
		3X332	" bolt				
			VALVE LIFTER				
Adage		1MCA179	Valve Lifter Guide Assembly (R)				\$3.85
Adagio		1MCA180	" " (L)				3.85



When possible, order through Thomas Dealer



Automotive Research Library

	7				d de	No.	
Code Word	Style of Body	Symbol .	Name of Part	Foreign Symbol	Illus- trated on Page	on Plate	Sellin
			VALVE LIFTER—Continued				
Adamic		1MC160	Valve lifter guide (right)				\$1.60
Adays		1MC161 1MC155	" " (left)				1.60
Adder		1MC184	" with roller, pin, yoke and key		8	130A	1.95
Addict Adding		1MC158 1MC159	" " roller pin				.20
Addle		1MC116	" " adjusting nut		8	133A	.25
		10X24 1MC156	" adjusting nut lock nut yoke				
		1MC1107 14X34	" " yoke key				
		14X34	Attaching screw				
			INLET CAM SHAFT				
Adduce		1MCA419	Inlet Cam Shaft Assembly with gear less gear				\$32.00
Adducing Adept		1MCA48 1M320	" " shaft		12	142A	10.00
Adequacy		1M1182 9X26	" " key		12	143A	1.15
Adhere		1MC111	Front bearing		12	144A	3.00
Adherent		1MC112 1MC113	Center bearing (front)		12	145A 146A	2.25
Adhesion Adhesive		1M132	" (rear)		12	147A	2.25
Adieu		1M1163	Thrust disc		12 12	148A 149A	.20
Adipose Adjacent		1M1166 1MX1243	Timer driving gear		12	150A	1.15
Adjoin		1M232	Main gear		10	151A	3.50
Adjourn		1M1133 14X75	" " screw				.05
			INLET CAM SHAFT MISCELLANY				
Adjudge		1M1130	Front bearing screw				\$0.10
Adjunct		1M1103	Center bearing screw				.10
Adjure		10X22 1M19	Bearing screw nut Rear bearing				1.75
Adjust		14X34 1M1247	" " screw " gasket				.05
			EXHAUST CAM SHAFT				
Admire		1MCA420	Exhaust Cam Shaft Assembly with gear				\$34.50
Admiring Admit		1MCA47 1MC33	less gear		12	167A	31.00
Admonish		1M1183	" " bay		12	168A	1.25
Adonis		9X26 1MC110	" key cam shaft front bearing		12	169A	3.00
Adherent		1MC112	Center bearing (front)		12	145A	2.25
Adhesion Adhesive		1MC113 1M132	" " (rear)		12 12	146A 147A	2.25
Adoption		1MX1204	Shifting collar		12	170A	.35
Adieu		1M1163 1M1166	Thrust disc "collar		12	148A 149A	.20
Adipose Adorable		1M177	Spring collar pin		12	171A	.05
Adore Adorn	\	1M199 1M1106	" seat " washer		12	172A 173A	.10
Adown		1MC152	Oil pump drive gear		12	174A	1.50
Adrift		1MC126 9X26	Air pump eccentric key		12	175A	1.00
djoin		1M232			10	151A	3.50
Adjourn		1M1133 14X75	Main gear " screw				.05
			EXHAUST CAM SHAFT MISCELLANY	1			
Adjudge		1M1130	Front bearing screw				\$0.10
Adjunct		1M1103	Center bearing screw			4	.10
Adjure		10X22 1M19	Bearing screw nut Rear bearing				1.75
Adjust		14X34 1M1247	" " screw " gasket				.05
aujust		1111247	gasket				.0.
desit		1MV1214	EXHAUST CAM SHAFT SHIFTING SHAFT				\$0.45
Adroit Acidity		1MX1214 1MX1213	Shifting shaft bushing				.25
Adult		1MX1180	" fork		8	182A	.75
Advance		1MX1228 9X23	" lever and fork key		8	182A	
dvent		1MC1102	" lever spring				.15


When possible, order through Thomas Dealer

MOTOR

Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Sellin; Price
			MAGNETO GEAR SHAFT				4
Adverb		1MX1212	Shaft		10	190A	\$2.7
dverse		1M1169			10	191A	2.0
		9X27	" gear kev				
dvice		1M1164	Thrust disc (front) " (rear)				-
dytum lerial		1M1165 1M115	Shaft coupling clutch				
erify		1MO1123	" clutch				
ffable		5M17	Coupling block				
		14X323	Clutch screw				
7		18X11	Spring Note—See crank case and gear cover for bushings.				
			WATER PUMP SHAFT				
ffair		1MOO143	Shaft		10	200A	\$1.
dverse		1M1169	" gear		10	191A	2.
		9X27	Rey				
dvice dvtum		1M1164 1M1165	Thrust disc (front)				:
uytum		1111103	Note—See crank case and gear cover for bushings.				
			CRANK SHAFT				
ffect		1MX421	Crank Shaft		10	210A	\$125.
ffiant		1MX1186	" gear (helical) 30T-9P			211A	4.
		9X27	" " gear key				
ffirm		1MX1185	" nut			212A	
ffix		1MX1187			10	123A	2.
fflatus		9x23 1MC23	" clutch key Fan drive pulley		10	214A	3.
matus		9X27	" Lev		10	21411	3.
fflict		1MX1188	" " nut		10	215A	
fflux	**	1MX1201	" " washer				
			FLY WHEEL				
fford		1MX419	Fly Wheel		8	220A	\$25.
		3X334	" bolt " bolt				
		10X73	" bolt nut				
			FLY WHEEL GUARD				
ffray		1MCA414	Fly Wheel Guard Assembly				\$1.
fghan		1MC410	(only)				
field		1M221	Bracket (right)				
fire		1M220	" (left)				
		19X13 10X410	" stud " stud nut				
		102410	stud nut				
			MOTOR GEARS				
m		134V1106	C 1 1 5 (1-11-1) 20T 0D		10	2444	
ffiant djoin		1MX1186 1M232	Inlot and exhaust cam shaft gear 60T-0P		10 10	211A 151A	\$4.
dverse		1M1169	Crank shaft gear (helical) 30T-9P Inlet and exhaust cam shaft gear 60T-9P Magneto and pump gear 20T-9P			191A	2.
djacent		1MX1243	Timer driving gear 18T-10P Oil pump gear 7T-10P Timer driven gear (bevel)		12	150A	1.
down		1MC152	Oil pump gear 7T-10P			174A	1.
lbum		1MX1262	Timer driven gear (bevel)		32	292A	1.
			GEAR CASE COVER				
firman		1MCA421	Gear Case Cover Assembly			302	\$14.
		1MC45	Gear case cover		10	236A	
foot		1MC1105	Magneto and pump gear shaft bushing				1.
ore		1MX424 1MX1189	Cover gasket		10	238A	:
fresh		1MX1190	packing nut "lock		10	238A	
		15X414	Nut lock screw				
frit		1MX1205	Starting bracket attaching bolt				
1			COVER MISCELLANY				
fter		1MX1191	Packing ring				\$0
		24X47	"				Ψ0
		14X332	Attaching bolt				
		10X41 14X33	" nut " screw				

When ordering parts use Code Word

		-	MOTOR				
Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Selling Price
Afterward Again Agape Agate Agave Agency Agenda		1MCA415 1M35 1M176 1M170 1MC168 9X26 1MC117 1MC1104	STARTING CRANK Starting Crank with Handle, Shaft and Collar Starting crank only " handle handle sleeve shaft " shaft " key shaft collar with dowel Collar dowel		15 15 15 15 15 15	246A 247A 248A 249A 250A 251A	\$3.70 1.00 .35 .35 .90 .45 .05
Agent Aggregate Aggress Aghast Agile Agility Afrit		1MCA422 1MC31 1MC167 1MC196 1MX1195 1MX1205 10X11 21X36	STARTING SHAFT BRACKET Starting Shaft Bracket with All Fittings Starting shaft bracket " " clutch " " clutch spring " " clutch spring retainer (One retainer includes two halves) Spring thrust washer Starting bracket attaching bolt Bolt nut " washer		10 10 10 10 10	256A 257A 258A 259A	\$4.25 1.20 2.50 .05 .40 .15
Agitate		1MCA210	AIR PUMP Motor Air Pump Assembly			1	\$13.70
Aglet Aglow Agnail Agnate Agoing Agony		1MC119 1MC29 1MC123 1MC124 1MC144 1MC127	Pump base " cylinder " piston " pin " pin lock " eccentric rod		66	266A 267A	1.15 4.15 .85 .10 .05 3.25



When possible, order through Thomas Dealer

MOTOR

Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Selling Price
			AIR PUMP—Continued				
		1340105	Domes into an los				CO 15
lgree lground		1MC185 1MC186	Pump inlet valve "spring				\$0.15
guish		1MC188	" " cap				.15
head		1MC187	" " spring washer				.05
imless		1MC189	" relief valve				25
		1X11	Dall 1/4 diameter				
iring		1MC190	valve casing		66	277A	.40
Airless Aisle		1MC191 1MC192	" valve spring " valve spring seat				.05
kimbo		1MC193	" valve spring can				.05
lack	*	1MC194	" valve adjusting screw		66	281A	.10
llarm	FA	1MC195	" valve adjusting nut				.05
			AIR PUMP MISCELLANY				
		22VE14	Air inlet simple				
	1	23X514 23X98	Air inlet nipple Air outlet ell				
		5X14	Connection				
		14X328	Pump attaching screw Pump inlet tube				2
lbatross		1MC1109	Pump inlet tube		66	283A	\$0.05
1124		1MC4011	TIMER DRIVE	100			01 50
lbino		1MCA211	Timer Drive Shaft with gear		32	291A	\$1.50
lbino lbum		1MC166 1MX1262	Timer drive shaft only Shaft gear		32	291A 292A	1.25
lbumen		1MCA1113	Timer drive shaft bracket with bushings		32	293A	2.40
lcaid		1MC164	Bracket upper bushing		32	294A	.85
lchemy		1MX1260	lower bushing		32	295A	.70
		6X11 14X82	grease cup		32	6X11	
		14882	" screw				
	-		OIL PUMP (Old Style)				
lcohol		6MCA36	Oil Pump with lower driven shaft 672" long				\$6.70
lcoran		6MC25	" case with strainer		11	301A	2.95
		11X416	dowel		-22-	302A	1.30
lcove		6MC131 6MC145	" " cover " strainer		11	302A	1.50
lderman		6MC132	" " impeller		11	304A	1.00
lert		6MC132 6MC133	" impeller shaft 6.7."			305A	.30
		9X21	impeller key				
lgebra		6MC134					.10
lias		6MC115 14X33	impener blade spring				.05
		14X31	Case cover screw				
libi		6MC168	" gasket				.10
			OIL PUMP (New Style)				
lien		6MCA34	Oil Pump with shaft 523" long				\$6.70
lienate		6MC213	" case with strainer				2.95
lienator		6MC166	" case with strainer " impeller shaft 533" long				.30
			All other parts same as for old assembly				
liferous	1	6MC124	6MCA36 Oil Pump Drive Shaft (Center Section)		11	310A	.70
light		6MC125	Shaft bushing		11	311A	.65
like		6MC126	" retainer			312A	.50
limony		6MC143	" lock				.10
		15X427				314A	.25
liquant		6MC16 6MCA167	" coupling Oil Pump Drive Shaft (Upper Section) Ass'y.		11	314A	2.40
liquot live		6MC122	Drive gear		11	321A	1.25
lkali		6MC123	Drive gear thrust cap		11	322A	.35
llayed		6MC128	Driven gear thrust rod		11	323A	.15
llege		6MC129	sleeve		11	324A	.50
		16X17	Sleeve lock screw				
llegro		10X21 6MC130	Thrust rod nut " " washer				.05
			MOTOR PITTINGS & ATTACHING SARRE				
			MOTOR FITTINGS & ATTACHING PARTS				
llot		1MCA28	Oil Can Holder Assembly				\$1.40
llow		1MX210 1MC178	" " " plate				.65
Haniac							.30
llspice		1M1119	" " plungers				OF
llspice llude lluring		1M1118 1M1113	Plunger spring				.05

When ordering parts use Code Word

					41		
Code Word	Style of Body	Symbol .	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Selling Price
			VENT PIPES				
Alluvial		1MA145	Vent Pipe (Long) Complete		8	345A	\$1.50
******		1M150	Pipe				
		1M149	" can				
		1M151	" baffle				
		1M147	" flange				
Almanac		1M152	" cap gauze				.05
Almond		1M146	" cap gauze retainer				.15
Almonry		1M1170	Gasket				.05
announ's		14X33	Attaching screw				
Almost		1MCA181	Vent Pipe (Short) Complete		66	355A	1.50
		1MC182	Pipe				
		1MC183	screw flange				
		11110100	Other parts are same as for 1MA145				
Ablaze		1MX1264	Timing Indicator		8	29A	.10
			COMPRESSION RELIEF				
Almug		10MCA212	Compression Relief Rod Complete				\$1.75
Aloft		10MC176	Rod only				.30
Alone		10MC177	" clevis				.25
		10X21	nut				
		11X71	" clevis pin				
Along		10MC135	nandle			368A	.75
Aloof		10MC178	pin (iront)				.10
		15X319	Screw				
		10X313	nut				
			For relief rod bracket, see "Radiator"				
			MOTOR ATTACHING PARTS				
							00.05
loud		1M1246	Motor leg shim				\$0.05
Ipaca		1MX242	block (front-right)				1.65
lpha		1MX241	(front-left)				1.65
ltar		1MX239	(rear-right)			7777	1.65
		1MX240	(rear-left)			21-1-1	1.65
Ilthea							
Althea		3X320 10X13	" bolt " nut				

GASOLINE SYSTEM


Code Word	Style of Body	Symbol	Name of Part		Foreign Symbol	Illus- trated on Page	No. on Plate	Selling Price
			CARBURETOR	•				
Babble		2MCA29	Carburetor Assembly (Miller X-1½)			18	1B	\$25.00
Baboon		2MC225	" body XC397			10	110	Ψ20.00
Babvish		2MC1137	" float			18	3B	
Bachelor		2MC1137	" glass			18	4B	
Backbite		2MC1138				18	5B	
			" glass cover	*		18	3D	
Backbone		2MC1140	giass gasket	3.				
Backdoor		2MC1141	Carburetor Water Jacket			18	8B	
Backed		2MC1142	" " nipple			2		
Backward		2MC1143	clamp screw					
Bacon		2MC1144	set screw					
Badge		2MC1145	Carburetor Sliding Air Sleeve			18	10B	
Badly		2MC1146	High speed adjusting screw			-30%		
Badness		2MC1147	" " spring				65	
Baffle		2MC1148	Throttle Valve with voke 2MC1153			18	15B	
Baggage		2MC1149	" " shaft					
Bagnio		2MC166	" ' lever			18	17B	
Bagpipe		2MC1150	" lever lug with screw					
Bailbond		2MC1151	" lever lug screw					
Bailed		2MC1152	" set screw					07000
Bailee		2MC1153	Yoke from valve to sliding sleeve			18	18B	
Bailiff		2MC1154	Normal Air Inlet Flange			18	20B	
Bairn		2MC1155	Flange gasket			10	20D	
Baize						10	24 D	
		2MC1156	Air inlet adjusting nut			18	21B	
Baker		2MC1157	Needle valve assembly			18	23B	
Bakery		2MC1163	spring					
Baking		2MC1161	base screw					
Balance		2MC1162	Spray nozzle vacuum flange			1000		

When possible, order through Thomas Dealer

GROUP 1-MOTOR GROUP 2-GASOLINE SYSTEM

GASOLINE SYSTEM

Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Selling Price
Million B			CARBURETOR—Continued				
Balcony		2MC1164	Needle valve bell crank		18	30B	
Baldric		2MC1165	Crank low speed adjusting screw		18	31B	
Baleful		2MC1166	Auxiliary crank with roller		18	32B	
Ballad		2MC1167	Crank pin				
Ballast		2MC1168	Air inlet flange attaching screw (short)				
Ballet		2MC1169	Attaching screw (long)				
Balloon		2MC1170	Gas. Level Tube with Adjustm't and Primer				
Balmy		2MC1171	Tube		FEET		
Balsam		2MC1172	Valve		18	37B	
Bamboo		2MC1173	Spring				
Banana		2MC1174	guide		18	39B	
Bandage	*******	2MC1175	adjusting sieeve		18	40B	
Bandana		2MC1176	Primer bracket				
Bandbox		2MC1177	" lever spring		18	42B	
Bandeau		2MC1178	" lever spring Float lifter		10	44B	
Banded		2MC1179			18 18	44B 45B	
Bandit		2MC1180 2MC1112	Gasoline inlet nipple		18	102	\$0.15
Bandrol		5X15	" connection or reduc'g coupl'g				\$0.13
D		2MC210			18	48B	
Bandy		2MC210	Hot air connection		18	48B	
			CARBURETOR MISCELLANY				
Baneful		2MC167	Carburetor gasket				\$0.10
Banish		1M1115	Jacket pipe connecting nut				.35
Banjo		2MC1117	" inlet pipe				.10
Banked		2MC1118	" outlet pipe		2000		.20




When ordering parts use Code Word GROUP 2—GASOLINE SYSTEM

GASOLINE SYSTEM

Code Word	Style of Body	Symbol Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Selling Price
			CARBURETOR MISCELLANY—Continued				
		AVIA	Toolset nine outlinder cools				
		4X14 14X340	Jacket pipe cylinder cock Attaching screw				
		14X18	Filister head screw				
			PRIMING ROD				
Barrow		10MCA165	Carburetor Priming Rod Assembly				\$0.50
Baseless		10MC166	Rod with collars				.15
D1		10M1131	" collar " button				.10
Bashaw		10M1130 10X36	" button " nut				.10
Bashful		2MC1136	" spring				.05
		211101100					
			GAS INLET MANIFOLD				
Basic		2MCA44	Gas Inlet Manifold		18	70B	\$15.50
Dasio		2MC26	Connection				Φ10.00
		2MC149	Short tube (center)				
		2MC215	Rear tube				
		2MC214	Front tube				
Danit		2MC147	Cylinder flange				
Basil		2MO11 10X43	Cylinder gasket "stud nut				.15
		10143	stud nut				
			GASOLINE TANKS				
Basin	TP	2MCA31	Gasoline Supply Tank		63	80B	\$36.00
Basis	**	2MC14	Tank filler			0013	2.40
Basked	TPR	2MC14 2MC162	" cap		63	82B	.90
Bassoon	TPR	6MC136	" cap gasket				.05
		2MC11	" rear flange		20	84B	.25
		2MC165	front nange		20	86B	.25
		2MC16	drain nange		20	80B	.50
		12X15 2MC144	" drain flange plug " outlet pipe		20	87B	.10
Basted		2MC1119	Air valve				.60
		5X14	Valve connection				
		23X97	Gasoline outlet ell				
		5X15	Connection				
Bastile	TP	2MCA36	Gasoline Reserve Tank Assembly				8.00
Basked		2MC1125 2MC162	Cover flange				1.00
Bastion		6MC136	Filler cap " gasket				.05
Batch		2MCA1124	Tank strainer assembly				.75
		2MC1135	" " head				.10
		2MC1134 2MC1133	" cylinder				.25
		2MC1133	ring				.10
Baton		2MC189	Outlet flange				.25
baton		2MC1132 5X14	Air connection flange Solderless connection				.50
		23X97	Outlet ell				
		5X15	connection				
Batten	S	2MCA32	Gasoline Supply Tank Assembly		20	89B	36.00
			All fittings same as for touring car tank 2MCA31.				
Batter		1EMC220	Casalina Tank Hanger (front)		63	100B	1.40
Batting		15MC328 15MC329	Gasoline Tank Hanger (front) (rear)		63	100B	1.60
		14X36	Hanger bolt 3/8-16X1				
		14X211	" 3/8-16X1½				
		10X43					
		14X34	" " 518-18X1 " nut				
Battle		10X415 15MC25	Gasoline Tank Strap		,		1.00
- Luc		3X34	" " holt 13/				1.00
		3X310	" " " 2				
		10X11	" " " nut				
Bawble	S	2MCA37	Gasoline Reserve Tank Assembly		50		8.00
Bawdiness	R	23471420	All fittings same as for touring car tank 2MCA36.			100	36.00
Bawdiness		2MCA38	Gasoline Tank Assembly Filler assembly				3.35
Bayard		2MCA46 2MC221	" ell				2.40
Basting	TPR	2MC162	" cap				.90
Bastion		6MC136 2MC1129	" cap gasket				.05
Bayberry		2MC1129	" strainer ring seat				.50
Bayed		2MCA1128	" strainer assembly				1.00
Paranet		2MC1127	THIS				.0
Bayonet		2MC1126	stramer				.7
Bayou		2MC224 2MC1130	" tube " tube flange				1.2
Jay Uu	menenee	2MC1130	" tube flange gasket				.2
Baysalt			" Aanga				

When possible, order through Thomas Dealer

GROUP 2—GASOLINE SYSTEM



GASOLINE SYSTEM

Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Selling Price
			GASOLINE TANKS—Continued				
		14X36	Clama halt				
		10X423	Clamp bolt				
Bazaar	R	2MCA223	Gasoline tank filler tube assembly				\$2.75
dellium	R	2MCA39	Gasoline Reserve Tank All other parts used same as for touring car tank 2MCA36.				8.00
			GASOLINE VALVE				
each		2MCA218	Gasoline Valve Assembly		20	108B	\$3.00
Beached		2MC217	Valve body				1.65
eachy		2MC194	" plug		20	110B	.80
Beaconed		2MC183 2MC182	" " washer " spring				.05
leadle		2MX151	" spring washer				.05
		23X515	Solderless connection nipple				
	2	5X15	" connection				
leadleism	S	2MC1120	Gasoline valve supporting angle		20	111B	.35
			MISCELLANY				
leadlery		2MC1115	Valve floor plate		1		\$0.35
		17X222	" screw				
		15X412 10X33	" screw " nut				
			GASOLINE FILTER				
leaker	TPS	2MCA216	Gasoline Filter Assembly		20	115B	\$2.90
eakiron	IFS	HH169	Body		20	116B	1.25
ealiah		2M15	" can		20	117B	.25
ealoth		2M16	" " gasket				.05
eamful		FH130	Strainer with nut				.50
		2M17 2M18	Strainer " nut				
		23X97	Connection nipple				
		5X15	" in the second				
		4X21	Drain cock				
		15X48	Filter bracket screw				
		10X33	nut				
			GASOLINE TUBES				
eard	TP	2MC1105	Tube from tank to 3-way valve		20	120B	\$0.45
earer		2MC1106	" " 3-way valve to filter			121B	.10
earing	TD.	2MC1107	niter to carburetor			122B	.30
	TP S	2MC1108	reserve tank to 3-way valve		20	123B	.10
		2MC1123	reserve tank to 3-way valve			2	
east		2MC1122	" " cupply tank to 3 way valve				50
earish east eastly eatify	SR TP	2MC1122 2MC1121	" supply tank to 3-way valve " gasoline tank air valve to res. tank				.50

EXHAUST SYSTEM.


Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Selling Price
Cabal Cabin Caboose Cacao Cache Caddy		3MCA41 3M26 3M27 3MC24 3M28 3MC11 14X335	EXHAUST MANIFOLD Exhaust Manifold Assembly Manifold center "front end "rear end "tube "tube "to pipe sleeve "to pipe sleeve screw	*	22 22 22 22 22 22 22 22	2C 3C 4C 5C 6C	\$10.00 2.70 2.00 2.50 .60 1.25
Caique Cadence		3M11 10X43 3MC31	EXHAUST MANIFOLD MISCELLANY Manifold gasket "stud nut Exhaust Pipe			 8C	\$0.15 2.05

When possible, order through Thomas Dealer

GROUP 2—GASOLINE SYSTEM GROUP 3—EXHAUST SYSTEM

EXHAUST SYSTEM

Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Selling Price
			MUFFLER				
aiole		3MCA42	Muffler Assembly		22	10C	\$12.50
alamite		3MCA211	" shell assembly				2.80
		3MC27	Shell				
		3MC212	" lining				
		3MC213	" lining retainer				
alamus		3MCA29	Silencing cone No. 1 (front center)				.50
alcine		3MCA36	" No. 2 (center)				.50
alculus		3MCA35	" No. 3 (rear center)				.50
alendar		3MCA210	" No. 4 (front rear)				.50
aliber		3MCA39	" No. 5 (center rear)				.50
alico		3MCA38	" No. 6 (rear rear)				.50
allous		3MC19	Internal pipe (front)				.50
alomel		3MC18	nut				.15
alumet		3MC110	" (rear)				.30
alvary		3MC17	" (rear) cap				.20
		3MC113	" (rear) cap pin				
alyx		3MC111	" connection				.15
amber		3MCA214	Cutout Head with all fittings				3.75
ambric		3MC33	" head only		22	12C	2.50
amel		3MCA14	valve (nead and stell)		22	13C	.50
		3MC15	nead only				
		3MC16	stem only				
		10X77	nut			7775	
amphor		3M18	spring		22	14C	.05
anary		3M19	spring seat				.10
ancel		3M16	lever bracket		22	15C	.30
		15X438	" bracket screw			77.00	
andent		3M15			22	16C	.20
		13X611	pin				
		14X314	Muffler head clamp screw			100	1 50
andle		3MC34	Muffler Rear Head		22	18C	1.75
		15X439	" head screw				
anine	TP	3MC112	nead packing		22	200	.10
anker annibal	SR	3MC26	Muffler Tail Pipe		22	20C	2.00 1.75
annibai	DK .	3MC12 15MC26	" tail pipe				.50
попп		3X38	Muffler Hanger Strap				.50
		14X337					
		141337	Screw 3/8-24x1				
			CUTOUT OPERATING ASSEMBLY				
			Note.—See page 49 for parts.	- 100 March 1990			



When ordering parts use Code Word


GROUP 3—EXHAUST SYSTEM

COOLING SYSTEM

Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Sellin
			FAN—1st DESIGN				
Dabble		4MCA45					\$25.5
Dactyl		4MC46	Fan Assembly with cone and cup bearings Fan				8.5
Dagger		4MC13	" enindle				1.0
Dainty		4MC111 4MC110	" hearing cone (rear)				.3
Damage		4MC110	(Iront)				.3
Damper		4MC112	" cup " ball				.9
Damson		1X11 4MC113					.0
Damson		4MC114	" ball retainer				.0
Darken		4MC115	" dust washer Dust washer retainer				.0
		10X43	Spindle front nut				
		10X24	" rear nut				
		7X11	Fan hub oiler				
Dastard		4MC31	" bracket (on crank case)				2.2
Dative Daunt		4MC16 4MC15	spindle bracket				2.7
Dawdle		4MC17	" stop pin key				.2
Dazzle		4MC14	" spring				
		3X328	Attaching bolt				
		10X44	nut				
eaden		4MX212	Fan Belt		26	15D	2.0
			4-1				
			FAN—2nd DESIGN				
Deadlock		4MCA410	Fan Assembly with annular bearings				\$24.7
Deafen		4MC49	Fan		24	1D	8.5
Dearth		4MC151			24	2D	1.0
		10X83	" nut				
		10X24 2X27			24	3D	2.3
ebar		4MC148	" bearing No. 203 " separator		24	4D	.2
Debate		4MC147	" retainer		24	5D	.6
ebris		4MC152	" retainer felt packing ring				.0
Decade		4MC149	" " cap		24	6D	.5
		15X48	" cap screw				
Decamp		4MC150	" spindle bracket		24	7D	2.7
		6X14	" grease cup " bracket on crank case		24		
Decant		4MC34				8D	2.2
		3X328 10X44	" bolt " bolt nut				
Daunt		4MC15	Bracket stop pin				.1
Dawdle		4MC17	" key " spring		24	9D	.2
Dazzle		4MC14			24	10D	.0
Deaden		4MX212	Fan Belt		26	15D	2.0
			WATER MANIFOLDS	1			
		4MCA42					
Deceit			Water Inlet Manifold		26	16D	\$10.0
Deceit		4M15	Cylinder flange		26	16D	\$10.0
		4M15 4MX153	Cylinder flange Pump flange				
		4M15 4MX153 4M115	Cylinder flange Pump flange Gasket				.1
		4M15 4MX153 4M115 10X43	Cylinder flange Pump flange Gasket Stud nut				.1
ecember		4M15 4MX153 4M115 10X43 19X12	Cylinder flange Pump flange Gasket Stud nut Stud				.1
ecember		4M15 4MX153 4M115 10X43 19X12 4MCA43	Cylinder flange Pump flange Gasket Stud nut Stud Water Outlet Manifold			17D	10.0
ecember ecide		4M15 4MX153 4M115 10X43 19X12 4MCA43 4M16 4M113	Cylinder flange Pump flange Gasket Stud nut Stud Water Outlet Manifold Cylinder flange Gasket		26	17D	10.0
December Decide		4M15 4MX153 4M115 10X43 19X12 4MCA43 4M16 4M113 10X21	Cylinder flange Pump flange Gasket Stud nut Water Outlet Manifold Cylinder flange Gasket Stud nut		26	17D	10.0
ecember ecide		4M15 4MX153 4M115 10X43 19X12 4MCA43 4M16 4M113	Cylinder flange Pump flange Gasket Stud nut Stud Water Outlet Manifold Cylinder flange Gasket		26	17D	10.0
ecember ecide		4M15 4MX153 4M115 10X43 19X12 4MCA43 4M16 4M113 10X21	Cylinder flange Pump flange Gasket Stud nut Water Outlet Manifold Cylinder flange Gasket Stud nut		26	17D	10.0
December Decide		4M15 4MX153 4M115 10X43 19X12 4MCA43 4M16 4M113 10X21	Cylinder flange Pump flange Gasket Stud nut Water Outlet Manifold Cylinder flange Gasket Stud nut		26	17D	10.0
Decide Decide		4M15 4MX153 4M115 10X43 19X12 4MCA43 4M16 4M113 10X21 19X12	Cylinder flange Pump flange Gasket Stud nut Stud Water Outlet Manifold Cylinder flange Gasket Stud nut Stud WATER PUMP		26	17D	10.0
Decide Decipher		4M15 4MX153 4M115 10X43 19X12 4MCA43 4M16 4M113 10X21 19X12	Cylinder flange Pump flange Gasket Stud nut Stud Water Outlet Manifold Cylinder flange Gasket Stud nut Stud WATER PUMP Water Pump Assembly		26	17D	10.0
Decide Decipher		4M15 4MX153 4M115 10X43 19X12 4MCA43 4M16 4M113 10X21 19X12	Cylinder flange Pump flange Gasket Stud nut Stud Water Outlet Manifold Cylinder flange Gasket Stud nut Stud WATER PUMP Water Pump Assembly Case (front) with bushings		26	17D	10.0 10.0 .1
Decide Decipher Decisive Declaim		4M15 4MX153 4MX153 10X43 19X12 4MCA43 4M16 4M113 10X21 19X12 4MXA36 4MCA35 4MXA37 4MX37 4MX160	Cylinder flange Pump flange Gasket Stud nut Stud Water Outlet Manifold Cylinder flange Gasket Stud nut Stud WATER PUMP Water Pump Assembly Case (front) with bushings " front " rear bushing		26 26 26 26 26	17D	\$14.0 6.7
Decisive Decline Declivia		4MX153 4MX153 4MX115 10X43 10X43 10X12 4MCA43 4M16 4M113 10X21 19X12 4MXA36 4MCA35 4MCA35 4MX37 4MX160	Cylinder flange Pump flange Gasket Stud nut Stud Water Outlet Manifold Cylinder flange Gasket Stud nut Stud WATER PUMP Water Pump Assembly Case (front) with bushings " front " rear bushing		26 26 26 26 26 26	17D 18D 19D 20D 21D	\$14.0 6.7
Decide Decide Decipher Decisive Declaim Decline Decline Decline		4MX153 4MX153 4MX155 10X43 19X12 4MCA43 4M16 4M113 10X21 19X12 4MXA36 4MXA36 4MXA37 4MX160 4MX161 4MX157	Cylinder flange Pump flange Gasket Stud nut Stud Water Outlet Manifold Cylinder flange Gasket Stud nut Stud WATER PUMP Water Pump Assembly Case (front) with bushings " front " rear bushing		26 26 26 26 26 26 26	17D 18D 19D 20D 21D 22D	\$14.0 6.7
Decide Decide Decipher Decisive Declaim Decline Decline Decline		4MX153 4MX153 4MX1151 10X43 19X12 4MCA43 4M16 4M113 10X21 19X12 4MXA36 4MCA35 4MCA35 4MXA36 4	Cylinder flange Pump flange Gasket Stud nut Stud Water Outlet Manifold Cylinder flange Gasket Stud nut Stud WATER PUMP Water Pump Assembly Case (front) with bushings " front " rear bushing		26 26 26 26 26 26	17D 18D 19D 20D 21D	\$14.0 6.7
Decimber Decisive Declaim Decline Decline Declored Decocoda Decocotor		4MX153 4MX153 4MX153 10X43 10X43 19X12 4MCA43 4M16 4M113 10X21 19X12 4MXA36 4MCA35 4MXA37 4MX160 4MX161 4MX157 4MX158 4MX158 44MX158	Cylinder flange Pump flange Gasket Stud nut Stud Water Outlet Manifold Cylinder flange Gasket Stud nut Stud WATER PUMP Water Pump Assembly Case (front) with bushings " front " rear bushing " front bushing " packing nut " " lock nut		26 26 26 26 26 26	18D 19D 20D 21D 22D	\$14.0 6.7 .8 .2
Decisive Decline Declivia Decouotor Decou		4MX153 4MX153 4MX1153 10X43 19X12 4MCA43 4M161 10X21 19X12 4MXA36 4MCA55 4MXA36 4MXA36 4MXA36 4MXL160 4MXL160 4MXL157 4MXL158 24X49 4R22	Cylinder flange Pump flange Gasket Stud nut Stud Water Outlet Manifold Cylinder flange Gasket Stud nut Stud WATER PUMP Water Pump Assembly Case (front) with bushings " front " rear bushing " front bushing " front bushing " jacking nut " " cover (rear) " " rearbeet		8 26 26 26 26 26 26	17D 18D 19D 20D 21D 22D	\$14.0 6.7 .6 .8 .2 .1
Decimber Decide Decipher Decisive Decline Decline Decline Declivia Decoada Decocda		4M15 4MX153 4M115 10X43 19X12 4MCA43 4M16 4M113 10X21 19X12 4MXA36 4MCA35 4MXA7 4MX160 4MX161 4MX157 4MX158 4MX158 4MX158 4MX2449 4R22 4R210	Cylinder flange Pump flange Gasket Stud nut Stud Water Outlet Manifold Cylinder flange Gasket Stud nut Stud WATER PUMP Water Pump Assembly Case (front) with bushings "front bushing "rear bushing "front bushing "packing nut "" lock nut "" "" cover (rear) "" gasket "" "gasket "" "gasket "" "gasket "" "screw		8 26 26 26 26 26 26	17D 18D 19D 20D 21D 21D 22D 24D	\$14.0 6.7 .6 .8 .2 .1
Decimber Decide Decipher Decisive Decline Decline Decline Declivia Decoada Decocda		4MX153 4MX153 4MX1153 10X43 19X12 4MCA43 4M16 4M113 10X21 19X12 4MXA36 4MCA35 4MXA37 4MX160 4MX157 4MX157 4MX157 4MX157 4MX158 24X49 4R22 4R110 14X710	Cylinder flange Pump flange Gasket Stud nut Stud Water Outlet Manifold Cylinder flange Gasket Stud nut Stud WATER PUMP Water Pump Assembly Case (front) with bushings " front " rear bushing " front bushing " packing nut " " ' cover (rear) " " gasket " " gasket " " screw " " screw		8 26 26 26 26 26 26	17D 18D 19D 20D 21D 22D	\$14.0 6.7 .6 .6 .8 .8 .2 .1
Decide Decide Decipher Decisive Decline Decline Decline Declocada Decodo Decoclor		4MX153 4MX153 4MX1151 10X43 19X12 4MCA43 4M16 4M113 10X21 19X12 4MXA36 4MCA35 4MXA37 4MX160 4MX157 4MX150 4MX157 4MX150 4MX157 4MX158 24X49 4R22 4R110 20X25 4R113	Cylinder flange Gasket Stud nut Stud Water Outlet Manifold Cylinder flange Gasket Stud nut Stud Water Pump Assembly Case (front) with bushings "front "rear bushing "packing nut "" lock nut "" cover (rear) "" screw wire "" and shaft thrust disc		8 26 26 26 26 26 26	17D 18D 19D 20D 21D 21D 22D 24D	\$14.0 6.7 .1 1.9 .6 .6 .2 .1
Decisive Decisime Decisiva Decisime Decisime Decisime Decisima Decisima Decisima Decoada Decoada Decocodo Decolor Decolor Decolor Decolor Decolor Decorum		4MX153 4MX153 4MX153 10X43 10X43 19X12 4MCA43 4M16 4M113 10X21 19X12 4MXA36 4MCA35 4MXA7 4MX160 4MX157 4MX158 44X160 44X1157 44X1160 44X1157 44X1158 44X110 14X710 120X25 4R110 14X710 14X710 20X25 4R113 4MXA216	Cylinder flange Pump flange Gasket Stud nut Stud Water Outlet Manifold Cylinder flange Gasket Stud nut Stud WATER PUMP Water Pump Assembly Case (front) with bushings " front " rear bushing " packing nut " " " over (rear) " " gasket " " screw " " screw " " screw " " screw " " " screw wire " " " Pump Impeller with Shaft		26 26 26 26 26 26 26 26	18D 19D 20D 21D 22D 24D	\$14.0 6.7 .0 .0 .0 .0 .0 .0 .0 .0 .0 .0 .0 .0 .0
Decide Decide Decide Decisive Declaim Decline Decocotor Decoclor Decolor Decoultry		4MX153 4MX153 4MX1153 10X43 19X12 4MCA43 4M16 4MX13 10X21 10X21 10X21 4MXA36 4MCA35 4MX37 4MX160 4MX161 4MX157 4MX158 24X49 4R22 4R110 20X25 4R113 4MXA216 4MX159	Cylinder flange Gasket Stud nut Stud Water Outlet Manifold Cylinder flange Gasket Stud nut Stud Water Pump Assembly Case (front) with bushings front rear bushing front bushing packing nut " " " " " " " " " " " " " " " " " " "		26 26 26 26 26 26 26 26	17D 18D 19D 20D 21D 22D 24D 25D 31D	\$14.0 6.7 .0 .0 .0 .0 .0 .0 .0 .0 .0 .0 .0 .0 .0
Decide Decipher Decisive Deciline Deciline Decoda Decoda Decodo Decodlobis Decollo		4MX153 4MX153 4MX153 10X43 10X43 19X12 4MCA43 4M16 4M113 10X21 19X12 4MXA36 4MCA35 4MXA7 4MX160 4MX157 4MX158 44X160 44X1157 44X1160 44X1157 44X1158 44X110 14X710 120X25 4R110 14X710 14X710 20X25 4R113 4MXA216	Cylinder flange Pump flange Gasket Stud nut Stud Water Outlet Manifold Cylinder flange Gasket Stud nut Stud WATER PUMP Water Pump Assembly Case (front) with bushings " front " rear bushing " packing nut " " " over (rear) " " gasket " " screw " " screw " " screw " " screw " " " screw wire " " " Pump Impeller with Shaft		26 26 26 26 26 26 26 26	18D 19D 20D 21D 22D 24D	\$14.0 6.7 .1 \$14.0 .6 .7 .6 .6 .7 .6 .6 .7 .6 .6 .7 .6 .6 .7 .6 .6 .7 .6 .7 .6 .7 .6 .7 .6 .7 .6 .7 .6 .7 .6 .7 .6 .7 .6 .7 .6 .7 .6 .7 .6 .7 .6 .7 .6 .7 .7 .7 .7 .7 .7 .7 .7 .7 .7 .7 .7 .7

When possible, order through Thomas Dealer

GROUP 4—COOLING SYSTEM




When ordering parts use Code Word GROUP 4—COOLING SYSTEM

	#	- 1			e.	27-	
Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Selling Price
			WATER PUMP MISCELLANY				
Deflect		4M114	Shaft coupling		26	35D	\$0.75
0.0		9X26	" key				
Deflour		4MX167 18X21	" set screw set screw lock				.05
Deform		4M118	Outlet flange gasket				.10
		3X328 10X44	" bolt " bolt nut				
		6X14	Case grease cup				
Defunct		4MXA213	Pump Inlet Pipe		26	40D	1.50
		4MC28 4MC137	Pipe carburetor water header				
Degrade		4M116	Pump inlet pipe gasket				.10
		14X35 4M110	Pipe flange				.20
Deism		1M121	" divided plug and nut		26	41D	.35
Delay		1M1115	" " nut				.35
			RADIATOR				
Delight		4MCA44	Radiator Assembly		26	45D	\$80.00
Delude Delve		4MCA131 4MCA142	" filler assembly (see below) " outlet assembly (see below)		26	46D	5.00 1.60
Demand		4M146	" hanger		26	47D	1.15
Demean Demerit		4MC127 4M137	Relief rod support bracket Drain cock flange				.45
Jemerit		23X39	Street ell				
		4X22	Drain cock				
Demise Demon		4M142 4M129	Priming rod bushing Outlet connection				
Denary		4M112	Inlet connection	20			11111
Denizen		4MC153 4MC130	Hood rod bracket				
Denude Depend		24X32	Prest-O-Lite valve stem tube Trophy plate				.05
Deplore		4M128	Ledge leather				.10
			RADIATOR MISCELLANY				
Deplume		4MC18	Inlet hose (from cylinder)		26	55D	\$0.65
Deport		23X72 4MC19	Clamp Outlet hose (to punp)		26	56D	.40
Deport		23X73	" " clamp		20		.40
Deprave		4M125	Radiator bracket bushing		. 26	57D	.35
Depredate		4M126	" hanger washer				.05
			RADIATOR FILLER				
Delude		4MCA131	Radiator Filler Assembly		26	61D	\$5.00
Depress Deprive		4MC26 4MC135	Filler body "strainer		1500		.60
Depth		4MC132	" cap		26	62D	2.50
Depute		111X410 4MC120	" " nacking				.15
Deride		4MC134	" " latch wire with latch				.15
		4MC133	" " latch	biili			
		15X49	" latch wire screw				
			RADIATOR OUTLET				
Delve		4MCA142	Radiator Outlet Assembly		26	46D	\$1.60
		4M18 4MC141	Outlet elbow tube				
			RADIATOR STAY ROD				
Descant		4MCA27	Radiator Stay Rod Assembly				\$0.85
Describe		4MC11	Rod only				.35
		22X12	" clevis				
		10X23 11X14	" " nut " pin			24	
		10X49	" nut 76-20				

When possible, order through Thomas Dealer


GROUP 4—COOLING SYSTEM



When ordering parts use Code Word GROUP 4—COOLING SYSTEM

Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Selling Price
			MAGNETOS				
Cager		5MA23	Magneto (Bosch D-R-6) to run clockwise		28	1E	\$90.00
agle		5MXA217	" (Eisemann-EU)		20		65.50
arly		5M19	" shaft nut				
		21X23	" lock washer				
		9X22	key (Bosch)				
arnest		1M1120 5M18	dower		28	2E	1.00
arth		21/119	" shaft coupling Note—See page 14 for drive.		20	215	1.00
			BOSCH				
ager		5MA23	Magneto (Bosch D-R-6) to run clockwise		28	1E	\$90.00
			Note—When ordering parts mention Mag- neto Number and direction of rotation.				
			End Plates, Magnets or internal parts will				
			not be furnished to individuals.				
arthen		5MC146	Carbon brush with spiral spring for carbon				
			holder 11b	10			.10
arthling		5MC147 5MC148	Carbon holder without thread, with carbon 10 Complete connecting bridge with carbon holder (brass) together with insulation	11b			.40
asel		31110140	holder (brass) together with insulation				
			piece and lock spring	12			.95
aster		5MC149	Carbon with spring for brass holder on con-		- 1		
			necting bridge 12	13			.10
aves		5MC150	Rotating distributor piece without carbon	14			1 21
briety		5MC151	and spring Rotating distributor piece with carbon and	14	-4		1.2
oricty		OMOTOT	spring	14a			1.3
carte		5MC152	Carbon with spring for rotating distributor				
			piece	15			.10
centric		5MC153	Distributor disc without screws	16 21a			5.4
lat lectic		5MC154 5MC155	Dust cover without any other parts	22			.9
lipse		5MC156	Ebonite cover for distributor disc 16 Complete triangular clamp for the distributor				.9
			disc together with brass connecting piece				
			and spring	23			2.0
cliptic		5MC157 5MC158	Clamp only without parts Knurled nut for switch wire	23a 24			1.3
clogue		5MC158 5MC159	Knurled nut for switch wire	25			.0.
cstasy		5MC160	Spring for brass cap 26 Brass block for spring 25	25 27			.3
lentate		5MC161	Bolt for fixing spring 25	28			.0.
dged		5MC162 5MC163	Long screw for front end plate	36			.0.
dging		5MC163	Short screw for front end plate	37	www.		.0
dible difice		5MC164 5MC165	Oil cover for backside end plate	38			.1
dify		5MC166	Fastening screw for oil cover 38 Spiral spring for oil cover screws 39 and 50	40			.0
dition		5MC167	Screw for fastening the cover to backside end				
			plate	47			.0
ditor		5MC168	Fastening screw for oil cover 229	50			.0.
ducate		5MC169	Steatite cover for safety gap together with	103			2
duce		5MC170	electrode Fastening screw for dust cover	103 105a			.3
face		5MC171	Top screw for distributor disc and clamp	111			.0
ffect		5MC172	Top screw for distributor disc and clamp Bottom screw for distributor disc and clamp	112			.0
fective		5MC173	Insulating plate for connecting piece 27	114			.0
fete		5MC174	Fixing screw for connecting piece 27	116			.0
ficient figy		5MC175	Washer for spring 25 Ebonite catch plate	117 125			.0
fluent		5MC176 5MC177	Fastening screw for catch plate 125	126			.0
fort		5MC178	Brass nut on dust cover 21a for fastening car-				
			bon holder 11b	211			0
ffulgent		5MC179	Body carbon with cable for base plate	212			.1
ffusion glantine		5MC180	Screw for fastening body washer to base plate	213 214			.0
goism		5MC181 5MC182	Washer for screw 213 Flat spring to keep body carbon 212 in position	215			.0
gotist		5MC183	Fastening screw for flat spring 215	216			.0
gotize		5MC184	Washer for screw 216	217			.0
gress		5MC185	Oil cover for front end plate (to state if arrow				
ider		5MC186	is right or left) Spring plate between cover 22 and clamp 23	* 229 237			.1
Idel	******	JAICIOU		231			.0
ither		5MC187	Timing Lever and Contact Breaker Contact breaker screw	2a			\$0.0
iect		5MC187 5MC189	Complete contact breaker	4b			5.6
lapse		5MC190	Long platinum screw	5			1.6
lastic		5MC191	Contact breaker spring Contact breaker bell crank lever	6.			.0
lbow		5MC193	Contact breaker bell crank lever	7b			.7
		25X41	High tension cable, 42 in. long with elbow terminal and Bosch Rajah hook terminal	18	1		.6

When possible, order through Thomas Dealer



When ordering parts use Code Word GROUP 5—IGNITION SYSTEM

Code	Style of			Foreign	ed age	No.	Sellin
Word	Body	Symbol	Name of Part	Symbol	Illus- trated on Page	on Plate	Pric
				7	0		
			BOSCH—Timing Lever and Contact Breaker				
			Continued				
lect		5MC195	Complete timing lever with fibre rollers	20			\$ 2.5
lection		5MC196	Brass cap for timing lever 20 together with	26			.3
lectric		5MC197	carbon and spring Short platinum screw	29			1.6
lectrify		5MC198	Stop screw for timing lever 20	30			.0
lectuary		5MC199 5MC1100	Washer for spindle cone ¾ in. Nut for spindle cone ¾ in.	71 72			0.
legiacal		5MC1101	Screw for contact breaker spring 6	90			.0
egy		5MC1102	Nut for long platinum screw	92			.(
ement		5MC1103 5MC1104	Carbon brush and holder for the cont. breaker Insulating ring for brass cap 26	107			
levate		5MC1105	Cover for fibre rollers in advance and retard	100			
levation		5MC1106	lever 20 Fixing screw for cover 108	108 110			
levator		5MC1107	Strengthening spring for bell crank lever 7a				
		F3.FG1.100	and 7b	218			.0
leven		5MC1108	Strengthening spring on projecting brass lug of the contact breaker disc 4a and 4b	219			.0
			EISEMANN		- 1		
agle		5MXA217	Magneto (Eisemann-EU) to run clockwise				\$65.5
icit		5MC1109	Condenser	23b 173			5.2
ite ongate		5MC1111 5MC1113	Safety cap cover Spring for oil wick screw No. 859	312			.0
lope		5MC1114	Leather washer for oil wick screw No. 859	313 500b			0.
loquence lude		5MC1115 5MC1116	Set screw for lower gear wheel Screw for pole piece cover	500b			.0
lysian		5MC1117	Short screw for end plates and magnets	512a			.0
manate		5MC1118 5MC1119	Platinum contact screw	516b			3.0
mbalm		SMCIII9	Nut for low tension terminal on make and break cover	519			.0
mbank		5MC1120	Long magnet screws	521 534			.0
mbargo mbark		5MC1121 5MC1122	Screw for armature flange Nut for platinum contact screw	569			.0
mbassy		5MC1123	Screw, in edge of distributor plate, for cover				
		F3401104	catch A	595 598			.0
mbay mbers		5MC1124 5MC1125	Nut for driving shaft coupling Oil wick screw for end plate, driving end	859			.1
mblem		5MC1126	Oil wick for screw No. 859	860 896			.0
mbolden mborder		5MC1127 5MC1128	Leather washer for screw No. 901 Oil wick screw for upper bearing Oil wick for screw No. 901	901			
mboss		5MC1129	Oil wick for screw No. 901	902			.0
mbower		5MC1130 5MC1131	Spring for screw No. 901	903			.0
mbrace		SMC1131	Combination wrench and gauge for setting contacts	1088			
mbrocate		5MC1132	Carbon brush and spring for high tension	1540			
mbroider		5MC1133	collector Washer for driving shaft coupling	1602			
mbroil		5MC1134	Nut for screw holding top of distributor plate	1813			.(
mbryo		5MC1135	Screw for holding end plates	1815 1816			
merald merge		5MC1136 5MC1137	Screw for holding large gear Screw for high tension collector cap No. 2689	1827			.(
metic		5MC1138 5MC1139	Stop screw for bascual	1828			.(
migrate minent		5MC1139 5MC1140	Screw holding contact lever spring, lever end Platinum contact screw, for contact lever	1831 1832b			3.0
missary		5MC1141	Screw for contact breaker spring, plate end	1833			.(
mmet		5MC1142 5MC1143	Screw holding platinum contact support	1834 1836			
motion mpale		5MC1143 5MC1144	Steel pin to stop contact breaker lever Catch with spring and button for make and				
1			break cover	1842 1847			
mpire mploy		5MC1145 5MC1146	Set screw for large gear wheel bearing Brass washer for screw holding distributor	1849			.(
mporium		5MC1147	plate Screw holding pole piece cover	1876b			.(
mpower		5MC1148	Screw holding pole piece cover Connecting screw for condenser	1878		deren	.(
mulate		5MC1149 5MC1150	Oil hole cover screw, driving end Long screw holding make and break mechan'm	1879 1880			.(
nable		5MC1151	Screw holding distributor plate	1881			.(
namel		5MC1152 5MC1153	Nut for fastening condenser cover	1889 1890			
ncamp nchain			Oil hole cover screw, back of gear casing Screw for end plate, cam end	1915	A		.(
nchase		5MC1155 5MC1156 5MC1157	Carbon collector brush, low tension	2139			
ncore		5MC1156	Steel ball for holding distributor arm	2151			. (
ncroach ncumber		5MC1157 5MC1158	Spring for ball catch of distributor cover Binding post on make and break cover	2157 2224			
ncysted		5MC1159	Binding post on make and break cover Spring for oil hole cover back of gear case	2359			.(
ndear		5MC1160 5MC1161	Fibre washer for high tension collector cap Cap for high tension collector	2688 2689			
ndemic							

When possible, order through Thomas Dealer


Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Selling Price
			EISEMANN—Continued				
Endow		5MC1163	Pin for cover No. 2691	2692			\$0.05
Endure		5MC1164	Insulating bushing for screw No. 1834	2705			.10
Endwise		5MC1164 5MC1165	Steel brush and spring for distributor arm	2729			.15
Enema		5MC1166	Carbon brush, holder and spring for high ten-				
			sion conductor	2732			.20
Energy		5MC1167	Washer for screw No. 1831	2739			.05
Enervate		5MC1168	Washer for nut holding condenser housing	2772			.05
Enfeeble Enforce		5MC1169 5MC1170	Steel washer for collector ring	2774 2776			.05
		5MC1170	Oil hole cover for end plate, cam end	2110			.03
Engage	76	SMCIIII	Pole piece cover with safety gap, without por- celain cover	2982			.60
Engender		5MC1172	Magnets	2985b			3.50
Engineer		5MC1173 5MC1174	Armature flange and shaft, cam end	2986b			3.50
Engird		5MC1174	Armature flange and shaft, driving end	2995b			2.80
English		5MC1175	Ball bearing	2997b			3.20
Engrave		5MC1176	Small gear with set screw Condenser housing	3000			1.25
Engross		5MC1177	Condenser housing	3001			.80
Enigma		5MC1178	Hard rubber insulating plate for armature	3004			.80
Enjoy		5MC1179	flange, cam end Insulating bushing for condenser connecting				
		F3501100	screw	3005			.10
Enkindle		5MC1180	Washer for shaft driving end	3009			.05
Enlarge Enlist		5MC1181 5MC1182	End plate, cam end, without No. 3011	3010 3011			4.00 1.60
nnity		5MC1182 5MC1183	Triangular plate, cam end, without ball bearing End plate, driving end without bearing	3012			4.15
nnui		5MC1184	Oil hole cover, driving end	3013			.05
nrage		5MC1185	Steel segment for bascual	3015			.30
nrich		5MC1186	Spring and holder for low tension carbon col-				
		FREGUIOR	lector brush	3019			.15
Inrobe		5MC1187	Disc of make and break mechanism without lever and platinum contacts, clockwise	3020			1.90
nsconce		5MC1189	Insulating bushing for platinum contact sup-	3023			.40
Insemble		5MC1190	Spring holding contact breaker lever, with	3026			.10
nshrine		5MC1191	fibre washer and rivet Contact breaker lever spring	3029			.05
Ensign		5MC1192	Ground contact brush with holder and spring	3032			.35
Enslave		5MC1103	Distributor plate cover	3034b			2.50
ensue		5MC1194 5MC1195 5MC1196 5MC1197	Distributor plate cover Distributor arm complete	3036b			4.00
ntail		5MC1195	Bearing of large gear, complete	3037			2.30
Enter		5MC1196	Oil hole cover for behind gear case	3038			.10
nteric		5MC1197 5MC1198	Shaft of large gear	3039			2.00
ntertain		5MC1198	Large gear	3040c 3041			3.00
nthrone		5MC1200	High tension conductor with brush Armature core and winding	3048b			10.00
ntire		5MC1200 5MC1201	Bascual with steel segments	3054			3.00
ntitle		5MC1202	Contact breaker lever with fibre block, with-	0001			0.00
			out platinum point	3055			.80
ntomb		5MC1203	Make and break mechanism comp., clockwise	3056			9.00
ntrap		5MC1204	Make and break cover with carbon brush	3059a			2.00
ntree		5MC1205	High tension collector brush holder	3060b			1.80
ntwine		5MC1206	Wire ring to lock set screw of small gear	3061			.05
nvelop		5MC1207 5MC1208	Washer for high tension collector ring High tension collector ring	3063 3064b			2.50
II TION		011201200		30010			2.30
		22	MAGNETO CLAMPS				
nvoy		1MA217	Magneto (Bosch) Clamp Assembly				\$1.50
ocene		1MA1273	Inside Strap complete				.90
		1M1108 1M1107	" only hinge				.25
		1M1111	" " hinge eye				.10
		1M1112	eve holt				.25
		21X31	" washer				
		11X43	" eye bolt pin				
		10X61	thumb nut				
olian		1MA1274	Outside Strap complete				.65
		1M1109 1M1107	" only " hinge				.25
		11X43	" " hinge pin				.13
		1M1110	" jaw				.10
olic		K2380	Magneto (Eisemann) Clamp Assembly				1.50
olipile		K11475	" clamp inside strap complete				.90
ozoic		K11476	" clamp outside strap complete				.65
			MAGNETO WIRE HOUSING				
paulet		5MCA42	Magneto Wire Housing Assembly (with wires		200	1007	016
		5MC21	and switches) Housing (less fittings)		28		\$16.50
		5MC21 5MC13	" spacer (front center)		2000		

When ordering parts use Code Word

Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Sellir Pric
			MAGNETO WIRE HOUSING—Continued				
		5MC14	Housing spacer (rear center)				
		5MC128	" spacer				
		5M112	" spacer (end)				
		5M114	" insulator				
		15X41 10X32	spacer screw				
		15X39	" spacer screw nut " insulator screw				
pitaph		5MC119	Spark plug switch bracket				\$0.1
		15X436	Bracket screw				
		10X312	Wasting to be a solut		28	110E	
phod		5MC12 5MC11	Vertical tube socket Vertical tube (with insulator)		28	112E	.5
prior		5MX128	Tube insulator		28	114E	
picure		5MC132	Wire housing bracket				.0
		15X436	Bracket screw				
pidemic		10X312 5MC134	" screw nut				.0
pidemic		10X415	Housing stud (in cylinder cover)				
			MAGNETO WIRES				
pidermis		5MCA211	Magneto wires (set) with ter. less ground wire				\$4.2
		25X41	Magneto wire (Bosch cable) with terminals	-6			
		24724	15½ feet				1.8
		24X24 24X21	Magneto wire terminals No. 10A Rajah (elbow with stud)				
		LINEI	SPARK PLUG SWITCH				-
pigram		5MCA135	Spark Plug Switch Assembly				\$0.6
pigraph		5MC121	Switch handle				.0
pilepsy		5MC133	" blade				.0
pilogue		5MC125 5MC126	cievis				.2
pisode		15X437	" clevis pin " clevis long screw				.0
pistle		5MC118	" thumb nut				.0
piotec		10X312	" plain put No. 5-40				
pitaph		5MC119	" bracket on housing				.1
		15X436 10X312	" screw nut				
		10A312	SPARK PLUG				
bjure		5MC130	Spark Plug with switch nut		28	26A	\$1.0
pitome		5MC131	" switch nut				.1
			TIMER				
poch		5MCA25	Timer Assembly, with drive (runs anti-clock-wise)				\$17.8
pode		5MC26	Timer Only		28	116E	13.5
			See page 16 for drive parts				
			Note—All parts not herein listed must be				
qual		5MCA28	See page 16 for drive parts Nore—All parts not herein listed must be procured by sending timer to makers. Shifting Chamber, with binding posts, roller carrier, spring and bearing cup Breaker Arm, with roller and platinum				
		FMCALOO	carrier, spring and bearing cup		32	120E	
quator quine		5MCA1209	Breaker Arm, with roller and platinum	612-F			2.7
quine		5MC1210 5MC1212	Platinum contact screw	634-F 616-F			2.2
quity		5MC1213	Screw lock nut	471-F			.0
rase		5MC1214	Shifting chamber cover	203-F	32	122E	1.0
rebus		5MC1215 5MC1216	Cover ball bearing	27-F			.2
relong		5MC1216 5MCA1217	Conai	206-F	32	125E	.0
rrand		5MCA1218	Distributor shaft with bearing Shaft lock nut with 6–32 x ½ set screw	207-F	32	125E	.1
ratic		5MC1219	Distributor shaft bearing	ZUI-E			
rror		5MC1220	Felt washer		2		
		5MC1221	Bearing cup			1007	
rudite		5MC1222 5MCA1223	Shaft set screw	45-F 536-F		128E 130E	.1
rudite ruption		5MC1224	Primary wire terminal with fibre sleeve Fibre block fastening screw 6-32 x $\frac{7}{16}$	536-F 635-F	32	130E	.0
rudite ruption scape			Primary wire terminal without fibre sleeve	526-F	32	132E	.0
rudite ruption scape schew		5MC1225	Terminal thumb nut	49-F			.1
rudite ruption scape schew scort sculent		5MC1225 5MC1226					.0
rudite ruption scape schew scort sculent spalier		5MC1226 5MC1227	spring	101/2		4.0.075	
rudite ruption scape schew scort sculent spalier special		5MC1226 5MC1227 5MC1228	Spring Distributing head less carbon brushes	16½ 209-F		133E	2.0
rudite ruption scape schew scort sculent spalier special spionage		5MC1226 5MC1227 5MC1228 5MC1229	spring Distributing head less carbon brushes Square carbon brush	641-F		133E 134E	.2
rudite ruption scape schew scort sculent spalier special spionage splanade		5MC1226 5MC1227 5MC1228 5MC1229 5MC1230	spring Distributing head less carbon brushes Square carbon brush Brush spring	641-F 642-F	32	134E	.2
rudite ruption scape schew scort sculent spalier special spionage splanade spousal squire		5MC1226 5MC1227 5MC1228 5MC1229 5MC1230 5MC1231 5MC1231	spring Distributing head less carbon brushes Square carbon brush Brush spring Round carbon brush Brush spring	641-F 642-F 606-F 235-F	32	134E 136E	2.0 .2 .0 .2
rudite ruption scape schew scort sculent spalier special spionage splanade spousal squire ssay		5MC1226 5MC1227 5MC1228 5MC1229 5MC1230 5MC1231 5MC1232 5MC1233	spring Distributing head less carbon brushes Square carbon brush Brush spring Round carbon brush Brush spring Distributor case	641-F 642-F 606-F 235-F 210-F	32 32	134E 136E 138E	.2 .0 .2 .0 2.7
rudite ruption scape schew scort sculent spalier special spionage spionage spianade spionage spianade		5MC1226 5MC1227 5MC1228 5MC1229 5MC1230 5MC1231 5MC1231	spring Distributing head less carbon brushes Square carbon brush Brush spring Round carbon brush	641-F 642-F 606-F 235-F	32 32	134E 136E	.2 .0 .2 .0

When possible, order through Thomas Dealer

Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Selling Price
			TIMER—Continued				
Estival		5MC137	Terminals (brass screw)	400-F			\$0.15
Estop		5MC139	Ferrule (rubber, with one line)	.,, .			.15
Estuary		5MC140	" (rubber, with two lines)				.15
Eternal		5MC141	" (rubber, with three lines)				.15
Ether		5MC142	" (rubber, with four lines)				.15
Eulogise		5MC143	" (rubber, with five lines)				.15
Euphony		5MC144	" (rubber, with six lines)				.15
Evade		5MC138	" (rubber, with no line)				.15
		. 1	TIMER WIRE HOUSING				
Extend		5MCA43	Timer Wire Housing, with wire less wire		28	142E	\$9.00
Extent		5MCA22	" less wire				5.30
		5MC23	Housing (less fittings)				.60
		5M118	" end				.10
External		5M115	wire busning				.10
Extol		16M137	wire busning retainer				.05
		5MC15	spacer (end)				.10
Extort		5M14 5M15	" spacer ¼ in. dia. x 1 in. " bracket		28	145E	.10
Extort		21/112	bracket		20	145E	.15
			COIL AND BATTERY				
Extra		5MC27	J & B Coil (single vibrating)		28	150E	\$7.50
Extreme		16MC37	Storage battery 6V-40A		28	151E	10.00
Extrude	S	16MC413	" box with hangers				1.75
		25X41	Timer wire (Bosch cable 141/4 ft.				1.70
		24X24	" terminals No. 10A Rajah				.05
			TIMER WIRES				
Exude		5MCA29	Timer wire (set) with all terminals				\$4.25



When ordering parts use Code Word GROUP 5—IGNITION SYSTEM

OILING SYSTEM

Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Selling Price
			OIL TANKS				
			Note—See Motor page 16 for Oil Pump		la l		
Fable	TP	6MCA24	Oil Tank Assembly		63	1F	\$24.5
Fabric Bastion		6MC26 6MC136	Filler "gasket				1.3
Facade		6MC137	" cap		63	3F	.9
Facet		6MC11	Rear flange		20	4F	.2
Facial		6MC135	" outlet pipe		20	5F	.1
		23X97	en				
Faction		5X15 6MC117	ell connection		20	6F	.5
raction		12X15	Drain flange		20	01	
Factor		6MC144	Air connecting flange				.2
		23X98	CII				
		5X14	Ell connection				
Faculty	S	6MCA27	Oil Tank Assembly		20	10F	26.5
			Note—All fittings same as used on touring car.				
			OIL TUBES				
Failure		6MC156	Tube from oil tank to oil valve		20	12F	\$0.6
Faint		6MC157	" " valve to crank case		20	13F	.1
		4X13	Oil valve		20	14F	
Falcon	R	5X15 6MCA28	" connection		20	18F	24.0
Fallow		6MC210	Oil Tank with Filler Flange only Filler flange			101	2.0
			OIL TANK FILLER				
False		6MCA41	Oil Tank Filler Assembly				\$6.2
Falsify		6MCA211	Filler tube with flange				2.1
		6MC212	" "				
Bayou Baysalt		2MC1130 2MC1131	" " flange				1.2
Falter		6MC29	" " flange gasket				2.4
Family		6MC137	" cap				.9
Bastion		6MC136	" cap gasket				.0
		3X31	Clamp bolt				
		10X11	" " nut				
			HANGERS			- 11	
Farce		15MC389	Oil Tank and Muffler Hanger (Front)		63	20F	\$2.5
		14X38	Hanger clamp bolt				
		10X43	Bolt nut				
2		14X339	Hanger attaching screw				
arrago Farrow		15MC331 15MC27	Oil Tank and Muffler Hanger (Rear-Upper)				1.6
airow		14X321	" " (Rear-Lower)				1.0
		10X415	Hanger bolt 56-18 x 1 34 nut				
		14X328	" " J-18 x 7/s				
		10X41	" " nut				
		14X341	" " 1/-24 x 7/s				
		10X47	" " nut				
		14X337	" screw 1/8-24 x 1 in.				
			OIL SIGHT FEED				
			See page 66 for parts.				

CLUTCH


Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Selling Price
Gable Gainful Gaiters Galaxy		7MCA44 7MCA45 7M42 7M118 7MC136	CLUTCH Clutch Assembly including coupling to transmission Center Disc with hub, corks and sleeve Disc with corks cork hub		34 34 34	1G 2G 3G	\$125.00 25.70 Set .21 6.73

When possible, order through Thomas Dealer

GROUP 6—OILING SYSTEM GROUP 7—CLUTCH

CLUTCH

Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Selling Price
			CLUTCH—Continued				
Gallant		7M124	Disc bearing sleeve		34	4G	\$ 1.10
Galley		7M115	" spacer		34	5G	.20
		2X23	" No. 206		34	6G	3.65
Gallon		7M117	" retainer		10	7G	.30
Gallop		7MXA414	Finger Disc with fingers			22.22	7.00
Gamble		7MX49	" disc		34	11G	4.10
Gammon		7MX130 11X11	Finger		34	12G	.60
Gander		7MX131	" pin			14G	
Gangway		7MX146	" disc pin (in fly wheel) disc releasing spring		8	15G	.15
Ganoid		7MCA46	Clutch Cover Assembly (less spring adjust-		8	150	.05
Ganoid		MCATO	ing nut and lock)				13.25
Garbage		7MX48	Clutch cover only		34	20G	10.00



When ordering parts use Code Word

GROUP 7—CLUTCH

CLUTCH

Garden Garlic Acolyte Aconite Garret Garrote Gastric Gather Gaudy		7MX29 7MX210 14X33	CLUTCH—Continued Clutch cover plate	34		
Garlic Acolyte Aconite Garret Garrote Gastric Gather Gaudy		7MX210	Clutch cover plate	 2.1	100000	1200
Garlic Acolyte Aconite Garret Garrote Gastric Gather Gaudy		7MX210	Citation Co. Ci. Piarco		21G	\$0.60
Aconite Garret Garrote Gastric Gather Gaudy		14X33	" " plate gasket	 		.15
Aconite Garret Garrote Gastric Gather Gaudy		1 12100	" " plate screw	 		
Garret Garrote Gastric Gather Gaudy		7M121	Cover plug with gasket	 34	88A	.1:
Garrote Gastric Gather Gaudy		7M140 7MX132	" " gasket	 34	26G	.0:
Gastric Gather Gaudy		7MX141	Finger adjusting screw	 34	27G	.03
Gaudy		7MX133	" " " nut	 34	28G	.10
		7MX134	" " lock	 34	29G	.1
		7MX144	Screw lock screw	 34	30G	.0.
		14X71 20X22	Cover attaching screw	 		
Gaunt		7M44	" gasket Clutch Spring Adjusting Nut Adjusting nut lock	 		.1
Gazelle		7MX213	Clutch Spring Adjusting Nut	 34	31G	1.6
Gemini		7MX145	Adjusting nut lock Screw	 34	32G	.10
		15X413	Class Strew	 		
Gender		7MCA217	Clutch Shifting Sleeve with finger plate and bushing	34	35G	9.50
		7MC26	Clutch shifting sleeve	 	330	9.31
General		7MX136	Sleeve finger bearing plate	 34	36G	.50
		9X27	Sleeve key	 		
enerate		7MC140 7MC173	Coupling bearing (or bushing)	 34	37G	2.6
Senerous Senial		7MC173 7MX135	Clutch Spring	 34 34	38G 39G	.4:
enius		7MCA219	Shifting sleeve plate (rear) Clutch Spring Clutch Trunnion with dust washer, plate and	 0.4	390	
			spring	 		6.80
		7MC211	Clutch trunnion	 34	43G	6.25
entile		7MC157 7MC158	Trunnion dust washer	 		.10
entry		7MC158 7MC159	" " plate " spring	 		.05
Cirume		2X64	Trunnion Bearing and Cup	 		9.80
		2X64a	" cone only	 34	46G	
		2X64b	" cup only	 34	47G	
eode		7MC156 20X37	" retainer retainer lock wire	 34	48G	1.05
			CLUTCH BRAKE			
Goedesy		7MCA218	Brake Front Disc with dust washer, spring, key			
			and lock	 34	50G	\$3.50
eology		7MC212	Brake front disc	 		2.40
eometry		7MC165	dust washer	 34	51G	.30
erman		7MC166 7MC163	44 44 44 1rove	 		.25
esture		7MC164	" key lock (screw)	 		.10
ewgaw		7MCA37	Brake Rear Disc with Lining	 34	55G	3.70
		7MC161	Lower disc with lining	 		
		7MC160	Upper disc with lining	 	7.00	
eyser		7MC162 7MC151	Brake disc lining	 34	56G	.70
HOST	*****	3X311	" " stop pin " clamp bolt	 		.03
		10X13	Clamp bolt nut	 		
houl		7MCA220	Clamp bolt nut Clutch Shaft with spring 7MO11			6.20
ihharr-		7MC25	Clutch Shaft	 34	60G	6.00
ibbous		1M1132 7MC137	Thrust plug (in crank shaft) " spring (front)	 		.05
riggle		7MC137 7MC138	" plunger (rear)	 34	63G	.05
inger		7MO11	" spring (rear)	 34	64G	.05
ipsy		7MC139	" cap	 34	65G	.25
			CLUTCH COUPLING			
irdle		7MC27	Clutch front coupling	34	70G	\$10.00
irth		7MC143	" screw	 34	71G	.05
izzard		7MC141	" rear coupling	 34	72G	4.25
lance		7MC152 7MC142	screw	 34	74G	.10
lare		7MC142 7MC123	Coupling ring (or center)		740	3.60
lass		7MCA38	Spring Clutch Coupling Cover with Clamps	 		5.25
laze		7MC35	Upper cover with plug	 34	80G	1.65
leam		7MC36	Lower cover	 34	81G	1.50
colyte		7M121 7M140	Upper cover plug with gasket	 34	88A	.15
		7M140 7MC168	Cover side gasket "rear gasket	 		.05
conite		7MC169	rear gasket	 		.05
conite	*****		Burney.			
conite leeful lide limpse		7MC172		 		.05
conite leeful lide		7MC172 7MCA215	Coupling Cover Front Clamp Assembly	 34	85G	.05
conite leeful lide limpse lobe		7MC172 7MCA215 7MC213	Coupling Cover Front Clamp Assembly	 		.85
conite leeful lide limpse		7MC172 7MCA215	Coupling Cover Front Clamp Assembly			.85

When possible, order through Thomas Dealer

GROUP 7—CLUTCH

CLUTCH


Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Selling Price
			CLUTCH COUPLING—Continued				
		21X31 10X61	Clamp washer "thumb nut				
lory		7MCA216	Coupling Cover Rear Clamp Assembly		34	87G	\$0.8
	ž	7MC214 1M1112	Clamp only " eve bolt				.4
1		11X43 7MC167	" eye bolt pin				.1
lorify		21X31 10X61	" yaw " washer " thumb nut				.1

TRANSMISSION

Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Selling Price
			TRANSMISSION				
Habeas		8MCA41	Transmission Assembly				\$185.00
			CASE				
Habit		8MX44	Case		37	2H	\$20.00
Habitat		8MXA35	" cover with cap				4.90
Hackle		8MX34	" " " "		37	4H	3.5
Hackney		8MX145	cap		37	5H	.7.
Haddock		8MX144	gasket				.10
Toward		14X23 8M122	" and cover oil plug		37	7H	.2
Haggard Haircloth		8M113	Control shaft bushing		31	711	.5
lancion		14X36	Cover attaching screw				.0.
		111100					
			MAIN SHAFT				
Hairy		8MCA31	Main Shaft with gears, bearings and retainer				\$38.0
Halberd		8M211	Main shaft only		37	10H	7.5
Halibut		8MC22	Second speed sliding gear 30-T		37	11H	7.7
Halloo		8MC21	Low speed sliding gear 37-T	307	37	12H	8.2 5.5
		2X31 2X32	Main shaft front bearing rear bearing	307	37	13H 14H	6.9
Halter		8M19	" bearing retainer	308	37	15H	.3
Tarter		20X34	" bearing retainer lock		31	1311	
	-						
			MAIN SHAFT MISCELLANY				
Halve		8M27	Rear bearing bushing		37	16H	\$1.2
Halyard		8MO29	" cap " packing nut		37	17H	1.2
Hames		8M127	" " packing nut		37	18H	1.1
		24X43	" " packing nut " " packing " " screw				
		14X71 11X61	Screw Dealing nut look nin				
		18X11	Packing nut lock pin spring				
Hamlet		9MC27	Universal joint flange		37	12J	2.7
Hammer		8M15	Flange washer		37	20H	.10
		10X14	" nut				
			CONSTANT MESH PINION				
Hammock		8MX214	Constant Mesh Pinion, with cork		37	25H	\$9.25
		2X26	Pinion large bearing	212	37	26H	8.45
		8M130	" cork				
Hamose		8MCA32	Constant Mesh Pinion Bearing Cap, with bearings and retainers				24.00
Hamper		8MC25	Pinion bearing cap only		37	29H	3.85
Hanaper		8MX155	" thrust hearing	H.B.1110-F	37	30H	9.50
Handcuff		8MX149	" thrust bearing retainer		37	31H	.70
		2X24	" front bearing	209	37	32H	5.25
Iandle		8MX140	" front bearing retainer		37	33H	.70
Iandmaid		8MX151	" front bearing retaining plate		37	34H	.40
Iandsome		8MX150	Plate retainer		37	35H	1.9
Iandspike		8MX147	Packing nut		37	36H	.7
Jandy.		24X48	Packing Plate retainer leafs				.05
Handy		8MX148 14X14	Plate retainer lock "" screw				.05
		14X14 14X74	Pinion bearing cap attaching screw				
		ITA/T	I infort bearing cap attaching screw				

When ordering parts use Code Word

GROUP 7—CLUTCH GROUP 8—TRANSMISSION



When possible, order through Thomas Dealer GROUP 8—TRANSMISSION

TRANSMISSION


Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Sellir Pric
			AUXILIARY SHAFT				
Hanekam		8MA37	Auxiliary Shaft with gears, bearings, nuts and				
			washers			-,	\$42.0
Hanger Hanker		8M25 8M21	Auxiliary shaft only		37 37	45H 46H	7.50 6.7
Hanker		8M14	Constant mesh gear 33-T Second speed gear 27-T		37	47H	5.5
Нарру		8M12	First speed gear 20-T		37	48H	4.0
Harass		8M13	Reverse gear 17-T		37	49H	3.5
Harbor		8M142	Spacing washer (special)			2277	.0.
Harden		2X41 8M15	Bearings Bearing washer	406	37 37	51H 52H	6.9
laiden		10X14	Shaft nut			3211	.1
Hardship		8M18	Auxiliary Shaft Front Bearing Can		37	55H	1.3
Hardy		8M210	" rear bearing cap		37	56H	1.0
Harelip		8MC23 14X71	rear bearing bushing or case		37	57H	1.4
		144/1	Bearing cap attaching screw				
			REVERSE IDLER GEAR				
Jarom		8MCA111			37	59 TT	QE 1
Harem		8M11	Reverse Idler Gear 18-T with bushing		31	58 H	\$5.1
Harmonize		8M112	Reverse Idler gear 18-T " bushing				1.0
Harmony		8MC13	" " shaft		37	60H	.7
			ORAD CHIETING MEGHANICA				
			GEAR SHIFTING MECHANISM				
Harness		8MC15	Shifter shaft (low and reverse)		37	65H	\$3.3
Iarong		8MC11 8MC14	" fork (low and reverse)		37	66H	3.0
Iarpoon Iarrow		8MC12	" shaft (high and intermediate) " fork (high and intermediate)		37 37	67H 68H	3.3
Iarsgom		8MCA26	Shift Shaft Front Bracket Assembly			0011	6.0
Iarsh		8M31	" " front bracket " " inter lock plunger		37	71H	3.5
Iartshorn		8M121	" " inter lock plunger				.0
Iarvest Iassock		8M126 8M125	Bracket plug (lower) " (end)		37	74H	.1
Hasty		8MC16	" lock plunger		37	75H	.2
Haten		8MC17	" spring		37	76H	.0.
		14X36	" attaching screw				
Iatless		8MA39 8M0212	Shift Shaft Rear Bracket Assembly		37	77.77	2.1
Hatred Hassock		8M125	Bracket plug		37	81H 74H	1.7
Lassock		14X36	" attaching screw			1411	.2
			TRANSMISSION ATTACHING PARTS				
Iaughty		8M110	Support bracket		37	85H	\$0.30
Iaunch		8M124 10X75	" holt (front)		37	86H	.2
Iaunt		8M132	" " nut " washer, ½ thick (spec.)				.0.
lautboy		8M133	" washer, 32 thick (spec.)				.0
		3X315	" attaching bolt				
		10X15	" " nut				
laven		8M123 10X14	Transmission bolt (rear)		37	87H	.2
Iavoc		8M138	" washer, ½ thick (spec.)				.0
lawser		8M139	" washer, 18 thick (spec.)				.0.
		- 7	GEARS (Set)				
lazard		8MCA42	Transmission Gears (Set)				\$50.1
lalibut		8MC22	Second speed sliding gear, 30-T		37	11H	7.7
lalloo lammock		8MC21 8MX214	Low speed sliding gear, 37-T		37 37	12H 25H	8.2 9.2
lanker		8M21	Constant mesh pinion with cork Auxiliary shaft constant mesh gear, 33-T		37	46H	6.7
lapless		8M14	Second speed gear, 27-T		37	47H	5.5
Гарру		8M12	Second speed gear, 27-T First speed gear, 20-T Reverse gear, 17-T		37	48H	4.0
Iarass Iaricot		8M13 8M11	Reverse gear, 17-T "idler gear with bushing, 18-T		37 37	49H 58H	3.50 5.10
aricut		OMII	idiei gear with busning, 18-1		31	3011	5.10
			BEARINGS (Set)				
Iazel		8MCA43	Transmission Bearings (Set)			-	\$49.6
		2X31	Main shaft front bearing	307	37	13H	5.5
		2X32	" rear bearing	308	37	14H	6.9
Iamula		2X26	Constant mesh pinion large bearing	212 H B 1110 F	37	26H	8.45
lamula		8MX155 2X24	Pinion thrust bearing "front bearing	H.B.1110-F 209	37 37	30H 32H	9.5 5.2


When ordering parts use Code Word

GROUP 8-TRANSMISSION

DRIVE

Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Selling Price
Jabber Jackal Jackdaw Jaconet	TP	9MCA31 9MC24 10X417 9MCA33 9MCA34	DRIVE SHAFT Main Drive Shaft Assembly with joints Drive shaft only nut Front Universal Joint Assembly Rear universal joint assembly UNIVERSAL JOINTS	231-SF 431 428	39	2J	\$29.25 5.00 12.75 11.50
Jackdaw Jaggy Jalap Jalap Jangle Japan Jargon Jasper Jaunt Hamlet Jejune Jenny Jerkin Jerkin Jetsam Jewish Jaconet Jingle	SR	9MCA33 9MC23 9MC18 9MC18 9M111 9MC17 9MC13 9MC10 9MC26 9MC27 14X344 10X415 9MC14 9MC15 9MC11 9MC16 14X19 9MC28 9MC28	Front Universal Joint Assembly Joint yoke " dust cap " dust washer " journal " bushing, It diameter " bushing retainer " flange yoke " companion flange " flange bolt nut " flange bolt nut " inner casing " inner casing plug " outer casing plug " outer casing packing " casing packing " casing lock nut screw Rear Universal Joint Assembly Joint yoke All other parts are the same as for Front Joint 9MCA33 (omitting 9MC18 and 9M111) Main Drive Shaft Assembly Drive shaft only All other parts the same as for Assembly 9MCA31.	431 230-SF 430-D 403-W 425-X 425-SB 425-BR 428-V 40-SF 	39 39 39 39 39 39 39 39 39 39	5J 6J 7J 8J 9J 11J 12J 14J 16J 17J 18J	\$12.75 3.65 .75 .15 1.15 .05 2.55 2.75 .75 .05 .75 .65 11.50 2.80 29.25 5.00





When ordering parts use Code Word GROUP 10—CONTROL

Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Sellir Pric
			GEAR CONTROL				
					3		
abacco		10MCA325	Gear Control Lever with handle		40	1L	\$4.2
abacol		10MC317 10M147	" " handle		40	2L	3.2
abander		10M147 10MX1273	" " handle Lever fulcrum button		40	21	.8
abardata		10MCA219	Control Lever Shaft with trunnion attached		40	4L	1.6
		10MX1256	Shaft only				1.2
		10M14	" trunnion				.3
		11X45	trunnion pin				
abardone		10M11	Lever and trunnion pin				.1
abareda		8MX143	Shaft Lever		40	8L	1.1
		10X82 21X32	" nut " washer				
		9X26	" lever key				
Iaircloth		8M113	" bushing		40	8H	.5
abarum		10MX413	Control Lever Bracket		40	10L	3.2
		14X38					
		10X43	" " bolt nut				
				Unage I			
			BRAKE CONTROL (HAND)		- 1		
abatie abbrone		10MCA421	Brake Lever with handle and pawl rod assem.		40		\$6.6
abbrone abdaci		10MC316	only		40	13L	4.7
abel		10M146 10MX1272	" " handle " pawl rod			14L	8
abecula		10M142	Pawl rod clevis				.1
abeling		10M141	Brake lever pawl				.5
abendes		10M143	Pawl rod and clevis screw				.0
abeo		10M140	" screw (through lever)				.1
abeosi		10M145	" rod button		40	16L	.1
abeosos		10M144	rod button spring				.0
aberca		10MC124 10X81	Brake Lever Shaft				.5
		9X26	" " nut				
aberdan		10MC122	" " shaft lever		40	21L	1.2
		9X26	" shaft lever key	0			
		3X38	" shaft lever bolt				
		10X11	Lever bolt nut				
aberius		10MC26	Brake lever shaft bracket		40	25L	1.2
		14X38	Bracket attaching bolt				
		10X43	" " nut				
abetrank abeurer		10MXA350 10MX221	Brake Lever Segment Bracket with Segment		40	31L	3.1
abewein		10MX1271	Segment bracket only		40	32L	1.1
ube well		14X613	" screw				1.1
		14X612	" bracket attaching bolt				
		14X67	" bracket attaching bolt				
		10X43	Bolt nut				
atinet		15MC1223	Brake lever floor plate				.2
			BRAKE AND CLUTCH CONTROL (FOOT)				
abiadas	TPR	10MCA323	Brake Pedal with tube, bushings and pad				\$5.0
abiado	TPR	10MCA36	" with tube and hushings		3		3.2
	TPR	10MCA36 10MC37	" only		40	36L	2.5
		10MX1209	" tube				.3
		10MX1211				201	.0
abial	TPR	10MC173	Pedal Pad		40	39L	1.0
abor	IPK	10M13	" adjusting plate (R) " adjusting plate (L)				.2
abor aborious	TPP						
abor aborious acerate	TPR	10M112 3X343	Plate bolt				
abor aborious	TPR	10M112 3X343 10X424	Plate bolt				.0
abor aborious acerate		3X343 10X424	Plate bolt				
abor aborious acerate ackaday ackey		3X343 10X424 10MX1212 10MX1213	Plate bolt nut Brake Pedal Spring connection				.0
abor aborious acerate ackaday ackey		3X343 10X424 10MX1212 10MX1213 10MCA324	Plate bolt "nut Brake Pedal Spring			*	5.0
abor aborious acerate ackaday ackey		3X343 10X424 10MX1212 10MX1213	Plate bolt unt Brake Pedal Spring connection Brake Pedal with tube, bushings and pad			*	5.0
abor aborious acerate ackaday ackey acmus		3X343 10X424 10MX1212 10MX1213 10MCA324 10MC319	Plate bolt unt Brake Pedal Spring connection Brake Pedal with tube, bushings and pad				5.0 3.2
abor aborious accrate ackaday ackey acmus	S	3X343 10X424 10MX1212 10MX1213 10MCA324 10MC319	Plate bolt nut Brake Pedal Spring connection Brake Pedal with tube, bushings and pad All other parts are same as for touring car. Clutch Pedal with tubes, bridge, collar and pad				5.0 3.2 9.0
abor aborious acerate ackaday ackey acmus		3X343 10X424 10MX1212 10MX1213 10MCA324 10MC319	Plate bolt " " nut Brake Pedal Spring " " " connection Brake Pedal with tube, bushings and pad All other parts are same as for touring car. Clutch Pedal with tubes and bridge Clutch Pedal with tubes and bridge			*	.0 5.0 3.2 9.0 7.2 2.5
abor aborious acerate ackaday ackey acmus	S	3X343 10X424 10MX1212 10MX1213 10MCA324 10MC319	Plate bolt " " nut Brake Pedal Spring " connection Brake Pedal with tube, bushings and pad All other parts are same as for touring car. Clutch Pedal with tubes, bridge, collar and pad Clutch Pedal with tubes and bridge " only		40	45L	9.0 7.2 2.5 .7
abial abor aborious acerate ackaday ackey acmus aconize acquer	S	3X343 10X424 10MX1212 10MX1213 10MCA324 10MC319 10MCA326 10MCA311 10MC38 10MX1225 10MC130	Plate bolt nut Brake Pedal Spring connection Brake Pedal with tube, bushings and pad All other parts are same as for touring car. Clutch Pedal with tubes, bridge, collar and pad Clutch Pedal with tubes and bridge only Right tube Left tube		40 40	45L 46L	0 5.0 3.2 9.0 7.2 2.5 .7
abor aborious acerate ackaday ackey acmus aconize acquer	S	3X343 10X424 10MX1212 10MX1213 10MCA324 10MC319 10MCA311 10MC38 10MX1225 10MC130 10MC34	Plate bolt		40 40	45L 46L	.0 5.0 3.2 9.0 7.2 2.5 .7 .6 2.0
abor aborious acerate ackaday ackey acmus aconize acquer	S	3X343 10X424 10MX1212 10MX1213 10MCA324 10MC319 10MCA311 10MC3311 10MC38 10MX1225 10MC130 10MC34 10MX1230	Plate bolt nut Brake Pedal Spring connection Brake Pedal with tube, bushings and pad All other parts are same as for touring car. Clutch Pedal with tubes, bridge, collar and pad Clutch Pedal with tubes and bridge only Right tube Left tube Tube bridge Tube collar		40 40	45L 46L 51L	.0 5.0 3.2 9.0 7.2 2.5 .7 .6 2.0
abor aborr alborrous accerate	S	3X343 10X424 10MX1212 10MX1213 10MCA324 10MC319 10MCA311 10MC38 10MX1225 10MC130 10MC34 10MX1230 10MC34	Plate bolt "nut" unt Brake Pedal Spring "" connection Brake Pedal with tube, bushings and pad All other parts are same as for touring car. Clutch Pedal with tubes, bridge, collar and pad Clutch Pedal with tubes and bridge "only Right tube Left tube Tube bridge Tube bridge Tube collar Collar set screw		40 40	45L 46L	.0 5.0 3.2 9.0 7.2 2.5 .7 .6 2.0 .3
aborious acerate ackaday ackey acmus aconize acquer	S TPR	3X343 10X424 10MX1212 10MX1213 10MCA324 10MC319 10MCA311 10MC38 10MX1225 10MC130 10MC34 10MX1230 16X13 10MCA327	Plate bolt nut Brake Pedal Spring connection Brake Pedal with tube, bushings and pad All other parts are same as for touring car. Clutch Pedal with tubes, bridge, collar and pad Clutch Pedal with tubes and bridge only Right tube Left tube Tube bridge Tube collar Collar set screw Clutch Pedal with tubes, bridge, collar and pad Clutch Pedal with tubes, bridge, collar and pad		40 40	45L 46L 51L	9.0 7.2 2.5 .7 .6 2.0 .3
aborious acerate ackaday ackey acmus aconize acquer	S	3X343 10X424 10MX1212 10MX1213 10MCA324 10MC319 10MCA311 10MC38 10MX1225 10MC130 10MC34 10MX1230 10MC34	Plate bolt "nut" unt Brake Pedal Spring "" connection Brake Pedal with tube, bushings and pad All other parts are same as for touring car. Clutch Pedal with tubes, bridge, collar and pad Clutch Pedal with tubes and bridge "only Right tube Left tube Tube bridge Tube bridge Tube collar Collar set screw Clutch Pedal with tubes, bridge, collar and pad "tubes and bridge" "tubes and bridge		40 40	45L 46L 51L	9.0 7.2 2.5 .7 .6 2.0 .3
aborious acerate ackaday ackey acmus aconize acquer	S TPR	3X343 10X424 10MX1212 10MX1213 10MCA324 10MC319 10MCA311 10MC38 10MX1225 10MC130 10MC34 10MX1230 16X13 10MCA327	Plate bolt "nut" unt Brake Pedal Spring "" connection Brake Pedal with tube, bushings and pad All other parts are same as for touring car. Clutch Pedal with tubes, bridge, collar and pad Clutch Pedal with tubes and bridge "only Right tube Left tube Tube bridge Tube bridge Tube collar Collar set screw Clutch Pedal with tubes, bridge, collar and pad "tubes and bridge" "tubes and bridge		40 40	45L 46L 51L	.0 5.0 3.2 9.0 7.2 2.5 .7 .6 2.0
abor aborious acerate ackaday ackaday accept	S TPR	3X343 10X424 10MX1212 10MX1213 10MCA324 10MC319 10MCA326 10MCA311 10MX23 10MX1225 10MX123 10MX123 10MX123 10MX123 10MX123 10MX123 10MX34 10MX123 10MX34 10MX123 10MX34	Plate bolt " nut Brake Pedal Spring " " connection Brake Pedal with tube, bushings and pad All other parts are same as for touring car. Clutch Pedal with tubes, bridge, collar and pad Clutch Pedal with tubes and bridge " only Right tube Left tube Tube bridge Tube bridge Tube collar Collar set screw Clutch Pedal with tubes, bridge, collar and pad " " tubes and bridge Nore—All parts are same as for 10MCA311. Difference is in angle of pedal with bridge.		40 40	45L 46L 51L	.0 5.0 3.2 9.0 7.2 2.5 .7 .6 2.0 3
abor aborious acerate ackaday ackey acmus	S TPR	3X343 10X424 10MX1212 10MX1213 10MCA324 10MC319 10MCA311 10MC38 10MX1225 10MC130 10MC34 10MX1230 16X13 10MCA327	Plate bolt "nut" unt Brake Pedal Spring "" connection Brake Pedal with tube, bushings and pad All other parts are same as for touring car. Clutch Pedal with tubes, bridge, collar and pad Clutch Pedal with tubes and bridge "only Right tube Left tube Tube bridge Tube bridge Tube collar Collar set screw Clutch Pedal with tubes, bridge, collar and pad "tubes and bridge" "tubes and bridge		40 40	45L 46L 51L	9.0 7.2 2.5 .7 .6 2.0 .3

When possible, order through Thomas Dealer

GROUP 10—CONTROL

Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Sellin Price
			BRAKE AND CLUTCH CONTROL (FOOT)				
			Continued				
		3X343	Plate bolt				
	S	10X424	" " nut				07.01
Lamberto	S	10MCA322 10MC320	Clutch Pedal with tube and bridge				\$7.25
Lament		10MC1118	" adjusting plate (R)				.20
Lampblack		10MC1119	" adjusting plate (R) " adjusting plate (L) All other parts are same as for touring car.				.20
75		•	BRAKE AND CLUTCH PEDAL TUBE BRACKETS				
Lamina	-	10MX1227	Right bracket				\$0.40
Lammas		10MCA172	Left bracket with cap				.90
		10MC131	Bracket				.50
		10MX1224 14X314	" cap cap screw				.15
		3X31	Bracket attaching bolt				
		10X44	" " nut				
19-5-19			INTERMEDIATE BRAKE SHAFT				
Lampoon	TP	10MC16 10MC1108	Foot Brake Intermediate Tube		40	61L	\$1.75
Lamprey		9X11	Tube inner lever		40	OIL	1.00
Lance		10MC128	" outer lever (right) " outer lever (left)		40	62L	1.25
Landlady		10MC129	" outer lever (left)		40	63L	1.25
		3X38 10X11	Outer lever bolt				
		9X11	" bolt nut " key				
Landlock	SR	10MC1104	Foot Brake Intermediate Tube				1.75
Landlord	TP	10MCA422	All other parts same as for touring car. Hand or Emergency Brake Intermediate Tube with bushings, bridge and levers				
-	TP .	10MC14	with bushings, bridge and levers		40 40	65L 66L	8.75
	TP	10MC14	Tube (left-long) " (right-short)		40	67L	.80
Landmark		10M17	" bushing				.15
		10MC13	" bridge		40	69L	1.40
Landslip		10MC123 3X318	" inner lever " inner lever bolt		40	70L	1.25
		10X15	Bolt nut				
Language		10MC126	Tube outer lever (right) " outer lever (left)		40	71L	1.25
Languid		10MC127	" outer lever (left)		40	72L	1.25
		3X38 10X11	Outer lever bolt				
		9X11	" kev				
Lantern	SR	10MCA418	NOTE—See frame page 62, for brackets. Hand or Emergency Brake Intermediate Tube				8.75
	SR	10MC1106	with bushings, bridge and levers Tube (left-long)				1.50
	SR	10MC1105	" (right-short)				.80
			Note—All other parts same as for touring car.				
- 1			FOOT BRAKE RODS AND ROCKER CONNECTION				
anvarde		10MXA1221	Note—These connect with external brake.		40	75L	£1 25
anyards		10MXA1221 10MX1219	Rod complete (R. H. thread)		40	75L	\$1.35
apse		10MX1218	" complete (L. H. thread)				.40
		10X21	Rod complete (R. H. thread) "complete (L. H. thread) "nut (R. H. thread) "nut (L. H. thread) "thread)				
		10X211 25X91	" nut (L. H. thread) " turnbuckle 36-16 thread				
		11X17	" front pin, ½ x 1 ¼				
		11X14	turnbuckle, 3%-16 thread front pin, ½ x 1½ rear pin, ½ x 1¾				
arceny	TP	10MCA149 10MC150	Foot Brake Intermediate Rod Assembly		40	80L	1.25
ALL CIT		22X12	Rod complete " clevis (tapped)				.03
		11X14	" clevis pin				
arder	SR	10X23	" clevis nut				1.25
arder	SR	10MCA182 10MC183	Foot Brake Intermediate Rod Assembly Rod complete				.60
aige		22X12	" clavis (tanned)			7777	.00
		11X14	" clevis pin				
		10X23	cievis nut				.75
argess		10MA237 10M125	Foot Brake Rod Rocker with bracket Rocker only		40	91L	.75
arrup		10M124	" bracket		40	92L	.30
		11X14	" pin				
		3X315	" bracket bolt				
		10X15	" bracket bolt nut				


When ordering parts use Code Word

GROUP 10—CONTROL

Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Sellin Price
			FOOT BRAKE RODS AND ROCKER				
		103504146	CONNECTION—Continued		40	OFT	01.05
Larum Larva		10MCA146 10MC147	Foot Brake Rear Rod Assembly Rod complete		40	95L	\$1.25
		22X12	" clevis (tapped)				
		11X14 11X81	" clevis pin " clevis pin				
		10X23	" clevis nut		-:		
			HAND OR EMERGENCY BRAKE RODS		13/17		
			Note—These connect with internal brake.				
Larynx	TP	10MCA192	Hand Brake Front Rod Assembly			100L	\$1.25
Lasso		10MC193 22X12	Rod complete " clevis				.65
		11X14	" clevis pin				
		21X37 10X23	" clevis pin washer clevis nut				
Latch	SR	10MCA197	Hand Brake Front Rod Assembly				1.25
Latent		10MC198	Rod complete				.60
		22X12 11X14	" rear clevis " clevis pin				
		10X23	" clevis nut				
Lather Latin		10MCA144 10MC145	Hand Brake Rear Rod Assembly Rod complete			105L	1.25
Laun		22X12	" clavis (tanned)				.00
		11X14	" clevis pin				
		11X81 10X23	" clevis pin " clevis nut				
		101120	Cievis nuc			****	
			STEERING CONTROL		1200		
			Note—See page 46 for post for surrey and		1897.19		
	mm		runahout				
Latitude Latria	TP TP	10MA47 10MCA420	Steering Post Assembly with Long Tubes Steering Post Assembly with Short Tubes Total case with Long tube and collar assembld				\$98.50 98.50
Latricis		10MXA338	Total case with Long tube and collar assemb'd				10.50
Latridie		10MCA318 10M31	with Short tube and collar assemb d		44	112L	10.50
		10M1155	Upper case only tube 421/8 (long tube)		44	113L	
		10MC1113	" " tube 42½ (long tube) " " 41½ (short tube) " " collar			113L	
		10M189 16X29	Set screw for sector		44	114L	
		10X22	" nut				
Latrobite Latter		10MA357 10M32	Lower Case with Cap		44	116L	5.30
Lattice		10M32	" " only " cap		44	117L	.60
			" "				
		14X73	" cap screw				
		3X39	" cap screw " bolt				
		3X39 10X11 14X38	cap screw bolt bolt nut center screw				
Latuis	P	3X39 10X11 14X38 10MC228	cap screw bolt bolt		44	120L	6.75
Latuis Laudanum		3X39 10X11 14X38 10MC228 10MC229 10MC28	cap screw bolt bolt center screw Sector Gear (triple thread)		44 44 44	120L 120L 120L 120L	6.75 6.75 6.75
Latuis Laudanum Laugh Launch	P S	3X39 10X11 14X38 10MC228 10MC229 10MC28 10M117	cap screw bolt bolt nut center screw Sector Gear (triple thread) Sector Gear (quadruple thread) Crank		44 44 44 44	120L 120L 120L 120L 122L	6.75 6.75 6.75 1.50
Latuis Laudanum Laugh Launch Laundry	P S	3X39 10X11 14X38 10MC228 10MC229 10MC28 10M117 10M1124 10X76	cap screw bolt nut center screw Sector Gear (triple thread) Crank ball with nut "" unt		44 44 44 44	120L 120L 120L 120L	6.75 6.75 6.75 1.50
Latuis Laudanum Laugh Launch Laundry	PS	3X39 10X11 14X38 10MC228 10MC229 10MC28 10M117 10M1124 10X76 10X74	cap screw bolt bolt center screw Sector Gear (triple thread) Sector Gear (quadruple thread) Crank ball with nut nut Sector shaft nut		44 44 44 44 44 44	120L 120L 120L 120L 122L 123L	6.75 6.75 6.75 1.50
Latuis Laudanum Laugh Launch Laundry	PS	3X39 10X11 14X38 10MC228 10MC229 10MC28 10M117 10M1124 10X76 10X74 2X61	cap screw bolt bolt center screw Sector Gear (quadruple thread) Crank ball with nut mut Sector shaft nut Sec		44 44 44 44 44	120L 120L 120L 120L 122L 123L	6.75 6.75 6.75 1.50 .75
Latuis Laudanum Laugh Launch Laundry	PS	3X39 10X11 14X38 10MC228 10MC229 10MC128 10M117 10M1124 10X76 10X74 2X61 2X61 2X61A 2X61B	cap screw bolt nut center screw Sector Gear (triple thread) Sector Gear (quadruple thread) Crank Crank ball with nut " nut Sector shaft nut Sector Gear Bearing (cone and cup) " " cup.		44 44 44 44 44 44 44 44	120L 120L 120L 120L 122L 123L	6.75 6.75 6.75 1.50 .75
Latuis Laudanum Laugh Launch Laundry	PS	3X39 10X11 14X38 10MC228 10MC229 10MC28 10M117 10X1124 10X76 10X74 2X61 2X61B 10M176	cap screw bolt nut center screw Sector Gear (triple thread) Sector Gear (quadruple thread) Crank Crank ball with nut " nut Sector shaft nut Sector Gear Bearing (cone and cup) " " cup.	2356 2320	44 44 44 44 44 44 44 44 44	120L 120L 120L 120L 122L 123L 123L	6.75 6.75 6.75 1.50 .75
Latuis Laudanum Laugh Launch Laundry Laurel Lavish Layer	PS	3X39 10X11 14X38 10MC228 10MC229 10MC28 10M117 10X76 10X76 10X74 2X61 2X61B 10M176 10M180	cap screw bolt bolt center screw Sector Gear (triple thread) Sector Gear (quadruple thread) Crank ball with nut sector shaft nut Sector Gear Bearing (cone and cup) cup, Sector Gear Eccentric (left) Cright) Eccentric plug (right) with dust washer	2356 2320	44 44 44 44 44 44 44 44 44 44 44	120L 120L 120L 120L 122L 123L 126L 127L 130L 131L 131L	6.75 6.75 6.75 1.50 .75
Latuis Laudanum Laugh Launch Laundry Laundry Laurel Laver Layer Lazar	PS	3X39 10X11 14X38 10MC228 10MC229 10MC28 10M117 10M1124 10X76 10X74 2X61 2X61A 2X61B 10M176 10M180 10M178 10M179	cap screw bolt nut center screw Sector Gear (triple thread) Sector Gear (quadruple thread) Crank Crank ball with nut nut Sector shaft nut Sector Gear Bearing (cone and cup) cone, cup, Sector Gear Eccentric (left) (right) Eccentric plug (right) with dust washer	2356 2320	44 44 44 44 44 44 44 44 44 44	120L 120L 120L 120L 122L 123L 126L 127L 130L 131L 131L 132L	6.75 6.75 6.75 1.50 .75
Laudanum Laugh Launch Laundry Laurel Lavish Layer Lazar Leach	PS	3X39 10X11 14X38 10MC228 10MC229 10MC229 10M17 10M117 10M117 10X76 10X74 2X611 2X61A 2X61B 10M176 10M178 10M178 10M178	cap screw bolt nut center screw Sector Gear (triple thread) Sector Gear (triple thread) Crank Crank Crank ball with nut nut Sector shaft nut Sector Gear Bearing (cone and cup) cone, cup, Sector Gear Eccentric (left) fright Eccentric plug (right) with dust washer flight lock lock	2356 2320	44 44 44 44 44 44 44 44 44 44 44	120L 120L 120L 122L 123L 123L 126L 127L 130L 131L 132L 132L 132L	6.75 6.75 6.75 1.50 .75 1.75 1.75 6.60 .60
Latuis Laudanum Laugh Launch Laundry Laundry Laurel Lavish Layer Lazar Leach Leach	PS	3X39 10X11 14X38 10MC228 10MC229 10MC28 10M1124 10X76 10X76 10X76 10X76 10X76 10X76 10X76 10X78 10M177 10M1180 10M178 10M179 10M181 10M177 10M181	cap screw bolt bolt center screw Sector Gear (triple thread) Sector Gear (quadruple thread) Crank ball with nut mut Sector shaft nut Sector Gear Bearing (cone and cup) cone, cup, sector Gear Eccentric (left) (fight) Eccentric plug (right) with dust washer mut lock plug dust washer	2356 2320	44 44 44 44 44 44 44 44 44 44 44	120L 120L 120L 120L 122L 123L 123L 126L 127L 130L 131L 132L 133L 134L 135L	6.75 6.75 6.75 1.50 .75 1.75 1.75 600 .600 .50
Latuis Laudanum Laugh Launch Launch Laundry Laurel Lavish Layer Lazar Leach Leach	PS	3X39 10X11 14X38 10MC228 10MC229 10MC28 10M117 10M1124 10X76 10X74 2X611 2X611 10M178 10M178 10M179 10M181 10M179 10M181	cap screw bolt nut center screw Sector Gear (triple thread) Sector Gear (quadruple thread) Crank Crank ball with nut nut Sector shaft nut Sector Gear Eccentric (left) crank Crank ball with nut cone, cup, Sector Gear Eccentric (left) crank crank crank cone, cup, sector Gear Eccentric (left) crank crank crank cone, cup, sector Gear Eccentric (left) crank crank crank crank cone, cup, sector Gear Eccentric (left) crank c	2356 2320	44 44 44 44 44 44 44 44 44 44 44	120L 120L 120L 122L 123L 123L 126L 127L 130L 131L 132L 132L 132L	6.75 6.75 6.75 1.50 .75 1.75 1.75 .60 .60
Latuis Laudanum Laugh Launch Launch Laundry Laurel Lavish Layer Lazar Leach Leaden	PS	3X39 10X11 14X38 10MC228 10MC229 10MC28 10M1124 10X76 10X76 10X76 10X76 10X76 10X76 10X76 10X78 10M177 10M1180 10M178 10M179 10M181 10M177 10M181	cap screw bolt bolt center screw Sector Gear (triple thread) Sector Gear (quadruple thread) Crank ball with nut mut Sector shaft nut Sector Gear Bearing (cone and cup) cone, cup, sector Gear Eccentric (left) (fight) Eccentric plug (right) with dust washer mut lock plug dust washer	2356 2320	44 44 44 44 44 44 44 44 44 44 44 44 44	120L 120L 120L 122L 123L 126L 127L 130L 131L 132L 134L 135L	6.75 6.75 6.75 1.50 .75 1.75 1.75 .60 .60
Latuis Laudanum Laugh Launch Launch Laundry Laurel Lavish Layer Lazar Leach Leaden	P S	3X39 10X11 14X38 10MC228 10MC228 10MC128 10MC128 10M117 10X1124 10X76 10X74 2X611 2X611 2X611 10M180 10M178 10M179 10M181 10M179 10M181 10M177 21X14 15X46	cap screw bolt nut center screw Sector Gear (triple thread) Sector Gear (quadruple thread) Crank Crank ball with nut cone, nut Sector shaft nut Sector Gear Bearing (cone and cup) cone, cup, Sector Gear Eccentric (left) (right) Eccentric plug (right) with dust washer (""" nut lock """ plug dust washer """ nut screw STEERING POST BEARINGS Lower Bearing cup with balls and retainer	2356 2320	44 44 44 44 44 44 44 44 44 44 44 44 44	120L 120L 120L 122L 123L 123L 126L 127L 130L 131L 131L 133L 134L 135L	6.75 6.75 6.75 1.50 .75 1.75 1.75 .60 .60
Latuis Laudanum Laugh Launch Launch Laundry Laurel Lavish Layer Lazar Leach Leaden	P S S	3X39 10X11 14X38 10MC228 10MC229 10MC229 10M127 10M1124 10X76 10X76 10X74 2X611 2X611 2X61B 10M176 10M180 10M178 10M179 10M181	cap screw bolt nut center screw Sector Gear (triple thread) Crank Crank ball with nut nut Sector shaft nut Sector Gear Eccentric (left) (right) Eccentric plug (right) with dust washer (right) lock plug dust washer nut street STEERING POST BEARINGS Lower Bearing cup only bolds diameter 16 required	2356 2320	44 44 44 44 44 44 44 44 44 44 44 44 44	120L 120L 120L 122L 123L 123L 126L 127L 130L 131L 132L 133L 134L 135L	6.75 6.75 6.75 1.50 .75 1.75 1.75 .60 .60
Latuis Laudanum Laugh Launch Laundry Laundry Laurel Lavish Layer Lazar Leach Leaden	P S	3X39 10X11 14X38 10MC228 10MC229 10MC229 10M117 10M1124 10X76 10X76 10X76 10X76 10X76 10X74 2X611 2X611 10M180 10M178 10M178 10M179 10M181 10M179 10M181 10M186 1X12 10M186 1X12	cap screw bolt nut center screw Sector Gear (triple thread) Sector Gear (triple thread) Crank Crank Crank ball with nut nut Sector shaft nut Sector Gear Bearing (cone and cup) cone, cup, Sector Gear Eccentric (left) nut Sector Gear Eccentric (left) nut Sector Gear Eccentric (left) nut Sector Gear Eccentric (left) Sector Gear Eccentric (left) nut Sector Gear Eccentric (left) Sector Gear Ecce	2356 2320	44 44 44 44 44 44 44 44 44 44 44 44 44	120L 120L 120L 122L 122L 123L 126L 127L 130L 131L 132L 134L 135L	6.75 6.75 6.75 1.50 .75 1.75 1.75 .600 .50 .10
Latuis Laudanum Laugh Launch Laundry Laurel Lavish Layer Lazar Leach Leaden Leafage League Learn Leases	P S	3X39 10X11 14X38 10MC228 10MC228 10MC128 10MC128 10MC128 10M117 10X76 10X74 2X611 2X611 2X611 10M180 10M178 10M179 10M181 10M179 10M181 10M177 21X14 15X46	cap screw bolt nut center screw Sector Gear (triple thread) Sector Gear (triple thread) Crank Cr	2356 2320	44 44 44 44 44 44 44 44 44 44 44 44 44	120L 120L 120L 122L 123L 123L 126L 131L 131L 131L 132L 133L 134L 135L	6.75 6.75 6.75 1.50 .75 1.75 1.75 .60 .60 .50 .10
Latuis Laudanum Laugh Launch Launch Laundry Laurel Lavish Layer Lazar Leach Leaden Leafage League Learn Leasn	P S	3X39 10X11 14X38 10MC228 10MC229 10MC28 10M117 10M1124 10X76 10X76 10X74 2X611 2X611 2X611 B 10M176 10M178 10M179 10M181 10M177 21X14 15X46 10M180 10M180 10M180 10M181 10M180 10M181 10M180 10M181	cap screw bolt nut center screw Sector Gear (triple thread) Sector Gear (triple thread) Crank Crank ball with nut cone, cone, cone, cone, cup, Sector Gear Bearing (cone and cup) cone, cup, Sector Gear Eccentric (left) cup, cup, Sector Gear Eccentric (left) cup, cup cup, cup, cup cup, cup	2356 2320	44 44 44 44 44 44 44 44 44 44 44 44 44	120L 120L 120L 120L 1212L 123L 127L 130L 131L 134L 133L 134L 135L	6.75 6.75 6.75 1.50 1.75 1.75 .60 .50 .10
Latuis Laudanum Laugh Launch Launch Laundry Laurel Lavish Layer Lazar Leach Leaden	P S	3X39 10X11 14X38 10MC228 10MC228 10MC128 10MC128 10MC128 10M117 10X76 10X74 2X611 2X611 2X611 10M180 10M178 10M179 10M181 10M179 10M181 10M177 21X14 15X46	cap screw bolt nut center screw Sector Gear (triple thread) Sector Gear (triple thread) Crank Cr	2356 2320	44 44 44 44 44 44 44 44 44 44 44 44 44	120L 120L 120L 122L 123L 123L 126L 131L 131L 131L 132L 133L 134L 135L	6.75 6.75 6.75 1.50 6.75 1.50 6.75 1.75 6.75 6.75 6.75 6.75 6.75 6.75 6.75 6

When possible, order through Thomas Dealer

GROUP 10-CONTROL



When ordering parts use Code Word GROUP 10—CONTROL

Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Sellin Price
			STEERING POST BEARINGS—Continued			-	
		*******			44		
eaven echery		10MO188 10M184	Upper bearing adjusting cone adjusting cone lug washer		44	147L	\$1.00
ecture		10M183	" adjusting cone lock nut		44	149L	.1
			STEERING POST TUBES				
edaea	TP	10MCA220	Wheel Tube (Long) with Quadruple worm				
edepop	TP	10MCA221	and bushings Wheel Tube (Short) with Quadruple worm				\$10.5
ederball	TP	10MCA222	and bushings Wheel Tube (Long) with Triple worm and				10.5
ederhose	TP	10MCA223	bushings Wheel Tube (Short) with Triple worm and				10.5
			bushings			151L	10.5
edger eech	TP	10M1159 10MC1109	Long wheel tube $50\frac{1}{16}$ in. Short wheel tube $49\frac{1}{16}$ in.		44	151L 151L	4.7
eefange		10M171	Tube bushings			1011	.1
eemput		10M28	" worm (quadruple thread) " (triple thread)		44	153L	5.0
eere		10MC217	" (triple thread)		44	153L	5.0
egate		9X27 10M192	" key " nut		44	154L	.1
Saro					1	-011	.1
		103561	STEERING WHEEL			1.00	
egend		10MCA414 10MC47	Steering Wheel Assembly		44	160L 161L	\$16.0
		10MC415	" spider " rim			1011	
		17X19	" rim screw				
ogible		9X27	" key		44	163L	.5
egible		10M191	" nut		77	1031	.5
			THROTTLE AND SPARK CONTROL				
egislate	TP	10MA1255	Throttle and Spark Control Tube (Long) with				\$1.9
egless	TP	10MCA1114	lower bracket and bushings Throttle and Spark Control Tube (Short) with				1.9
		10M1158	lower bracket and bushings Segment tube (long)		44	165L	1.0
		10MC1110	" " (short)		44	165L	1.0
egume eisure		10M169 10M151	Dusining		44	167L	.0
cisure		14X72	" " bracket Bracket screw			10/12	
emon		10MA238	Segment Bracket with segment				4.1
emonade		10M21	" only		44	171L	1.5
		14X310 10X47	" bolt nut				
ength		10M165	Segment screw				.0
eniger		10MA231	Segment with plates		44	175L	2.3
		10M120	Segment				1.5
		10M149 10M150	" plate (upper) " (lower)				.3
enkbar		10MA1253	Throttle Control Tube (Long) with bushings and gear				2.2
enkung	TP	10MCA1117	Throttle Control Tube (Short) with bushings and gear				2.2
	TP	10M1157	Tube only (long) $52\frac{7}{16}$ in. "only (short) $51\frac{7}{16}$ in.		44	180L	1.0
eopard		10MC1111 10M168	" hiishing		44	180L	1.0
esson		10M162	" gear		44	182L	1.0
ethal		10M170	" gear spacer (thin .014 in. ga.)				.0
etter eucone		10M174 10MA232	" gear spacer (thick .032 in. ga.) Throttle Control Lever Assembly				1.9
evant		10MA232 10M161	" " only		44	185L	1.5
		14X310	" screw			1002	
		10X47	" " screw nut		44		
ever		10M166 18X11	" " plunger " plunger spring		44	186L	.1
		10MA1251	Spark Control Rod (Long) with gear				1.1
	TP	10MCA1116	Spark Control Rod (Short) with gear				1.1
		10MC1112	" (short) only		44 44	188L 188L	.1
	TD	10M1156	" " gear		44	189L	.8
everbot	TP	10M160					.0
everbot evity ibation	TP	10M160 10M173	" " spacer (thick)				.0
everbot evity ibation iberal	TP	10M160 10M173 10M175	" " spacer (thick)				.0
evity ibation iberal iberons	TP	10M160 10M173 10M175 10MA233	" spacer (thick) " spacer (thin) Spark Control Lever Assembly				1.2
everais everbot evity ibation iberal iberons ibertine	TP	10M160 10M173 10M175 10MA233 10M157 11X57	spacer (thick) spacer (thin) Spark Control Lever Assembly only pin				1.2
evity ibation iberal iberons	TP	10M160 10M173 10M175 10MA233	spacer (thick) spack Control Lever Assembly				1.2

When possible, order through Thomas Dealer

GROUP 10-CONTROL


Liberty				Illus- trated on Page	Plate	Pric
Library			THROTTLE AND SPARK CONTROL			
Library			In Bottom of Case			100
Library		10MA1263	Throttle Control Gear with shaft	44	195L	\$1.8
Library		10M163	" " only	 		1.2
Library		10M164	" " chaft (tube)	 		.1
		10M172	shaft bushing	 44	198L	.3
License		10M1116	Throttle Lever (or finger)	 44	199L	.3
		14X31	Lever screw	 		
Lichen		10M1188	Accelerator Bell Crank	 44	200L	.4
Ligament		10MXA1281 10M159	Spark Control Gear with shaft	 44	205L	1.5
- 3		10M158	" " only shaft (rod)	 44	207L	1.2
Library	********	10M172	" " bushing	 44	198L	.3
ight		10MC175	Spark Lever	 44	208L	.4
		16X12	" screw	 		
			STEERING POST BRACKETS			
ightly	T	15MC2103				\$1.9
igneous	S	15MC239	Steering Post Bracket (on dash) Steering Post Bracket (on dash)	 		1.9
		14X38	Bracket clamp screw	 		
		14X315	Bracket attaching bolt	 		
		10X41	" " nut	 		
ilac		15MC133	Dash Plate (upper)	 		.1
imber		15MC134 17X222	" (lower) " screw	 		.1
imbo	P	15MC2112	Dash Bracket	 		1.9
imit	R	15MC241		 		1.9
			Note—See above for standard parts.			
impet		10MC211	Steering Post Frame Block	 		1.4
		3X322	" " attaching bolt	 		
		10X11	" attaching bolt nut	 		
			STEERING POST (SURREY)			
ineage	S	10MCA419	Steering Post Assembly Special parts are as follows. All other parts same as for touring car.	 		\$98.5
Linen	S	10MXA336	Total Case with tube and collar	 		10.5
	S	10M154	Case tube	 		
infa	SSS	10MCA224	Wheel Tube with Quadruple worm and bush'gs Wheel Tube with Triple worm and bushings	 		10.5
inger	S	10MCA225 10M153	Wheel tube with Triple worm and bushings Wheel tube	 		10.5
	5	10111133	See page 45 for other parts.	 		4.7
innet	S	10MA1254	Control Segment Tube with lower bracket and			
			bushings_	 		1.9
	S	10M152	Segment tube only See page 45 for other parts.	 		
in a the	C	103// 4 12/2	See page 45 for other parts.			22
inotte	S	10MA1252 10M156	Throttle Control Tube with bushings and gear Tube only	 		2.2
	3	10141130	See page 45 for other parts.	 		
inquis	S	10MA1250	Spark Control Rod with gear	 		1.1
	S	10M155	" only	 		
			See page 45 for other parts.			
			STEERING POST (RUNABOUT)			
iquefy	R	10MCA411	Steering Post Assembly			\$98.5
			Special parts are as follows. All other parts			220.0
			same as for touring car.			
iquid	R	10MCA1100	Total Case with tube and collar	 		10.5
imit	R R	10MC167 15MC241	Case tube	 		1.9
iquidate	R	10MCA226	Steering gear dash bracket Wheel Tube with Quadruple worm and bush'gs	 		10.5
iquidos		10MCA227	Wheel Tube with Quadruple worm and bush'gs Wheel Tube with Triple worm and bushings	 		10.5
	R	10MC168	Wheel tube	 		
			See page 45 for other parts. Control Segment Tube with lower bracket			
isten	R	10MCA1101	Control Segment Tube with lower bracket			
	R	10MC169	and bushings Segment tube only	 		1.9
		101110109	See page 45 for other parts.	 		
itany	R	10MCA1102	See page 45 for other parts. Throttle Control Tube with bushing and gear	 		2.2
	R	10MC170	Tube only	 		
	D	103501111	See page 45 for other parts.			
iteral	R	10MCA1103	Spark Control Rod with gear	 		1.1
	R	10MC171	Spark control rod only See page 45 for other parts.	 		
			SIDE STEERING TUBE			
iat		10350122				
itharge ithe		10MCA39 10MC17	Side Steering Tube Assembly	 44	216L	\$5.0

When ordering parts use Code Word
GROUP 10—CONTROL

Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Sellin
			SIDE STEERING TUBE—Continued				
Lithology Lithotomy Litigate		10MA1135 10MA1136 10M1143	Tube front end assembly (1½B-single) "rear end assembly (1½B-double) "nut	*********	44	219L	\$1.7 2.2 .0
Lithology		10M1143 10MA1135	Side Steering Tube Front End Assembly (1 1/4 B - single)		44	2191	1.7
Littoral Liturgy		10M1139 10M1137	Tube end	ASR-16 ASR-18	44 44	225L 226L	.6
Livelong		10M1140	" " spring	ASR-22	44	227L	.1
lively liver		10M1142 10M1141	" " sleeve " spring adjusting nut	ASR-12 ASR-26	44	228L 229L	.4
ithotomy		10MA1136	Rear End Assembly (1 1/4 B-double)				2.2
ivid iturgy		10M1138 10M1137	Tube end " " socket	ASR-11 ASR-18	44 44	231L 226L	.8
ivelong		10M1140	" " spring	ASR-22	44	227L	.1
izard ively		10M1144 10M1142	" socket (long) " sleeve	ASR-28 ASR-12	44	232L 228L	.3
iver		10M1141	" " spring adjusting nut	ASR-26	44	229L	.2
lama		11X58 15M181	" socket pin Side Steering Tube End Boot not included				.6
		25X72	Boot lacing (20 in. long) in assembly				
			ACCELERATOR CONTROL				
oafer	TPR	10MCA314	Accelerator Pedal with bracket and crank			2411	\$2.5
oam		10MCA230 10MX225	Pedal with toe plate Pedal		48 48	241L 241L	1.0
abados		10MC164	" toe plate		48	242L	.2
obby obster		10MC190 10MX1298	" " collar				.1
		16X32	" collar set screw				
ocal ocate		10MX1278 10MC187	" " bracket " lever		48 48	245L 246L	.4
		15X32	Attaching bolt		40	2401	
		21X41	" washer				
ocker	TPSR	10X31 10MCA215	Accelerator Push Button Bracket Assembly				2.2
ocust		10M1203	Bracket		48	248L	.9
odge ogic		10M1195 10M1196	" plunger " spring		48 48	249L 250L	.0
ogistic		10M1190	" shaft		- 48	251L	.1
ogwood oiter		10M1194 10M1193	" " long lever		48	251L 252L	.3
oose		10M1192	" spring				.0
otion		10M1191 14X315	" attaching bolt			*	.1
		10X41	" nut				
ottery	S ·	10MCA315	Accelerator Pedal with bracket and crank Pedal with toe plate				2.5
		10MCA231 10MC213	Peda1				
obados		10MC164	" toe plate All other parts same as for touring car.				.2
ovable		10MX1285 17X22	Accelerator toe board plate Plate screw				.2
			CARBURETOR, MAGNETO AND TIMER				
ovelv		10MCA162	CONTROL Assolution and Stanting Post Connecting Post				
			Accelerator and Steering Post Connecting Rod Assembly		48	260L	\$0.6
ower		10MC163 22X41	Rod only				.1
		LLATI	" end complete Note—See Standard Parts page for parts of rod end				
owly		10X48 10MCA160	Rod end nut Carburetor and Steering Post Connecting Rod				
oyal			Assembly			265L	.6
oyal		10MC161 22X41	Rod only " end complete			32.	.1
070000		10X48	" end nut				
ozenge		10MCA158	Timing Rocker and Steering Post Connecting Rod Assembly		48	270L	.6
ubber		10MC159	Rod only				.1
		22X41 10X48	" end complete " end nut				
ubricate		10MA1149	Timing Rocker and Magneto Connecting				
ucent		10M130	Rod Assembly Rod only		48	275L	.6
		22X41	" end complete				
ucid		10X48 10MCA156	" end nut Timing Rocker and Timer Connecting Rod				
							.6

When possible, order through Thomas Dealer

GROUP 10-CONTROL



Automotive Research Library


Code	2						
Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Selling Price
			CARBURETOR, MAGNETO AND TIMER CONTROL—Continued				
Lucifer		10MC157 22X41	Rod only "end complete				\$0.15
ucky		10X48 10MCA1121	" end nut Timing Rocker with eye (for Eisemann mag.)		48	285L	1.00
Lucre Ludicrous Luggage		10MC1107 10MCA1120 10M132	" only with eye (for Bosch mag.) only		48	285L	.70 1.00 .70
Lullaby		10MC155 10X48	" screw eye nut		48	286L	.25
Lumbago		10MX1240 14X31	Timing Rocker Bracket attaching screw		48	290L	.60
			NOTE—See page 19 for Carburetor Priming Rod				
			Note—See page 17 for Compression Relief Rod				
			MUFFLER CUTOUT CONTROL				
Lumber		10MCA186 3MC13	Muffler Cutout Control Assembly Lever bracket		22	295L	\$1.60
Lunacy		HI177 10MC120	Operating lever Operating crank				.80
Lunch		11X57 HI179	Lever and crank pin "" shaft				.05
			MISCELLANY				100
Lunette		HI182	Cable link				\$0.05
		11X112 17X213	Bracket attaching screw				
Lunge		17X28 10MC188	Cutout Cable		22	305L	.10
Lupine		FI1130 HI183	Cable Clamp Assembly Clamp claw				.20
		HI184 15X433	" screw			240T	
Lurch		FD110 HI174 HI175	Cable Pulley Block with pulley Block Pulley			310L	.40
		HI175 HI176 15X45	Pulley pin Block attaching bolt				
		10X33	Bolt nut				

REAR AXLE

Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Selling Price
			REAR AXLE—TO LOCATE DETAILS				
Macaroni		11MCA42	Rear Axle Assembly (Give Ratio desired) Includes to part Six. To locate details—Axle is divided into parts			574M	\$310.00
			as follows for convenience only: Part One—Axle Housing with riveted parts and Truss Rod				
			Part Two—Differential Carrier complete with all fittings			12.	
			Part Three-External Brake Band with all				
			fittings Part Four—Internal Brake Shoe with all				
			fittings				
			Part Five—Axle Shafts with Clutches				
			Part Six—Rear Wheel Assembly				
			Part Seven—Torque Tube and Buffer Assem.				
			PART ONE				
Macaw Machine		11MCA420 11MCA327 11MX317	Axle Housing with riveted parts and truss rod Axle Housing with sleeves (after 1st 50 cars) Axle housing	T-1907	-50	-ī m	\$65.00 35.60

When possible, order through Thomas Dealer

GROUP 10—CONTROL GROUP 11—REAR AXLE




When ordering parts use Code Word

GROUP 11—REAR AXLE

Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Selling Price
			PART ONE—Continued				
		11MC223	Axle housing sleeve (after 1st 50 cars)	T-2428			
Mackerel		11MCA47	" with closures (on let 50 care)	T-2385	0000		\$38.5
		11MC213	" sleeve (on 1st 50 cars)	T-2094			
Madam		11MC117	Spring Seat collar	T-1099	50	43M	.3
Madrigal		11MC38	Brake spider (right)	R-1006			3.9
Magazine		11MC39	" (left)	R-1005	52	11M	3.9 1.5
Magic		11MC29	" dust shield (right) " dust shield (left)	R-1008		7777	1.5
Magistrate		11MC210	dust shield (left)	R-1007 R-901	50	13M	1.5
Magnesia		11MC132 11MX229	Internal brake steady bracket guide	R-623	52 52	15M 16M	.1
Magnet Magpie		11MC140	External brake anchor only	R-856	50	19M	1.0
Maintain		11MC121	Internal brake anchor stud	R-832		17111	.5
Maize		11MC142	Internal brake anchor stud External brake anchor stud	R-847	50	21M	.4
		10X413	Anchor stud nut				
Major		11MCA218	External brake supporting bracket (R) with				
			eye stud (R-626)				1.1
Malady		11MCA219	External brake supporting bracket (L) with				
Malanart		11MV226	eye stud (R-626)	R-692			1.1
Malapert Malaria		11MX236 11MX237	External brake supporting bracket (R)	R-691	50	$\bar{28}\bar{M}$.5
Malice		11MC148	" " steady bracket guide	R-903	50	30M	.0
Malign		11MX1107	Supporting bracket eye stud	R-626	52	31M	.6
Mallard		11MC174	Truss Rod	T-2382	52	35M	.9
		10X16	" " nut		52	36M	
Mallet		11MC177 11MC178	" nut lock wire " nut lock wire eyelet	T-2386		2222	.0
Malmsey		11MC178	" nut lock wire eyelet	R-1013	52	38M	.0
		21X321	" " washer				
					-		
			PART ONE MISCELLANY				
Maltreat		11MC318	Housing Cover	T-2291	50	2M	\$2.2
		14X79	" screw				
		10X423	" screw nut				
Mamma		11MX326	" gasket	T-1651			.60
Mammon		11MC169	mining note plug	T-1629			.20
		12X13	overnow plug	m 0000			
Mammoth		11MC171	overnow plug reducer	T-2364	50	1037	2.0
Manacle Manage		13MCA213 13MC27	Spring Seat with cap used up to 9-5-1911	T-1659		40M	3.95
Mandarin		13MCA214	" less cap prior to 9-5-1911 " with cap used after 9-5-1911	T-2468			3.9
Mandate		13MC211	" less can after 9-5-1911	1-2100			2.5
		3X44	" holt				
		10X421	" bolt nut				
		6X31	" "- grease cup				
Mandrake		13MC128	" cap				1.4
			PART TWO				
Mandrel		11MCA413	Differential Carrier with differential and				
MARINI CI		11111011110	Pinion Shaft complete, Ratio 210 to 1				\$163.50
		11MCA414	Differential carrier with differential and pinion				Ψ100101
Manes							
Manes			shaft complete, Ratio 3 to 1				163.5
Manes Manganese		11MCA415	shaft complete, Ratio 3 to 1 Differential carrier with differential and pinion				163.50
Manganese			Differential carrier with differential and pinion				
		11MCA415 11MCA416	Differential carrier with differential and pinion				163.5
Manganese Manger		11MCA416	Differential carrier with differential and pinion shaft complete, Ratio 3 ² / ₃ to 1 Differential carrier with differential and pinion shaft complete, Ratio 4 to 1	T-212F			163.50
Manganese Manger Mangle		11MCA416 11MC46	Differential carrier with differential and pinion shaft complete, Ratio 3 to 1 Differential carrier with differential and pinion shaft complete, Ratio 4 to 1 Differential carrier	T-2137		 50M	163.50 163.50 21.00
Manganese Manger Mangle		11MC4416 11MC46 11MC220	Differential carrier with differential and pinion shaft complete, Ratio 3 to 1 Differential carrier with differential and pinion shaft complete, Ratio 4 to 1 Differential carrier	T-2137 T-1705		50M	163.50 163.50 21.00
Manganese Manger Mangle		11MC4416 11MC46 11MC220 3X341	Differential carrier with differential and pinion shaft complete, Rafto 33 to 1 Differential carrier with differential and pinion shaft complete, Rafto 4 to 1 Differential carrier and housing gasket and housing bolt below the bolt mut.	T-2137 T-1705			163.50 163.50 21.00
Manganese Manger Mangle Mango		11MCA416 11MC46 11MC220 3X341 10X421	Differential carrier with differential and pinion shaft complete, Ratio 33 to 1 Differential carrier with differential and pinion shaft complete, Ratio 4 to 1 Differential carrier " and housing gasket " bolt nut " beep hole plus	T-1705			163.56 21.00 .10
Manganese Manger Mangle Mango Mania		11MCA416 11MC46 11MC220 3X341 10X421 11MX199	Differential carrier with differential and pinnon shaft complete, Rafto 33 to 1 Differential carrier with differential and pinnon shaft complete, Rafto 4 to 1 Differential carrier " and housing gasket and housing gasket and housing bolt bolt nut peep hole plug " bearing cap (right)	T-1705 T-1567		52M	163.50 163.50 21.00 .10
Manganese Manger Mangle Mango Mania Manifold		11MCA416 11MC46 11MC220 3X341 10X421 11MX199 11MC211 11MC212	Differential carrier with differential and pinion shaft complete, Ratio 33 to 1 Differential carrier with differential and pinion shaft complete, Ratio 4 to 1 Differential carrier and housing gasket and housing bolt bolt nut peep hole plug bearing cap (right) """ (left)	T-1705 T-1567 T-2138 T-2139	50		163.5(21.0(.1(.2(1.1(
Manganese Mangle Mangle Mango Mania Manifold Manioc		11MCA416 11MC46 11MC220 3X341 10X421 11MX199 11MC211 11MC212 11MX1125	Differential carrier with differential and pinnon shaft complete, Ratio 33 to 1 and pinnon shaft complete, Ratio 4 to 1 Differential carrier with differential and pinnon shaft complete, Ratio 4 to 1 Differential carrier and housing gasket and housing bolt believed to bolt nut peep hole plug bearing cap (right) (left) (left) when the property of the	T-1705 T-1567 T-2138	50	52M 53M	163.50 21.00 .10 .20 1.10 1.20
Manganese Mangle Mangle Mango Mania Manifold Manioc		11MCA416 11MC46 11MC220 3X341 10X421 11MX199 11MC211 11MC212 11MX1125 10X41	Differential carrier with differential and pinnon shaft complete, Ratio 33 to 1 Differential carrier with differential and pinion shaft complete, Ratio 4 to 1 Differential carrier and housing gasket and housing bolt bolt nut peep hole plug bearing cap (right) (left) " " (left) " " steady screw " " " steady screw nut	T-1705 T-1567 T-2138 T-2139	50 50 50	52M 53M 54M	163.5 21.0 .1 .2 1.1 1.2
Manganese Manger Mangle Mango Mania Manifold Manioc Manner		11MCA416 11MC46 11MC220 3X341 10X421 11MX199 11MC211 11MC212 11MX1125 10X41 14X711	Differential carrier with differential and pinnon shaft complete, Ratio 33 to 1 Differential carrier with differential and pinnon shaft complete, Ratio 4 to 1 Differential carrier " and housing gasket and housing bolt bolt nut peep hole plug bearing cap (right) " (left) " " steady screw " steady screw nut " " screw	T-1705 T-1567 T-2138 T-2139 X-371	50 50 50	52M 53M 54M	163.5 21.0 .1 .2 1.1 1.2 .0
Manganese Manger Mangle Mango Mania Manifold Manioc Manner Mansion		11MCA416 11MC46 11MC220 3X341 10X421 11MX199 11MC211 11MC212 11MX1125 10X41 14X711 11MC155	Differential carrier with differential and pinnon shaft complete, Ratio 33 to 1 Differential carrier with differential and pinion shaft complete, Ratio 4 to 1 Differential carrier and housing gasket and housing bolt bolt nut peep hole plug bearing cap (right) (left) earlier with the carrier stands of the ca	T-1705 T-1567 T-2138 T-2139 X-371 T-1701	50 50 50	52M 53M 54M	163.5 21.0 .1 .2 1.1 1.2 .0
Manganese Manger Mangle Mango Mania Manifold Manioc Manner Mansion Mantel		11MCA416 11MC46 11MC220 3X341 10X421 11MX199 11MC211 11MC212 11MX1125 10X41 14X711 11MC155 11MC156	Differential carrier with differential and pinnon shaft complete, Ratio 33 to 1 Differential carrier with differential and pinion shaft complete, Ratio 4 to 1 Differential carrier and housing gasket and housing bolt bolt nut peep hole plug bearing cap (right) (left) earlier with the carrier stands of the ca	T-1705 T-1567 T-2138 T-2139 X-371 T-1701 T-2132	50 50 50 50	52M 53M 54M 54M	163.5 163.5 21.0 .1 .2 1.1 1.2 .0
Manganese Manger Mangle Mango Mania Manifold Manioc Manner Mansion Mantel Mantel Mantua		11MCA416 11MC20 3X341 10X421 11MX199 11MC211 11MC212 11X1125 10X41 14X711 11MC155 11MC155 11MC157	Differential carrier with differential and pinnon shaft complete, Ratio 33 to 1 1 Differential carrier with differential and pinion shaft complete, Ratio 4 to 1 1 Differential carrier " and housing gasket and housing bolt " bolt nut " peep hole plug bearing cap (right) " (left) " steady screw " steady screw nut " screw " screw lock wire adjusting case (R) " adjusting case (L)	T-1705 T-1567 T-2138 T-2139 X-371 T-1701 T-2132 T-2133	50 50 50 50	52M 53M 54M 54M	163.5 163.5 21.0 .1 .2 1.1 1.2 .0 .0 2.2 2.2 2.5
Manganese Manger Mangle Mania Mania Manifold Manioc Manner Mansion Mantel Mantel Mantua		11MCA416 11MC246 11MC220 3X341 10X421 11MX199 11MC211 11MC212 11MX1125 10X41 14X711 11MC155 11MC155 11MC156 11MC157	Differential carrier with differential and pinnon shaft complete, Ratio 33 to 1 Differential carrier with differential and pinnon shaft complete, Ratio 4 to 1 Differential carrier " and housing gasket and housing gasket below and housing gasket	T-1705 T-1567 T-2138 T-2139 X-371 T-1701 T-2132 T-2133 T-2152	50 50 50 50 50 50	52M 53M 54M 54M 60M 61M 62M	163.5 163.5 21.0 .1 .2 1.1 1.2 .0 .0 2.2 2.5 5 1.1
Manganese Manger Mangle Mango Mania Manifold Manioc Manner Mansion Mantel Mantua Manual Manure		11MCA416 11MC46 11MC220 3X341 10X421 11MX199 11MC211 11MC212 11MX1125 10X41 114X711 11MC155 11MC156 11MC157 11MC157 11MC158 11MC159	Differential carrier with differential and pinnon shaft complete, Ratio 33 to 1 Differential carrier with differential and pinnon shaft complete, Ratio 4 to 1 Differential carrier " and housing gasket and housing gasket below and housing gasket	T-1705 T-1567 T-2138 T-2139 X-371 T-1701 T-2132 T-2133 T-2152	50 50 50 50 50 50 50 50 50 50	52M 53M 54M 54M 60M 61M 62M 63M	163.5 163.5 21.0 .1 .2 1.1 1.2 .0 .0 .0 2.2 2.5 1.1.1
Manganese Manger Mangle Mania Mania Manifold Manioc Manner Mansion Mantel Mantel Manutua Manure Manure Manure		11MCA416 11MC46 11MC220 3X341 10X421 11MX199 11MC212 11MX1125 10X41 14X711 11MC155 11MC157 11MC158 11MC158 11MC158 11MC158 11MC158 11MC159	Differential carrier with differential and pinnon shaft complete, Ratio 33 to 1 1 Differential carrier with differential and pinion shaft complete, Ratio 4 to 1 1 Differential carrier ——————————————————————————————————	T-1705 T-1507 T-2138 T-2139 X-371 T-1701 T-2432 T-2133 T-2152 T-2151 T-2375	50 50 50 50 50 50 50 50 50 50	52M 53M 54M 54M 60M 61M 62M 63M	163.5 163.5 21.0 .1 .2 .2 .1.1 1.2 .0 .0 2.2 2.5 1.1 1.2 1.2
Manganese Manger Mangle Mangle Mania Mania Manifold Manioc Manner Mansion Mantel Manutua Manutua Manure Manue		11MCA416 11MC46 11MC220 3X341 10X421 11MX199 11MC211 11MC212 11MX1125 10X41 11MC155 11MC155 11MC157 11MC159 11MC159 11MC159 11MC153	Differential carrier with differential and pinnon shaft complete, Ratio 33 to 1 Differential carrier with differential and pinnon shaft complete, Ratio 4 to 1 Differential carrier " and housing gasket and housing gasket bearing and housing gasket bearing ap (right) " bearing ap (right) " (left) " steady screw " steady screw nut " screw lock wire adjusting case (R) " adjusting case (L) " adjusting case lock ring (R) " adjusting case lock ring (L) " lock ring pin " lock ring pin " (right) complete	T-1705 T-1567 T-2138 T-2139 X-371 T-1701 T-2432 T-2133 T-2152 T-2151 T-2375 T-2374	50 50 50 50 50 50 50 50 50	52M 53M 54M 54M 60M 61M 62M 63M	163.5 163.5 21.0 .1 .2 1.1 1.2 .0 .0 2.2 2.5 1.1 1.2
Manganese Manger Mangle Mania Mania Manifold Manioc Manner Mansion Mantel Mantel Manutua Manure Manure Manure		11MCA416 11MC46 11MC220 3X341 10X421 11MX199 11MC211 11MC212 11MX1125 10X41 14X711 11MC155 11MC155 11MC155 11MC158 11MC158 11MC159 11MC152 11MC153 2X62 2X62A	Differential carrier with differential and pinnon shaft complete, Ratio 33 to 1 Differential carrier with differential and pinnon shaft complete, Ratio 4 to 1 Differential carrier " and housing gasket and housing gasket bearing cap (right) bearing cap (right) bearing cap (right) " steady screw steady screw nut screw screw adjusting case (R) adjusting case (L) adjusting case lock ring (R) adjusting case lock ring (L) bock ring pin lock ring pin spring (right) complete cone (right)	T-1705 T-1507 T-2138 T-2139 X-371 T-1701 T-2432 T-2132 T-2152 T-2151 T-2375 T-2374	50 50 50 50 50 50 50 50 50	52M 53M 54M 54M 60M 61M 62M 63M	163.5 163.5 21.0 .1 .2 1.1 1.2 .0 .0 2.2 2.5 1.1 1.2
Manganese Manger Mangle Mania Mania Manifold Manioc Manner Mansion Mantel Mantel Manutua Manure Manure Manure		11MCA416 11MC46 11MC220 3X341 10X421 11MX199 11MC211 11MC212 11MX1125 10X41 14X711 11MC155 11MC157 11MC158 11MC158 11MC158 11MC159 11MC152 2X624 2X62B	Differential carrier with differential and pinnon shaft complete, Ratio 33 to 1 Differential carrier with differential and pinnon shaft complete, Ratio 4 to 1 Differential carrier " and housing gasket and housing gasket bearing and housing gasket bearing ap (right) " bearing ap (right) " (left) " steady screw nut " steady screw nut " screw lock wire " screw lock wire " adjusting case (L) " adjusting case lock ring (L) " adjusting case lock ring (L) " lock ring pin " (right) complete " (right) complete " " cup (right)	T-1705 T-1567 T-2138 T-2139 X-371 T-1701 T-2432 T-2133 T-2152 T-2151 T-2375 T-2374	50 50 50 50 50 50 50 50 50	52M 53M 54M 54M 60M 61M 62M 63M	163.5 163.5 21.0 .1 .2 .2 .1.1 1.2 .0 .0 2.2 2.5 1.1 1.2 1.2
Manganese		11MCA416 11MC46 11MC220 3X341 10X421 11MX199 11MC211 11MX191 11MC212 11MX1125 10X41 114X711 11MC155 11MC155 11MC155 11MC155 11MC157 11MC158 11MC159 11MC152 2X622 2X628 2X628	Differential carrier with differential and pinnon shaft complete, Ratio 33 to 1 Differential carrier with differential and pinnon shaft complete, Ratio 4 to 1 Differential carrier " and housing gasket and housing gasket bearing and housing gasket bearing ap (right) " bearing ap (right) " (left) " steady screw nut " steady screw nut " screw lock wire " screw lock wire " adjusting case (L) " adjusting case lock ring (L) " adjusting case lock ring (L) " lock ring pin " (right) complete " (right) complete " " cup (right)	T-1705 T-1567 T-2138 T-2139 T-2139 T-1701 T-2132 T-2152 T-2151 T-2374 375 3720	50 50 50 50 50 50 50 50 50	52M 53M 54M 54M 60M 61M 62M 63M 66M 67M	163.5
Manganese Manger Mangle Mania Mania Manifold Manioc Manner Mansion Mantel Mantel Manutua Manure Manure Manure		11MCA416 11MC46 11MC220 3X341 10X421 11MX199 11MC211 11MX212 11MX1125 10X41 11MC155 11MC155 11MC156 11MC157 11MC158 11MC158 11MC158 11MC152 2X622 2X62A 2X615 2X615	Differential carrier with differential and pinnon shaft complete, Ratio 33 to 1 Differential carrier with differential and pinnon shaft complete, Ratio 4 to 1 Differential carrier " and housing gasket and housing gasket bearing cap (right) " bearing cap (right) " (left) " steady screw nut " steady screw nut " screw lock wire " adjusting case (R) " adjusting case (R) " adjusting case lock ring (R) " adjusting case lock ring (L) " lock ring pin " (right) complete " cone (right) " cup (right) " (left) complete " cone (left)	T-1705 T-1567 T-2138 T-2139 X-371 T-1701 T-2132 T-2132 T-2152 T-2151 T-2375 T-2374 375 3720	50 50 50 50 50 50 50 50 50 50	52M 53M 54M 54M 60M 61M 62M 63M 66M 67M	163.5/ 21.00 .10 .20 1.1/ 1.22 .00 2.22 2.5/ 1.1/ 1.20
Manganese Manger Mangle Mango Mania Manifold Manioc Manner Mansion Mantel Mantel Manuta Manual Manure Mangle		11MCA416 11MC46 11MC220 3X341 10X421 11MX199 11MC211 11MX191 11MC212 11MX1125 10X41 114X711 11MC155 11MC155 11MC155 11MC155 11MC157 11MC158 11MC159 11MC152 2X622 2X628 2X628	Differential carrier with differential and pinnon shaft complete, Ratio 33 to 1 Differential carrier with differential and pinnon shaft complete, Ratio 4 to 1 Differential carrier " and housing gasket and housing gasket bearing and housing gasket bearing ap (right) " bearing ap (right) " (left) " steady screw nut " steady screw nut " screw lock wire " screw lock wire " adjusting case (L) " adjusting case lock ring (L) " adjusting case lock ring (L) " lock ring pin " (right) complete " (right) complete " " cup (right)	T-1705 T-1567 T-2138 T-2139 T-2139 T-1701 T-2132 T-2152 T-2151 T-2374 375 3720	50 50 50 50 50 50 50 50 50	52M 53M 54M 54M 60M 61M 62M 63M 66M 67M	163.5/ 21.00 .10 .20 1.1/ 1.22 .00 2.22 2.5/ 1.1/ 1.20

When possible, order through Thomas Dealer

Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Selling Price
March Margin Marigold Marine Marital		11MCA410 11MCA221 11M215 11MC222 11M217	PART TWO—Continued Differential, 45 H. P. with large bevel gear. Give ratio See below for details Pinion Shaft with pinion. Give ratio "for all but 4 to 1 ratio "for 4 to 1 ratio "pinion 3 to 1 ratio	T-1095 T-621	50 50 50 50	76M 76M 78M	\$77.50 17.10 6.50 6.50 10.00




When ordering parts use Code Word

	-	- 1	1				1
Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Sellin Price
			PART TWO—Continued				
Market		11MC161	Pinion shaft pinion 210 to 1 ratio	T-620	50	78M	\$10.00
Marline		11M177	" " 33 to 1 ratio	T-622	50	78M	10.00
Marmot		11MC23	" 4 to 1 ratio	T-1544	50	78M	10.00
Maroon		12M112	nut	L-224	50	79M	40
Marque		11M147 9X12		T-983			.10
		9X16	" key for all but 4 to 1 ratio key for 4 to 1 ratio				
Marrow		11MC167	" rear bearing adjusting case, not				
			used for 4 to 1 ratio	T-2165	50	85M	2.25
Marry		11MC168	Pinion shaft rear bearing adjusting case, used	m	***	0=34	2.01
		2X65	with 4 to 1 ratio	T-1569	50	85M	2.2
		2X65A	Pinion shaft rear bearing complete cone regular	435	50	87M	
		2X65B	" " cone regular	4320	50	88M	777
		2X615	Pinion shaft rear bearing complete with 4 to 1				
			ratio only				
		2X615A	Pinion shaft rear bearing cone with 4 to 1				
BALL STORY		OVEITE	ratio only	456			
		2X615B	Pinion shaft rear bearing cup with 4 to 1	4520			
Marten		11MX198	ratio only Pinion shaft rear bearing adjusting hole cover	4320			
		11111190	with felt	T-1628	13		.20
Mason		11M154	Pinion shaft rear bearing adjusting hole cover		177	The state of	
			felt	T-642			.10
		14X83	Adjusting hole cover screw				
		3X342	Pinion shaft rear bearing clamp bolt		****		
		10X712 2X63	Clamp bolt nut Pinion shaft front bearing complete				
		2X63A		336	50	101M	
		2X63B	" " " cup	3320	50	102M	
Taster		11MC165	" " spacing nut	T-2147	50	103M	2.2
Mastic		11MX196	Front bearing jam nut	T-1579	50	104 M	.50
Iastodon		11MX197	" washer " dust felt	T-1581	50	105 M	.10
Match		11MC166		X-629	50	106M	.20
Maternal Matins		11MC163 11MC164	Front hooring felt retainer (outer)	T-2150 T-2149			.15
Matron		11MC162	" " dust collar " " grease cup	T-2148	50	109 M	.15
		6X32	" grease cup				
March		11MCA410					
naich		IIMCATIO	Differential Assembly, 45 H. P. with large bevel gear. Give ratio				77.50
Mattress		11MCA215	Differential assembly less bevel gear	T-2163			53.00
Mature		11M39	" hevel gear 3 to 1 ratio	T-612		116M	24.00
Maudlin		11M314	" 33 to 1 ratio " 4 to 1 ratio	T-613	50 -	116M	24.00
Mauve		11MC24	4 to 1 ratio	T-491 X-307	50	116M	24.00
Mawkish Mayor		11MC116 11MC315	" " rivet " " 2½ to 1 ratio	T-614	50	116M	24.00
Meadow		11MC316		T-2708	50	120M	8.10
Aeander		11MC317	housing (right) housing (left) internal bevel gear (large)	T-2787	50	121M	10.60
Measles		11M225	" internal bevel gear (large)	T-1362		122M	9.30
Teasure		11MC180	internal bevel pinion (small)	T-1354	50	123M	2.4
Techanic		11M238	" pinion spider	T-1353	50	124M	5.10
		14X74	" housing bolt				
Medal		11MC172	Torque Pin (not included in axle assembly)	T-2295	56	130M	3.10
Meddle		11MC173	Torque pin nut	T-2296	56	131M	.40
Iedical		11M158	bushing (this is included in car-	T 625			10
		6X14	rier assembly)	T-635			1.00
		0214	Torque pin grease cup For balance of parts see Torque Tube page 56	2			
			PART THREE		-		
Medicine		11MCA319	External Brake Band Assembly (R)				\$12.50
Iediocre		11MCA320	" " " (L)	D 1018			12.50
Iedium Iedlev		11MC310 11MC146		R-1017 R-1018	52	142 M	3.40
legrim		11MC146 11MC141	Band lining " anchor bracket	R-1018 R-849	52	144 M	.8
Iellow		11MX195	" adjusting stop	R-651		145 M	.1
Ielody		11M132	" releasing spring	R-413			.10
Iember		11MC144	" end bracket (upper)	R-850	52	147 M	.3
Iembrane		11MC145	" end bracket (lower)	R-851	52	148 M	.5
Iemento		11MC216	" lever (right) " lever (left) " lever head pin	R-1208		15034	1.5
Iemoir		11MC217	" lever (left)	R-1209	52	150 M	1.5
		11MX1119 11MX227	" lever head pin	R-128 R-678	52 52	151 M 152 M	1.0
I emorial		11M X227 10X422	" lever eye bolt im nut	14-010			1.00
I emorial		IUNTEL	" lover ove bolt stop put	D chr			.0
Memorial Memory		11MX1120		R-075			
Memorial Memory Menace Menial		11MX1129 11MX1105	" lever eye bolt adjusting nut	R-675 R-603		155 M	.35
Memorial Memory Menace		11MX1129		R-675 R-603 R-627 R-628		155 M 156 M	.35

When possible, order through Thomas Dealer

Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Selling Price
Merchant Mercurial		11MC149 11MC147	PART THREE—Continued Band expanding spring washer (lower) steady bracket PART FOUR	R-629 R-902	52	159 M	\$0.05 .95
Mercy Merge Merino Merit Merlin		11MCA321 11MCA322 11MC37 11MC124 11MC120	Internal Brake Shoe Assem. (R) Includes	R-1010 R-834	52	168 M 170 M	\$11.50 11.50 1.40 2.25 .85



When ordering parts use Code Word


GROUP 11—REAR AXLE

54

Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Sellin
			PART FOUR—Continued				
Mellow		11MX195	Internal brake shoe adjusting stop	R-651	52	145 M	\$0.10
Mermaid		11MC122	" " end bracket	R-1012	52	171 M	.85
Merry		11MC125	" " contracting spring	R-1090	52	172 M	
lessage		11MC126	contracting spring stud	R-1091			.10
Ietal		11MC130	guide bracket	R-909	52 52	174 M	
Ietaphor		11MC131	steady bracket	R-900		175 M	.10
leteor		11MX1113	releasing spring	R-650 R-908	52 52	176 M	
Iethinks		11MC119 10X41	adjusting screw	X-340	32	1//M	.10
Iethod		11MC138	" adjusting screw nut end bracket pin (upper)	R-874	52	179 M	.35
letre		11MC139	" end bracket pin (dpper)	R-875	52	180 M	
lettle		11MC123	" " end bracket pin washer	R-1115		100111	.05
liasma		11MC118	" " adjusting screw	R-869	52	182 M	.6
lidday		11MC134	" adi, screw lock spring	R-1039	52	183 M	.0.
lidge		11MC135	" lock spring support	R-1040	52	184 M	
idrib		11MC133	" shoe toggle adj. link	R-904	52	190 M	.7
letre		11MC139	" toggle adj. link pin	R-875	52	180 M	.3
lidriff		11MC136	toggie connecting link	R-873	52	192 M	1.5
idsummer		11MC137	toggle connecting link pin	R-132	52 52	193 M	.13
eteor		11MX1113	anti-rattle spring	R-650	52	176 M 207 M	.0.
ight almsey		11MC181 11MC178	" " clip eyelet	R-1189 R-1013	52	38 M	.0.
elody		11M132	" shoe stop spring	R-413	02		.10
igrate		11MCA184	" Operating Lever with Shaft (R)				1.5
ilch		11MCA185	" " (L)				1.55
ildew		11MC127	" " " "	R-1054	50	197 M	.80
ilitary		11MC129	" stop screw	X-658			.10
		10X423	" stop screw nut				
		11X511	" " pin		-55-		
illet		11MC128	" " shaft	R-1055	52	200 M	.65
			MICCELLANY				
			MISCELLANY		100		
illion		11M111	Internal brake expanding lever	R-131	52	205 M	\$1.00
		11X511	ii ii pin				
			PART FIVE				
imic		11MC311	Axle Shaft (right) with driving clutch	T-1888	50	212M	\$13.50
inaret		11MC312	" (left) with driving clutch	T-1889	50	213M	13.50
		2X62A	Rear wheel bearing cone	375		236 M	4.75
ince		11MX1102	" " adjusting nut	T-1576	50	238 M	.55
ineral		11MC150	" " adjusting nut washer	T-1668			.10
ingle		11M1132	" " adjusting nut felt	X-502			.15
inim		11M184	" adj. nut felt spacer	T-1340			.05
			DADT CIV				
			PART SIX				
inimum		11MCA412	Rear Wheel Assembly, less tire rim (painted)				\$40.00
inster		11MCA45	" Assem., less tire and rim (primed)				37.00
		11MC411	" (spokes, felloe and band)				
inistry		11MCA323	nub assembly (see below)				18.35
innow		11MC17	DOIL and nut				.10
instrel		10X421	Dolt nut	X-645			.10
instrel		11MC18 11MC35	" brake drum	R-1070	54	220 M	4.25
ingle		11M176	" " holt and nut	10/0	34	220 W	.10
		10X38	" " holt nut				
inute		11M164	" " holt washer				.05
inocene		11MC16	" hub cap	W-695	54	222 M	2.50
inor		11MC186	Tire rim wedge				.05
iracle		11MCA323	Rear Wheel Hub Assembly				18.35
irage		11MC33	" " hub	W-587		225 M	5.75
irror		11MC34	nange	W-573		226 M	6.75
innow		11MC17	bolt and nut	X-568			.10
		10X421	Dolt nut	W 606	- 27	22735	
irth		11MC110	dust left	X-606		227 M	.10
isapply		11MC19 11MC111	Felt retainer (outer)	T-2105 T-2104		200	.10
iscall iscarry		11MX1134	" (inner) " lock ring	T-693			.05
iscarry		11MX1134	" " lock ring lock wire	1-093	54	231 M	.00
instrel		11MC18	Hub oiler	X-645	01	201111	.10
and ti CI		2X62B	" bearing cup	3720	54	237 M	2.40
		2X62	Rear wheel bearing complete				
ischance		12MC44	Tire Rim No.3 United (see tool equipment for		-		
			rim tool and brace)				5.50
			PART SEVEN		100		
			TORQUE TUBES				
					1		
•	mp						001.00
iscount iscreant	TP TP	11MCA330 11MCA31	Torque Tube and Spring Buffer Assembly Torque Tubes with Connections				\$24.00

When possible, order through Thomas Dealer

Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Selling Price
			PART SEVEN				
			Torque Tubes—Continued	The same of			
	TP	11MC11	Upper tube		56	261 M	\$ 1.60
	TP	11MC12	Lower tube		56	262 M	1.60
		11M220	Front connection		56	263 M	2.15
		11MC114	Rear-upper connection	T-2146	56	264 M	1.50
	TP	11MC13	Rear-lower connection	T-2369		265 M	1.50
	1P	11X45	Connection pin	1-2309	30	205 IVI	1.50
					2000		
		3X38	" bolt				
		10X11	DOIL HUL				
		10X71	Front connecting nut		-		
Misdate		11M168	" washer				.05
Medal		11MC172	Torque pin		56	130 M	3.10
Misdeed		11MC173	" nut		50		.40
		6X14	" " grease cup				
Misdirect	SR	11MCA329	Torque Tube and Spring Buffer Assembly			2222	24.00
Misemploy	SR	11MCA36	Torque Tube with connection				13.36
arisemploy	SR	11MC112	Upper tube		56	261 M	1.10
	SR	11MC112	Lower tube			262 M	1.10
	SR	11MC115	Rear-lower connection		56	265 M	1.50
			Note—All other parts same as for touring car				
Miserere		11MCA328	Torque Spring Buffer or Housing Assembly				10.50
Misery		11MCA224	Housing with bushing, less bracket		56	270 M	3.15
		11MO21	" only				
Misgive		11MO118	" bushing		56	271 M	1.00
		6X13	" grease cup		10000		
Misgotten		11MCA187	" cap with bushing		56	273 M	1.80
MIDBOLLOIL		11M169	" cap only		00	2,011	1100
Misguide		11M166	" cap bushing		56	274 M	.75
Misguide		15X49			30	214 IVI	./3
			cap screw				
Mishap		11MA1136	Spring rod (with yoke)				2.45
Misjudge		11M173	only		56	276 M	1.10
Mislay		11MOO18	" " nut		56	277 M	.75
Mislead		11M165	" " voke		56	278 M	1.25




When ordering parts use Code Word

Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Selling Price
			PART SEVEN Torque Tubes—Continued				
Misname Misplace Misprint Misprize		11M170 11M167 6X13 11M171 10X14 11M172 10X14	Rod spring " block " " grease cup " " bolt " " bolt nut Housing to bracket bolt Bolt nut Note—See page 64 for bracket on frame		56 56 56	279 M 280 M 284 M	\$0.35 1.10 .25

FRONT AXLE

Code Word	Style of .Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Selling Price
Nabob		12MCA42	FRONT AXLE ASSEMBLY Front Axle Assembly, No. 146 Includes to wheels. Omitting wheel bear-	E-1006			\$110.00
Naivete Naked Naphtha Narcotic		12MCA45 12MC122 12MC123 12MX130 10X43 2X614B	ings. Axle with bushings and bearing cups "bushing (upper) "bushing (lower) Knuckle arm stop screw "nut "bearing cup	L-1769 L-1639 L-1594 X-546	57 57 57 57 57	1N 2N 3N 5N	52.30 .85 .95 .05




When possible, order through Thomas Dealer

GROUP 11—REAR AXLE GROUP 12—FRONT AXLE

FRONT AXLE

Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Selling Price
			FRONT AXLE ASSEMBLY—Continued				
Narrate		12MC36	Steering Knuckle (right)	L-1570	57	10N	\$ 6.20
Narrow		12MC37	" (left)	L-1569			6.2
Nasal		12M13	" spindle washer	L-218	57	12N	.10
Nastv		12M112	" nut (right-hand thread)	L-224	57	13N	.40
Nation		12M111	" nut (left-hand thread)	L-225			.40
Native		12MC23	Steering Knuckle Pin	L-1595	57	18N	1.9
		10X712	" " nut				
		21X321	" " washer				
		6X13	" " grease cup		57	20N	
Naught		12MC125	" " cap	L-1645	57	21N	.0.
Vausea		12MC126	" " draw key	L-1712	57	22N	.1
· · · · · · · · · · · · · · · · · · ·	-	10X43	" " draw key nut				



When ordering parts use Code Word

GROUP 12—FRONT AXLE

58

FRONT AXLE

Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Sellir Pric
			FRONT AXLE ASSEMBLY—Continued				
		2X614	Steering Knuckle Bearing complete				\$ 5.10
		2X614A	" cone	3650	57	26N	3.3
		2X614B	cup	3620	57	27N	1.8
Nautilus Nebula		12MC121	dust wasner	L-1596	57	28N	.1
Nebula		12MCA39 12MC34	Steering Arm (right-double) with ball (right-double)	L-1576	57	35N	7.4
Vecrology		12MCA310	" (left-single) with ball	L-1370		3311	3.6
recreiogy		12MC35	" (left-single)	L-1577			0.0
		9X15	" kev				
Vectar		12MC110	" nut	L-1608			.2
Veedle		12MC19	ball and nut	L-1352	57	38N	.9
Veedy		12MC111	Dan nut	X-518		2037	.1
Vegation		6X31 12MC112	" grease cup	L-1602	57	39N	.0
egation		12MC112	" pin draw key " pin draw key nut	L-1002			.0
Teglect		12MCA33	Steering Cross Tube Assembly	N-1023			11.2
legligee		12MC14	" tube	L-1152	57	45N	2.2
Tegro		12MCA24	Tube end (right) with bushings		57	46N	3.5
		12MC21	Steering cross tube end (right)	L-1910			
Teology		12MCA25	Tube end (left) with bushings				3.5
		12MC22	" " (left)	L-1871			2.0
Tepenthe Tephew		12MC116 12MC117	" bushing (upper) " bushing (lower)	L-1644 L-1380	57 57	50N	.6
epnew		12MC117 14X38	" " clamp holt	L-1380		51N	.0
		10X43	" " clamp bolt nut				
							0
			MISCELLANY				
Terve		12MC113	Tube end pin	L-1600	57	55N	\$1.1
estle		12M115	" " nut	X-203	57	56N	.0
euter		12MC114	wasner	L-1347			.0
lever		12MC115 6X31	dust cap	L-1646			.0
lewel		12MC44	Front tire rim No. 3 United Q. D.				5.5
CWCI		12111011	FRONT WHEEL			****	0.0
dination.		12340420					C140
licotian liece		12MCA38 12MC31	Front Wheel Hub Assembly	W-574	58	65N	\$14.0
light		12MC31	" " flange	W-574 W-584	58	66N	3.7
imble		12MC13	" " flange holt with nut	X-608		0011	.1
		10X421	" " flange holt nut		101		
		2X613B	" inner bearing cup	412	58	67N	2.0
		2X611B	" " outer bearing cup	312	58	68N	1.8
imbus		12MC15	inner bearing dust conar	L-1603	58	69N	.2
ippers		15X435 12MC118	" " inner dust collar screw " inner dust (felt) washer	X-525	58	70N	.1
itrate		12MC17	" in dust (felt) retin'a ring	L-1604	30	TOIN	.0
itrogen		12MC17	" " can	W-696	58	72N	1.5
asal		12MC119	" spindle washer	L-219	30	1214	.1
obody		12MCA46	Front Wheel Assembly (right) painted				27.4
oddle		12MCA47	" " (left) painted)				25.5
oggin		12MCA48	(right) primed)				24.0
omad		12MCA49	(left) primed				22.0
			FRONT AXLE BEARINGS		-		
		2X614	Knuckle bearing complete				\$5.10
		2X614A	" cone	3650	57	26N	3.3
		2X614B	cup	3620	57	27N	1.8
		2X613 2X613A	Hub inner bearing complete	410	57	76N	6.0
			" cone	419	31	1 OIN	3.9
			11 11 11 0000		50	67 N	2.0
		2X613B	cup	412	58	67N	5.10
					58	67N 79N	2.0 5.1 3.3

When possible, order through Thomas Dealer

GROUP 12—FRONT AXLE

SPRINGS


Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Sellin
			SPRINGS				
Pacific	TLi. La.	13MC411	Front Spring (right)		63	1P	\$17.50
Packet		13MC42	" (left)		63	2P	17.50
Paddle	PSR	13MC41	(right)		63	3P	17.50
Padlock		13M16 13MCA110	Front Spring Bolt Assembly				1.00
Pagan Pageant		13MC111	" " only				.60
Pagoda		13MC117	" " lubricator				.4
aint		13MC116	" " lock washer				.0.
		10X45	" " nut				
76			FRONT SPRING FITTINGS				
alace		13M112	Clip plate		63	10P	\$0.1
alate		13M14	Bumper				.6
		3X71 10X42	bolt				
alatine		13M129	" bolt nut Dowel				.0
alacine		13MC118	Spring seat (right) see shock absorber page 61		61	15P	1.5
		13MC119	" seat (left)				1.5
alfrey		13MX133	" clip		63	17P	.5
		10X711	" clip nut				
			REAR SPRINGS				
aling	T	13MCA44	Rear Spring (upper and lower-Right) with				
			Rear Spring (upper and lower-Right) with shackles and bolts in rear end				\$42.0
alisade	T	13MC21	Rear spring (upper-right)		63	21P	14.3
allet	T	13MC43 13MCA46	(lower-right)		63	22P	27.5
alliate	T	13MCA40	Rear Spring (upper and lower-Left) with shackles and bolts in rear end				42.0
almistry	T	13MC22	Rear spring (upper-left)		63	25P	14.3
alpable	Ť	13MC45	(lower-left)		63	26P	27.5
alsy		13MC33	Auxiliary Spring		63	27P	5.0
adlock		13M16	Rear Spring Shackle Rear Spring Rear Bolt Assembly				1.0
altry aludal		13MCA114 13MC115	Rear Spring Rear Bolt Assembly only				.6
agoda		13MC117	Spring bolt lubricator				.4
aint		13MC116	" ' lock washer				.0
		10X45	" " nut				
amper		13MCA112	Rear Spring Front Bolt Assembly				1.1
amphlet	~	13MC113 13MC117	Spring bolt lubricator				.4
agoda aint		13MC116	" lock washer				.0
aint		10X45	" " nut				
			REAR SPRING FITTINGS				
anada		13M121	Clip plate		63	35P	\$0.2
andect		13M13	Bumper				.5
andect		3X71	" bolt				
		10X42	" bolt nut				
alatine		13M129	Dowel			38P	1.7
ander		13MC24 13MC25	Rear spring seat (right)		61	38P	1.7
anel anic		13MC127	" (left)		63	40P	.6
AIIIC		10X711	" " clip nut				
	1	F.7					
			REAR SPRING UPPER ATTACH'G PARTS				0-
annel		13M18	Rear spring block (wood)				\$0.1
anoply		13M110 13M19	" gib (malleable) " wedge (aluminum)				.1
anorama		15X48	" " wedge (aluminum)				
ansy		13M131	Fender iron and spring hanger bolt				.2
antheon		16MC115	Rear spring bolt spacer (used without trunk				.0
anthe-		13MX141	rack) Rear spring rear hanger holt (long)				.0
anther		10X13	Rear spring rear hanger bolt (long) Bolt nut				
alliate	P	13MCA46	Rear Spring (upper and lower-Right) with		200720.0	Z.	
			shackles and bolts in rear end				42.0
almistry	P	13MC22	Rear spring (upper-right) " (lower-right)				14.3 27.5
alpable	P P	13MC45 13MCA47	Pear Spring (upper and lower-Left) with				27.5
aper	P	13MCA47	Rear Spring (upper and lower-Left) with shackles and bolts in rear end				42.0
	P	13MC23	Rear spring (upper-left)				14.3
apoose	P	13MC48	Rear spring (upper-left) " (lower-left)				27.5
			Note—All other parts same as for touring				
arable	CD	12350145	Car.				
apoose arable aper	SR	13MCA47	Rear Spring (upper and lower-Right) with				42.0
arable	SR SR	13MCA47 13MC23	car. Rear Spring (upper and lower-Right) with shackles and bolts in rear end Rear spring (upper-right) " " (lower-right)				42.0 13.3

When ordering parts use Code Word

GROUP 13—SPRINGS

GROUP 13—SPRINGS

		1	SPRINGS				
Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Selling Price
			REAR SPRING UPPER ATTACHING PARTS—Continued				
Parasite	SR	13MCA415	Rear Spring (upper and lower-Left) with shackles and bolts in rear end				
			shackles and bolts in rear end				\$42.00
Parboil	SR	13MC416	Rear spring (upper-left)				13.30
Parch	SR	13MC417	" (lower-left)				27.50
Parade	Li. La.	13MCA412	Rear Spring (upper and lower-Right) with				
			shackles and bolts in rear end				45.00
Paradise	Li. La.	13MC413	Rear spring (upper-right)				15.30
Paradox	Li. La.	13MC414	" (lower-right)				28.50
			Note-All other parts same as for touring				
			car.				
Paragon	Li. La.	13MCA418	Rear Spring (upper and lower-Left) with				
			shackles and bolts in rear end				45.00
Parallel	Li. La.	13MC210	Rear spring (upper-left)				15.30
Parapet	Li. La.	13MC419	" (lower-left)				28.50
			Note—All parts same as for touring car.				
			SHOCK ABSORBERS				
Pardon		13MCA31	Front Shock Absorber, Right, with stude and				
uluon		10112 01101	spring seats				\$11.25
Paregoric		13MCA35	Front Shock Absorber, Left, with stude and				Филлио
urogorio		10112 01100	spring seats				11.25
Parent		13MC129	Center arm	A-101	61	50P	1.50
Parget		13MC130	Outer arm	A-102	61	51P	1.25
Pariah		13MC131	Spider spring	A-103	61	52P	70
Parity		13MC132	" stop washer	A-104			.10
Parley		13MC133	Brass cover	A-105			.50
Parlor		13MC134	" lock key	A-106			.10
Parody		13MC135	Center friction disc cup washer	A-107			.30
Parrot		13MC136	" friction washer	A-108			.25
Parslev		13MC137	" stud	A-109			1.00
Parson		13MC138	" adjusting nut	A-110	61	54P	.40
Partake		13MC139	" stud bushing	A-111	01	341	.35
Partial		13MC140	" stud pushing	A-112			.05
Parting		13MC140	Adjusting dial	A-112 A-113			.50
Parting		13MC141 13MC142		A-113 A-114			.25
rartiner		131110142	Indicator	M-114			.23



When possible, order through Thomas Dealer

GROUP 13—SPRINGS

SPRINGS


Passage	Foreign Symbol	Illus- trated on Page	No. on Plate	Selling Price
Passim				
Passim	A-116			\$ 0.1
Pedicel 13MCA36 Pedicel 13MCA37 Pedicel 13MCA36 Pedicel 13MCA37 Pedicel 13MCA36 Pedicel 13MCA37 Pedicel 13MCA36 Pedicel 13MCA37 Pedicel 13MCA36 Pedicel 13MCA36 Period Rear Shock Absorber, Left, less upper 1 reackets and lower stud brackets and lower stud brackets and lower stud brackets and lower stud Penguin 13MCA215 Pennate 13MCA216 Pennate 13MCA215 Pennate 13MCA216 Pen	A-117			.1
Pastime 13MC146 "reinforcing washer asture 13MC148 "reinforcing pin Pasture 13MC148 "bearing (outside arm) "stud bushing Patrol 13MC122 Stud (front-lower) Patrol 13MC126 "(front-upper) Patrol 13MC126 "unt "washer Patrol 13MC126 "unt "washer Patrol 13MC135 "int "i	A-119			.4
Pedicel 13MCA36 Pedicel 13MCA37 Pedicel 13MCA36 Perent 13MCA37 Pedicel 13MCA37 Perent 13MCA37 Perent 13MCA37 Pene	A-120		2005	.1
Takent 13MC148 " bearing (outside arm)	A-121			
Pedicel 13MCA25 Pedicel 13MCA25 Pedicel 13MCA36 Pedicel 13MCA37 Pedican 13MCA37 Pedican 13MCA37 Pedican 13MCA38 Pedican 13MCA37 Pedican 13MCA38 Pedican 13MCA38 Pendant 13MCA216 Pennane 13MCA215 Pennane 13MCA215 Pennane 13MCA215 Pennane 13MCA215 Pennane 13MCA215 Pennane 13MCA215 Peace 13MCA26 Peace 1	# A-122			.4
Paunch Paunch Paunch Paunch Peace Pagace 13MC125 Pebble Peccary 13MCA155 Peccary 13MCA156 Peccary 13MCA156 Peccary 13MCA168 Peccary 13MCA18 13MC118 Pedant 13MCA32 Pedicel 13MCA36 Pequate Pequate Pequate 13MCA36 Pequate Pequate 13MCA36 Pequate Pequate Pequate 13MCA37 Pelican Pendant Parget 13MCA38 Pence Parget 13MCA39 Pence 13MCA30 Pence 13MCA30 Pence 13MCA30 Pence 13MCA30 Pence 13MCA31 Pence 13MCA31 Pence 13MCA32 Pence 13MCA32 Pence 13MCA34 Pence 13MCA35 Pence 13MCA36 Pence 13MCA215 Pence 13MCA216 Pe	A-124			.3
Peace 13MC126 Poearl 13MC125 Pebble 13MCA155 Peccary 13MCA155 Peccary 13MCA156 Peccary 13MCA156 Peccary 13MCA16 Peccary 13MCA16 Peccary 13MCA16 Peccary 13MCA36 Peccary 13MCA36 Perevish 13MCA36 Pegasus 13MCA37 Pelican 13MCA37 Pelican 13MCA37 Penent 13MC129 Parget 13MC130 Penenat 13MC124 Penguin 13MC124 Penguin 13MC124 Pennate 13MCA215 Pennate 13MCA215 Pennate 13MCA215 Pennate 13MCA216 Pennate 13MCA216 Pennate 13MCA216 Penecary 1 Perevision Service		61	60P	.4
Peace 13MC126 Poearl 13MC125 Pebble 13MCA155 Peccary 13MCA155 Peccary 13MCA156 Peccary 13MCA156 Peccary 13MCA16 Peccary 13MCA16 Peccary 13MCA16 Peccary 13MCA36 Peccary 13MCA36 Perevish 13MCA36 Pegasus 13MCA37 Pelican 13MCA37 Pelican 13MCA37 Penent 13MC129 Parget 13MC130 Penenat 13MC124 Penguin 13MC124 Penguin 13MC124 Pennate 13MCA215 Pennate 13MCA215 Pennate 13MCA215 Pennate 13MCA216 Pennate 13MCA216 Pennate 13MCA216 Penecary 1 Perevision Service		61	61P	
Peeble 13MCA156 Peecary 13MCA156 Peedant 13MCA26 Pedicel 13MCA36 Peesish 13MCA36 Peesish 13MCA36 Peesish 13MCA37 Pelican 13MCA37 Pelican 13MCA37 Perent 13MCA37 Perent 13MCA37 Penend 13MCA38 Penend 13MCA215 Pennan 13MCA215 Pennan 13MCA215 Penend 13MCA216 Penend 1	A-118			.2
				.1
				2.0
Dedical 13MCA36 Dedical 13MCA36 Deevish 13MCA36 Delican 13MCA37 Delican 13MCA37 Delican 13MCA38 Derivity 13MCA38 Delican 13MCA39 Delican 13MCA216 Delican 13MCA215 Delican 13MCA215 Delican 13MCA216 Delican			1000	2.0
Pedant 13MCA12 Pedicel 13MCA32 Peevish 13MCA34 Pegasus 13MCA35 Pelican 13MCA38 Parent 13MC129 Parent 13MC129 Parent 13MC123 Pendant 13MC123 Pendant 13MC123 Pendant 13MC124 Penguin 13MC124 Pennan 13MCA215 Pennan 13MCA215 Pennan 13MCA215 Pennate 13MCA216 Pendant 13MCA216 Pennate 13MCA216 Pensikin Penatric (L) with stud		61	15P	1.5
bedicel 13MCA36 Peevish 13MCA34 Pegasus 13MCA37 Pelican 13MCA37 Pelican 13MCA37 Perent 13MC130 Penere 13MC130 Penere 13MC130 Penere 13MC124 Penguin 13MC124 Pennant 13MCA215 Pennant 13MCA216 Pennant 13MCA216 Pennant 13MCA216 Pennant 13MCA216 Pennant 13MCA216 Pennant 13MCA216 Pennant Pennate Penna	***************************************		1	1.5
bedicel 13MCA36 Peevish 13MCA34 Pegasus 13MCA37 Pelican 13MCA37 Pelican 13MCA38 Perant 13MCA39 Perant 13MC129 Perant 13MC130 Pendant 13MC124 Penguin 13MC124 Penguin 13MCA215 Pennane 13MCA215 Pennane 13MCA215 Pennane 13MCA215 Pennane 13MCA216 Penside Perant Pe	and	7500		-
Peevish 13MCA34 Pegasus 13MCA37 Pelican 13MCA38 Parent 13MC129 Parget 13MC123 Pendant 13MC124 Penguin 13MC124 Penguin 13MC2125 Pennant 13MCA215 Pennate 13MCA215 Pennate 13MCA216 Pears Shock Absorber, Right, less upper Rear Shock Absorber, Left, less upper Packet Pear Shock Absorber, Right, less upper Packet Pac				12.0
Peevish 13MCA34 Pegasus 13MCA37 Pelican 13MCA38 Parent 13MC129 Parget 13MC123 Pendant 13MC124 Pendant 13MC124 Penguin 13MC2120 Penman 13MCA215 Pennate 13MCA215 Pennate 13MCA216 Pennate 13MCA215 Pennate 13MCA216 Pennate Penate Pena	s and	77000		
Peevish 213MCA34 Pegasus 13MCA37 Pelican 13MCA38 Perican 13MCA38 Parent 13MC129 Parget 13MC130 Pence 13MC124 Penguin 13MC124 Penguin 13MC124 Penman 13MCA215 Pennan 13MCA215 Pennan 13MCA215 Pennan 13MCA216 Pennan				12.0
Pegasus 13MCA37 Pelican 13MCA38 Rear Shock Absorber, Left, less upper learner lamC129 Parent 13MC129 Pendent 13MC123 Pendant 13MC124 Penguin 13MC120 Penman 13MCA215 Pennate 13MCA215 Pennate 13MCA216	bkts.			11.3
Pelican 13MCA28 Parent 13MC129 Pareet 13MC123 Pence 13MC123 Pendant 13MC124 Penguin 13MC124 Penman 13MCA215 Pennate 13MCA215 Pennate 13MCA216 Pennate Penna				11.3
Parent 13MC129 Brackets and lower stud Rear shock absorber (center arm) Parget 13MC130 " upper stud Pendant 13MC120 " upper stud Penguin 13MC120 " upper bracket Penguin 13MC120 " upper bracket Penguin 13MC120 " upper bracket " upper stud	less			
Parent 13MC129 Rear shock absorber (center arm)	Maria Maria			9.1
Parget 13MC130 " (outer arm) Pence 13MC123 " upper stud Pendant 13MC124 lower stud Penguin 13MC120 " upper bracket Penman 13MCA215 " spring seat (R) with stud Pennate 13MCA216 " (L) with stud	A-101	61	50P	1.5
Pence 13MC123 "upper stud Pendant 13MC124 "lower stud Penguin 13MC120 "upper bracket Penman 13MCA215 spring seat (R) with stud Pennate 13MCA216 " " (L) with stud	A-102	61	51P	1.2
Pendant 13MC124 "lower stud Penguin 13MC120 "upper bracket Penman 13MCA215 "spring seat (R) with stud Pennate 13MCA216 " "(L) with stud		61	65P	.4
Penguin 13MC120 " upper bracket Penman 13MCA215 " spring seat (R) with stud Penguin 13MCA216 " (L) with stud		61	66P	.4
Penman 13MCA215 "spring seat (R) with stude "(L) with stude "(L) with stude "		61	68P	.5
Pennate 13MCA216 " " (L) with stud				2.2
				2.2
		61	38P	
13MC25 " " (L)				
Pensile 13MC29 " axle strap		-	-	1.8

FRAME

Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No.	Selling
Word	Dody			Dymoor	tra	Plate	11100
			FRAME ASSEMBLY				
abbet	TP	14MCA41	Frame Assembly				\$134.0
accoon	TP	14MC42	Side rail, right with hangers and gussets		63	1R	35.0
aceme	TP	14MC43	" left with hangers and gussets		63	2R	35.
acket	TPS	14M33	Transmission front cross member		63	3R	4.
adial	TPS	14MC310	" rear cross member		63	4R	4.
adiant	TPS	14MC115	" cross member plate (front)				
adical	TPS	14MC116	" cross member plate (rear)				
adish	TPS	14MC34	Rear center cross member		63	7R	3.
adius	TPS	14M36	" cross member		63	8R	1
adix	TPS	14MC419	" spring rear hanger (right)				4.
affle	TPS	14MC420	" spring rear hanger (left)				4.
afters	TPS	14MC212	Rebound strap bracket		63	11R	2.
agout	TPS	14M32	Rear Spring Front Bracket (Right) with cap		63	12R	2.
ailing	TPS	14M31	" " (left) with cap		63	14R	2.
	TPS	10M1127	" " cap				
	TPS	14X36	" cap screw				
ainbow	TPS	14MC213	Front Spring Front Bracket (Right)				2.
aise	TPS	14MC214	" " (left)				2.
aisin	TPS	14M28	Front Spring Rear Hanger (Right)				1.
ally	TPS	14M21	" " (left)				1.
amble	TPS	14MC210	Radiator Bracket (right)				3.
amify	TPS	14MC211	" (left)		63	23R	3.
	TPS	4MO124	" cap				
	TPS	14X322	" cap screw				
			Note — See page 25 for radiator hanger bushings and washers.				
ancho	TP	14MCA219	Running Board Front Bkt. with reinforcement		63	25R	1.
	TP	14MC119	Reinforcement		-	2020	
andom	SR	14MCA221	Running board front bracket assembly				1.
ankle	TPSR	14MCA220	" rear bkt, with reinforcement		63	26R	î.
	TPSR	14MC117	Reinforcement		30	2310	-
	TPSR	14MC120	A COMMON				

When ordering parts use Code Word

GROUP 13—SPRINGS GROUP 14—FRAME



When possible, order through Thomas Dealer GROUP 14—FRAME

FRAME

Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Selling Price
			FRAME ASSEMBLY—Continued				
Raphe	TPSR	14MCA215	Frame Stiffener Tube Assembly				\$ 3.50
Rapid	TPSR	14MX14	Stiffener tube		63	31R	1.0
Rapier	TPS	14MX213	" tube bracket (right)			OTTE	.7
Rappee	TPS	14MX214	" tube bracket (left)				.7
Rapport	TPS	14MC12	Starting crank bracket		63	34R	1.0
Rarefy	After 1st	15MC356	Lamp Bracket (front-right) (Not included in)		00		2.5
Rascal	30 cars	15MC357	" (front-left) frame assembly.		3.5.5.5		2.5
Ratchet	TPS	11M221	Torque Tube Buffer Bracket		63	40R	1.2
Rather	TPS	15M180	Windshield Brace Bracket		63	41R	.1
Ratify	TPS	14MC417	Dust Pan ledge (right)		00	****	1.0
Ratio	TPS	14MC418	" " (left)		63	43R	1.0
Ration	TP	10MC189	Internal Brake Relief Spring Bracket		00	4310	.4
Penguin	TP	13MC120	Shock Absorber Bracket, Rear		61	68R	.5
Ratoon	TP	15MC336	Fender Ledge (right) with leather		01	0020	1.2
Rasbane	TP	15MC337	" (left) with leather				1.2
Casbane	11	15X47	" " holt				1.2
		10X33	" " bolt nut				
Rattle							
		15M120 15M179	leather				.1
Raucous	CD.		" angle				.0
Ravage	SR	15MC3125	Fender Ledge (right) with leather				1.2
Ravel	SR	15MC3126	" (left) with leather				1.2
		15X47	bolt				
		10X33	bolt nut				
Rattle		15M120	leatner				.1
Ravine	SR	14MCA412	Frame Assembly			~~~	130.0
		14MC48	Side rail, right with hangers and gussets				
		14MC49	" left with hangers and gussets				
Readopt	SR	10MC191	Internal Brake Relief Spring Bracket				.4
Readorn		14MC311	Drive Shaft and Torque Tube Loop				2.0
		14X34	Loop bolt				
		10X41	" nut				

BODY—TOURING CAR

Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Selling Price
			BODY				
abbath	T	15MCA4115	Body fully equipped				\$750.0
aber		15MC344	Front seat cushion (right)				15.7
able		15MC391	" (left)		7000		15.3
achem		15MC348	Rear " "				24.0
adiron		15MC3193	Foredoor, with upholster and paint				50.0
affron	T	15MC347	" with hinges, less upholster or paint				30.0
agacious	*	15MC1326	" hinge (upper)				1.
aint		15MC1327	" hinge (lower)				2.
alacious		15MC3194	Rear Door (right) with upholster and paint				50.
Salad		15MC3194 15MC354					30.0
			" (right) less upholster or paint				50.
alary		15MC3195	" (left) with upholster and paint				
alaratus		15MC392	(left) less uphoister or paint		50.75		30.
alic		15MC1328	ninge (upper-right)				1.
alient		15MC1329	ninge (upper-leit)				1.
alify		15MC1330	ninge (lower-right)				2.
aliva		15MC1331	" " hinge (lower-left)				2.
		15MC1332	Door Lever with lock				
almon		15MC1333	" " handle No. 385				
altant		15MC1334	" " guide with plate				
alutary	220222	15MC1336	" lock No. 4 (right and foredoor) with lever				1.
alute		15MC1337	" lock No. 4 (left) with lever			55.55	1.
alvage		15MC1338	" buffers (right and foredoor)				
alver		15MC1339	" buffers (left)				
alvo	T	15MC175	Front Top Iron				
amphire	Ť	15MC169	Center top iron				
	TPS						1.
ample	TPS	15MCA3170 15MCA3171	Bow separator assembly (R)				1.
anctify	IPS		Bow separator assembly (L)				
anctore		15MCA1388	Separator clamp with spring				
andacker	TP	15MC170	Top iron retainer pin (stud)				
andacus	TP	15MC179	nut				
andberg	TP	15MC178	" cap screw				
anguine	TPS	15MC1156	Threshold Plate (front)				1.0
anitary	TPS	15MC1157	" (rear-right)				1.0
Sancrit	TPS	15MC1158	" (rear-left)				1.0

When ordering parts use Code Word

GROUP 14—FRAME GROUP 15—BODY—TOURING CAR


Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Sellin Price
			BODY—Continued				
Sapid	T	15MC372	Auxiliary Seat (right) less body bracket				\$ 25.0
Sapient	T T T T	15MC385	" (left) less body bracket				25.0
Sapphire Sarcastic	T	15MC355 15MC222	bracket (on body)				1.8
Sarcenet	Ť	15MC247	" post (right) " post (left)				1.3
Sardonyx	T	15MC1115	Tonneau Cocoa Mat				7.5
Satchel	TS	15M140 3X41	Body Frame Angle				.1
		17X31	" screw				
		3X22	" bolt 5 x 3 ½				
Satinet	TP	3X210 15MC1223	" bolt 16 x 4 Brake lever floor plate				
Saunei	IF	17X24	" screw				
Satire	TPS	15MCA249	Robe Rail Assembly, give upholstering				7.7
Saturn		15MC1100	Rail bracket (right) " " (left)				
Satyr		15MC1101 15X35	French head screw				
Sauce	TP	15MCA3168	Foot Rest Assembly				7.
Saunter		15MCA3172	" less end support brackets				6.
Savage		15MC1252 17X24	Board moulding "moulding screw"				
Savanna		15M133	" end support				
Saviour		15M132	" center support				
Savor		15X21 15MC1251	" mat				
Saying		15M134	" end support brackets				
		14X316	Bracket cap screw				
		10X412 15X419	" cap nut " machine screw			2222	
	*****	10X35	" machine screw nut				
			COWL				
Scabbard	Т	15MCA4116	Cowl, Switch Board and Dash Assembly				\$100.0
	Ť	15MC49	Cowl with ventilators				54.0
Scaffold		15MC231 15MC232	Ventilator door (right)				3.
Scald Scale		15MC232 15MC233	" frame (right)				.8
Scallop		15MC234	" frame (left)				.7
Scalpel		15MC172 15MC173	" latch " latch knob				.0
Scamp Scamper		15MC173	" latch spring				doz.
Scandal		15MC171	" hinge pin				.(
Scarify	TPS TPS	15MC327	Cowl Dashboard Accelerator bracket dash plate				1.7
Scarlet Scathe	IPS	15MC1124 15MC217	Side lamp bracket (left)				1.2
Scatter		15MC371	" and horn bracket (right)				1.7
			SWITCH BOARD				
Schedule		15MCA3128	Switch Board Assembly (with all fittings)				\$46.0
Schism		15MC1174	Board right upper stay angle				.2
		15MC1175	" left upper stay angle				.2
Schist			Lower stay angle				
Schist Scholar		15MC1176 17X17	Lower stay angle				.1
Schist Scholar		17X17 15MC133	Lower stay angle Stay angle screw Steering post plate				
Schist Scholar Jilac		17X17 15MC133 17X211	Lower stay angle Stay angle screw Steering post plate "screw"				1.0
Schist Scholar Lilac School		17X17 15MC133 17X211 16MC140 17X24	Lower stay angle Stay angle screw Steering post plate Screw Patent plate Screw				
Schist Scholar Lilac School Scripture		17X17 15MC133 17X211 16MC140 17X24 2MCA220	Lower stay angle Stay angle screw Steering post plate Screw Patent plate Screw Hand Air Pump Assembly		66	10S	1.7
Schist Scholar Lilac School Scripture		17X17 15MC133 17X211 16MC140 17X24 2MCA220 2MC186	Lower stay angle Stay angle screw Steering post plate Screw Patent plate Hand Air Pump Assembly elbow		66	10S	1.7
Schist Scholar Lilac School Scripture Scofula		17X17 15MC133 17X211 16MC140 17X24 2MCA220 2MC186 5X14 2MC184	Lower stay angle Stay angle screw Steering post plate Screw Patent plate Screw Hand Air Pump Assembly elbow " " elbow connection		66	10S	1.7
Schist Scholar Lilac School Scripture Srofula		17X17 15MC133 17X211 16MC140 17X24 2MCA220 2MC186 5X14 2MC184 17X212	Lower stay angle Stay angle screw Steering post plate "screw Patent plate "screw Hand Air Pump Assembly "elbow connection Pump rod plate or bushing "screw"		66	10S	1.7
Schist Scholar Lilac School Scripture Srofula		17X17 15MC133 17X211 16MC140 17X24 2MCA220 2MC186 5X14 2MC184 17X212 2MC1102	Lower stay angle Stay angle screw Steering post plate Screw Patent plate Screw Hand Air Pump Assembly Blow connection Pump rod plate or bushing Screw Screw Libow connection Pump rod plate or bushing Screw Libow Screw Libow Screw Screw Libow Connection Pump rod plate or bushing Screw Libow Connection Libow Spring		66	10S	1.7
Schist Scholar School Scripture Scroll Scrub		17X17 15MC133 17X211 16MC140 17X24 2MCA220 2MC186 5X14 2MC184 17X212 2MC1102 17X34 2MC168	Lower stay angle Stay angle screw Steering post plate Screw Patent plate Screw Hand Air Pump Assembly Blow connection Pump rod plate or bushing Screw Screw Screw Screw Screw		66	10S	1.5
Schist Scholar Lilac School Scripture Srofula Scruple Scruple Scruple		17X17 15MC133 17X211 16MC140 17X24 2MCA220 2MC186 5X14 2MC184 17X212 2MC1102 17X34 2MC168 2MC168 2MC171	Lower stay angle Stay angle screw Steering post plate Screw Patent plate Screw Hand Air Pump Assembly Blow connection Pump rod plate or bushing Screw Screw Screw Screw Screw Screw Fundament of the state of the sta		66	10S	1.5
Schist Scholar School Scripture Scroll Scrub Scruple Scruple Scull		17X17 15MC133 17X211 16MC140 17X24 2MCA220 2MC186 5X14 2MC184 17X212 2MC1102 17X34 2MC168 2MC171 2MC169	Lower stay angle Stay angle screw Steering post plate Screw Patent plate Screw Hand Air Pump Assembly Screw Slow elbow connection Pump rod plate or bushing Screw		66	10S	1.5
Schist Scholar Lilac School Scripture Srofula Scrub Scrub Scrub Scruple Scuffle Scullery		17X17 15MC133 17X211 16MC140 17X24 2MCA220 2MC186 5X14 2MC184 17X212 2MC1102 17X34 2MC168 2MC168 2MC169 2MC170 2MC170 2MC170	Lower stay angle Stay angle screw Steering post plate Screw Patent plate Screw Hand Air Pump Assembly Blow connection Pump rod plate or bushing Composite the screw Co	4	66	10S	1.5
Schist Scholar Lilac School Scripture Scrotll Scrub Scruple Scuffle Scull Scullery Scupper Scuff		17X17 15MC133 17X211 16MC140 17X24 2MC220 2MC186 5X14 17X212 2MC1184 17X212 2MC1102 17X34 2MC1102 17X34 2MC168 2MC171 2MC169 2MC170 2MC170 2MC177 2MC173	Lower stay angle Stay angle screw Steering post plate """ screw Patent plate """ screw Hand Air Pump Assembly """ elbow """ elbow connection Pump rod plate or bushing """ screw """ screw "" screw """ screw """ screw """ screw """ rock spring """ bracket """ cylinder head (upper) """ cylinder head (lower) """ rod handle	<u> </u>	66	10S	1.7
Schist Scholar Lilac School Scripture Srofula Scroll Scruple Scuffle Sculll Scullery Scupper Scurf Scurry Scurry		17X17 15MC133 17X211 16MC140 17X24 2MCA220 2MC186 5X14 2MC184 17X212 2MC1102 17X34 2MC171 2MC170 2MC170 2MC170 2MC171 2MC170 2MC170 2MC170	Lower stay angle Stay angle screw Steering post plate Screw Patent plate Screw Hand Air Pump Assembly Blow connection Pump rod plate or bushing Composite to	<u> </u>	66	108	1.5
Schist Scholar Lilac School Scripture Scrofula Scruple Scruple Scull Scullery Scull Sculper Scurf Scurry Scuttle Scythe		17X17 15MC133 17X211 16MC140 17X24 2MCA220 2MC186 5X14 2MC184 17X212 2MC1102 17X34 2MC1102 17X34 2MC171 2MC170 2MC170 2MC170 2MC172 2MC173 2MC173 2MC174 2MC1174 2MC1175	Lower stay angle Stay angle screw Steering post plate Screw Patent plate Screw Hand Air Pump Assembly Blow connection Pump rod plate or bushing Composition of the plate of the		66	10S	1.7 .1 .4 .4 .4 .4 .2 .2 .2 .0 .0
Schist Scholar Scholar Scholar Scripture Scrotll Scrub Scrub Scrub Scrub Scrull Scull Scullery Scullery Scurt Scurt Scurt Scurt Schute Scythe		17X17 15MC133 17X211 16MC140 17X24 2MCA220 2MC186 5X14 17X212 2MC1102 17X34 2MC170 2MC170 2MC170 2MC170 2MC170 2MC171 2MC172 2MC171 2MC172 2MC173 2MC174 2MC175 2MC175	Lower stay angle Stay angle screw Steering post plate "" screw Patent plate "" elbow "" elbow connection Pump rod plate or bushing "" screw " screw " screw " buck spring " screw " in screw " screw " in scr		66	108	1.5 .1 .1 .4 .4 .4 .4 .2 .2 .0 .0
Schist Scholar School Scripture Scripture Scrotl Scruple Scruple Scull Scullery Scutper Scury Scuttle Scythe Seamc		17X17 15MC133 17X211 16MC140 17X24 2MCA220 2MC186 5X14 2MC184 17X212 2MC1102 17X34 2MC168 2MC171 2MC170 2MC170 2MC170 2MC170 2MC170 2MC170 2MC170 2MC173 2MC173 2MC174 2MC1175 2MC175 2MC177 2MC177 2MC177 2MC177 2MC177	Lower stay angle Stay angle screw Steering post plate "Screw Patent plate "Screw Hand Air Pump Assembly "Blow connection Pump rod plate or bushing "Blow connection "Blow conn		66	108	1.7 .1 .4 .4 .4 .4 .2 .2 .2 .0 .0
Schist Scholar Scholar Scholar Scripture Scrotll Scrub Scrub Scrub Scrub Scrull Scull Scullery Scullery Scurt Scurt Scurt Scurt Schute Scythe		17X17 15MC133 17X211 16MC140 17X24 2MCA220 2MC186 5X14 17X212 2MC1102 17X34 2MC170 2MC170 2MC170 2MC170 2MC170 2MC171 2MC172 2MC171 2MC172 2MC173 2MC174 2MC175 2MC175	Lower stay angle Stay angle screw Steering post plate "screw Patent plate "screw Hand Air Pump Assembly "elbow connection Pump rod plate or bushing "screw "lock spring "screw "lock spring "screw "producer bracket "producer bracket "producer bracket "rod handle "rod handle "rod collar "rod collar "rod collar "rod collar "rod collar "rod collar "" washer (lupper) "" leather "" leather		66	108	1.1

When possible, order through Thomas Dealer

GROUP 15—BODY—TOURING CAR

The second second second						
DOD		OI	DIN		CA	D
BOD	I - I	U	KIIN	CT.	4/1	IX.

Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Selling Price
			SWITCH BOARD—Continued				
Secant		2MCA161	Air Gauge Assembly		66	15S	\$2.90
		5X17	" solderless bushing			100	42.50
		5X14	Connection or nut				
		17X39	Air gauge screw				
		******	Note—See junction box for tubing.				
Secede		6MCA150	Oil Sight Feed Assembly		66	20S	3.00
Second		6MC146	Body with drip ell		00	200	1.25
Secret		6M3C153	Inlet ell				.25
Secret		*5X14	" " connection				.23
		6MC151	Outlet ell				20
Section							.30
		5X16	" " connection				
Secular		6MC147	Body cover				.65
Secure		6MC148	glass				.10
Sedan		6MC142	wasner			-	.05
		17X21	attaching screw				
Sedative		15MCA388	Switch Board Junction Box Assembly		66	25S	5.50
Sedge		15MC235	Junction box only				4.50
Sedition		15MC183	" " check valve complete				.15
		23X514	Coupling nipple (small)				
		23X516	(large)				
		5X14	" connection (small)				
		5X16	" connection (large)	1 25000000000000000000000000000000000000	No.		
		17X16	Box attaching screw				



When ordering parts use Code Word-GROUP 15—BODY—TOURING CAR

BODY—TOURING CAR

Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Sellir Price
			SWITCH BOARD—Continued				
			Tubes in Upper Side of Junction Box		1776		
					12.5		
educe	T PSR	2MC1110	Tube from gas hand air pump		66	30S	\$0.05
edulous	TPSR	2MC1111 2MC219	" from gas hand air pump " to gas tank pressure gauge		66	31S	.05
eemly	T	6MC149	" to gas tank pressure gauge " from oil hand air pump		66	32S	.0.
eesaw	PSR	6MC159 6MC160	" from oil hand air pump				.0.
eethe egment	T PSR	6MC160 6MC161	to ou tank pressure gauge		66	35S	.1
eigntor	T	6MC164	" to oil tank pressure gauge " from sight feed gauge		66	37S	.2
eine	PSR	6MC165	" from sight feed gauge		-22-	200	.2
eldom elect	T	6MC162 6MC163	" to sight feed gauge to sight feed gauge		66	39S	.1
ciect	ron	UNICIOS	Tubes Connected to Lower Side of				
elective		2MC1104	Junction Box Tube from mechanical air pump		66	45S	\$0.2
electman		2MC1103	" to gasoline tank		66	46S	.4
electos		6MC154	" to oil tank		66	47S	.3
elencio elenit		6MC158 6MC155	" to crank case " from mechanical oil pump		66	48S 49S	.1
elvage		15MC197	Lower Tube Clamp		66	50S	.3
		3X26	Clamp bolt				
		10X415	" " nut				
			Push Button Switches				
emblance		15MCA180	Battery cutout switch		28	55S	\$0.7
emaphore		15MCA181	Magneto cutout switch		28	56S	.7
		17X111	Cutout switch screw	*******			
			SWITCH WIRES				
		26X11 26X24	Reckard cable, 76 in. long No. 24-10 Strand cotton covered lamp cord,				
			38 in. INDICATOR BUTTON				
emibreve		15MCA1404	Indicator Button (bat.) with fer. and washer				\$0.5
emicolon		15MCA1403	" (mag) with fer, and washer				.5
eminary emivowel		15MCA1402	(gas) with fer, and washer				.5
enary		15MCA1401 15MCA1400	" (oil) with fer. and washer (off) with fer. and washer				.5
enate		15MCA1399	" (on) with fer. and washer				.5
enile		15MC182 15MC199	" ferrule " ferrule washer				.1
		15X319	Switch board attaching screw				
		21X42	Screw washer				
ensual	T	15MC1204 17X112	Switch board finish moulding				.1
		1/A112	Moulding screw				
entenca	TPR	15MCA3140	FLOOR BOARD				\$8.5
enticar	IPK	15MC1198	Floor Board Assembly mat				.7
entilho		15MC1194	Board brass angle				1.2
enuah	TPSR	17X14 15MX1194	Angle screw				.3
uail	IFSR	17X21	Board plate Plate screw				.31
enuelo	TPSR	15MC1131	Cutout cable floor board plate				.13
eoir		17X22 15M165	Plate screw				.6.
OII		17X27	Floor board handle				.0.
	1000		TOE BOARD				
eorsos	TPR	15MCA3144					\$5.85
epaline	TER	15MC1199	Toe Board Assembly (upper)		1730		35.8
epan		15MC1200	Board moulding (angle)			96	.60
epedon epelio		15MC1201 15MC1202	" moulding (strip) filler block				.05
epicole		15MC1140	Speedometer bracket				.30
		17X211	" screw				
ovable		10MX1285	tube plate				.25
		17X22 15M11	Toe board pedal plate				.25
PDIOS		10MX1285					.25
epios ovable		15X32	Accelerator plate Toe board screw "" washer				
epios ovable		21V41					
ovable	TPR	21X41	Toe Board Assembly (lower)				4 00
epios ovable epolto	TPR	21X41 15MCA3143 15MC1197	Toe Board Assembly (lower)				4.90
ovable	TPR	21X41 15MCA3143	Toe Board Assembly (lower)				4.90

When possible, order through Thomas Dealer

GROUP 15—BODY—TOURING CAR

BODY—TOURING CAR

Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Selli
			TOE BOARD—Continued				
Septenal Septenos		15MC120 15MC119	Accelerator foot rest block Rest plate				\$0.1
			RUNNING BOARD	100			
eptet	TP	15MCA445	Running Board Assembly (right)				\$6.7
eptica epticum		15MCA455 15MC378	" " (right)				1.9
eptifore		15MC379	" (left)				1.9
eptimo eptipes	TPS	15MC242 45MC193	Moulding (front)				
eptisch	TPS TP	15MC156 15MC1105	" (rear-upper)				
eptorie eptuncis	TP	15MC1106	" (inside-front-right) " (inside-front-left)				
epulcres		15MC162 15MC190 15MC191	" (outside)				
epultar	TPS	15MC190	" (inside-rear-right)				
equelle	TPS	17X22	" (inside-rear-left) " screw				
equence	TPSR	15MC195	" corner (square)				dz
equester equillo	TPS	15MC1151 15MC1166	" (obtuse) left				:
		15X428	" screw				200
equoia erado	TPSR TPSR	15MC1178 15MC1113			7		
erado eraglio	TPSR		Fender bracket (front-right) " (front-left)				
		3X52 10X41	" bolt				
erail	TPS	15MC1117	" (rear-lower-right)				
eraph	TPS	15MC1118	" (rear-lower-left)	Lauren			.:
	TPS	14X29 10X41	Running board bolt				
erapiao	TPSR	15M214	" tire bracket				1.5
erasker	TPSR TPR	15M142 15MF41	" tire bracket strap				1.3
erata erbare	TPR	15MF41 15MF42	Front tire bracket Rear tire bracket				1.7
			RUNNING BOARD APRONS				
erbava	TP.	15MCA463	Apron Assembly (right) with brake lever (left) housing				\$7.2
erbocal erieta		15MCA464 15MX252	(left) housing				6.1
eriole		15MCA1165	Housing guard plate Housing Guard Door Assembly				
eriphi		K-11314	Guard door handle				
erious erlio		15MC1203 K-11315	Handle washer "spring				.1
eroja	******	15MC1110	Guard door hinge				.2
			HOOD				
extile		15MCA4111	Hood Assembly				\$36.0
nallow		15M17 15X47	Hood handle				.5
		10X33	" " screw nut				
ampoo		15MA0147 15MO146	Hood Lock Assembly spring retainer				.9
ank		15M1106	" lock				.3
nanty		15MO13 15X47	" lock spring				.0
		LUMIT	Attaching screw				
	mp		FENDERS				
nare	TP Li. La.	15MCA3175	Front fender (right) with iron and paint				\$13.0
1	TP	15MCA3176					13.0
narp	Li. La.		(lert)	7			13.0
		15X415 10X35	" " screw nut				
atter		15MC448	" iron (right) " iron (left)				2.6
awl		15MC449 3X52					2.6
		10X51	" iron bolt " iron bolt nut				
		16X25	Front fender iron screw				
ear	TPS	10X27 15M141	Top strap eye bolt			-4	2
eath		15MC1188	Front fender iron filler (rear)				.0
eave		15MC268 15MC1239	" " (front)				.1
een		15MC1239 14X414	Fender apron clip				.0
	m	10X35	" screw nut				
iekel ielf	T	15MCA3181 15MCA3182	Rear Fender (right) with iron and paint				12.0
ell	Ť	15MCA3182 15MC431	" (left) with iron and paint " iron (right) " " iron (left)				12.0
elter	Ť	15MC432	" " iron (left)				1.7

When ordering parts use Code Word

GROUP 15-BODY-TOURING CAR

BODY—TOURING CAR

Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Selling Price
			FENDERS—Continued				
Sherbet	T	15MC1111					\$0.35
Sherry	T	15MC1111 15MC1112	Rear fender angle iron (right) " angle iron (left)				.35
onciry		14X33					100
		15X414	\$\frac{8}{6} - 18 \times \frac{3}{2} \text{ cap screw}\$ \$\text{No. } 1032 \times \frac{1}{2} \text{ screw}\$ \$\text{No. } 10-32 \text{ screw}\$ \$\text{No. } 1424 \times \frac{3}{2} \text{ screw}\$				
		10X35	No. 10—32 screw nut				
		15X45	No. 14—24 x ¾ screw No. 14—24 screw nut				
		10X41 15X47	Machine screw				
		10X33	Nut				
		10235	1144				
			DUST PAN				
Shield		15MCA477	Dust Pan Assembly				\$16.50
Shimmer		15MA186	" " lock assembly				.35
Shindy		15MCA149	" valve assembly (Old Style)		+		2.30
hock		15MCA1348	Valve assembly (New Style) Dust Pan Lock Assembly " lock				1.25
himmer hire		15MA186 15M114	" " lock Assembly				.35
hirt		15M113	" ' lock " lock spring				.05
hindy		15MCA149	Dust Pan Valve Assembly (Old Style)				2.30
hiver		15MCA149 15MC213	11 11 11 cost 11 11				1.00
hoal		15MC150	" " with gasket " "				.85
hoddy		15MC151	gasket				.05
hoot		15MC128	Stem			4464	.15
hore hould		15MC130 15MC129	" " lever " " spring " "				.05
iouiu		10X11	Nut spring " "				.00
hock		15MCA1348	Duct Dan Valve Assembly (New Style)				1.25
hortage		15MC1350	" " with gasket " "				.25
		15MC1351	gasket				
		15X49	Screw				
horten		15MC1349	vaive seat				.20
horthand hortness		15MC1354 15MC1352	" spring " "				.30
houlder		15MC1353	" lever pin " "				.05
hout		15MC496	Dust Shield				3.25
		15X48	" screw				
		10X33	" screw nut				
			WINDSHIELD				
	-						1
hower	T	15MCA491	Windshield Assembly (fitted) Windshield Assembly, less filler board		1113		\$58.50
							50.00
	T	15MCA4123			2277		
hrew	T	15MCA4123 15MC287 15MC1322	Filler board				10
hrew	T	15MC287 15MC1322	Filler board				.10
hrew hrift ickle	T	15MC287 15MC1322 15MC1258 15MC1280	Filler board "screw 4 dia. x 10" tube Side frame tube bumpers				.10 .45 .05
hrew hrift ickle	T	15MC287 15MC1322 15MC1258 15MC1280 15MC1159	Filler board "screw 4 dia. x 10" tube Side frame tube bumpers				.10 .45 .05
hrew hrift ickle idelong idereal	T	15MC287 15MC1322 15MC1258 15MC1280 15MC1159 15MC1274	Filler board screw 34 dia. x 10" tube Side frame tube bumpers Windshield to cowl filler strip Lower corner brace				.10 .45 .05 .10
hrew hrift ickle idelong idereal iege	T	15MC287 15MC1322 15MC1258 15MC1280 15MC1159- 15MC1274 15MC1299	Filler board screw 34 dia. x 10" tube Side frame tube bumpers Windshield to cowl filler strip Lower corner brace				.10 .45 .05 .10 1.20
hrew hrift ickle idelong idereal iege ienna	T	15MC287 15MC1322 15MC1258 15MC1280 15MC1159 15MC1274 15MC1279 15MC1278	Filler board screw 34 dia. x 10" tube Side frame tube bumpers Windshield to cowl filler strip Lower corner brace hinge block (R) hinge block (L)				.10 .45 .05 .10 1.20 .50
hrew hrift ickle idelong idereal iege ienna iesta	T	15MC287 15MC1322 15MC1258 15MC1280 15MC1159 15MC1274 15MC1279 15MC1278	Filler board screw 34 dla, x 10" tube Side frame tube bumpers Windshield to cowl filler strip Lower corner brace hinge block (R) hinge block (L) Upper hinge block (R)				.10 .45 .05 .10 1.20 .50
hrew hrift ickle idelong idereal iege ienna iesta ieve	T	15MC287 15MC1222 15MC1258 15MC1280 15MC1274 15MC1274 15MC1279 15MC1278 15MC1278	Filler board screw 34 dla, x 10" tube Side frame tube bumpers Windshield to cowl filler strip Lower corner brace hinge block (R) hinge block (L) Upper hinge block (R)				.10 .45 .05 .10 1.20 .50 .50
hrew hrift ickle idelong idereal iege ienna iesta ieve ifting	T	15MC287 15MC1322 15MC1258 15MC1258 15MC1280 15MC1274 15MC1279 15MC1278 15MC1278 15MC1298 15MC1277 15MC1263 15MC1271	Filler board screw 34 dla, x 10" tube Side frame tube bumpers Windshield to cowl filler strip Lower corner brace hinge block (R) hinge block (L) Upper hinge block (R)				.10 .45 .05 .10 1.20 .50 .50 .50
hrew hrift ickle idelong idereal eege eenna eesta eeve ffting ight	T	15MC287 15MC1322 15MC1258 15MC1280 15MC1159- 15MC1274 15MC1279 15MC1278 15MC1278 15MC1263 15MC1263 15MC1263 15MC1271	Filler board " " screw 34 dia. x 10" tube Side frame tube bumpers Windshield to cowl filler strip Lower corner brace " hinge block (R) " hinge block (L) Upper hinge block (R) " hinge block (L) Lower hinge tube joint (R) " hinge tube joint (L) Screw No. 6 x ¾				.10 .45 .05 .10 1.20 .50 .50 .50
hrew hrift ickle idelong idereal iege ienna iesta ieve ifting ight	T	15MC287 15MC1322 15MC1258 15MC1258 15MC1159 15MC1174 15MC1279 15MC1278 15MC1278 15MC1278 15MC1277 15MC1263 15MC1271 17X222 15MC1279	Filler board " " screw 44 dia. x 10" tube Side frame tube bumpers Windshield to cowl filler strip Lower corner brace " hinge block (R) " hinge block (L) Upper hinge block (L) Lower hinge tube joint (R) " hinge tube joint (L) Screw No. 6 x ¼ Hinge tube stud				.10 .45 .05 .10 1.20 .50 .50 .50 .90
hrew hrift ckle delong dereal iege enna iesta ieve ffting ight	T	15MC287 15MC1322 15MC1258 15MC1280 15MC1159 15MC1274 15MC1278 15MC1278 15MC1277 15MC1263 15MC1271 17X222 15MC1271 17X222 15MC1279	Filler board " " screw 34 dla. x 10" tube Side frame tube bumpers Windshield to cowl filler strip Lower corner brace " hinge block (R) " hinge block (L) Upper hinge block (R) " hinge block (L) Lower hinge tube joint (R) " hinge tube joint (L) Screw No. 6 x ½ Hinge tube stud Stud screw " Strew when the stud Stud screw				.10 .45 .05 .10 1.20 .50 .50 .50 .90
hrew hrift ckle delong dereal iege enna iesta ieve ffting ight	T	15MC287 15MC1322 15MC1258 15MC1280 15MC1159- 15MC1274 15MC1279 15MC1278 15MC1277 15MC1263 15MC1277 15MC1263 15MC1271 17X222 15MC1279 15X440	Filler board " " screw 34 dia, x 10" tube Side frame tube bumpers Windshield to cowl filler strip Lower corner brace " hinge block (R) " hinge block (L) Upper hinge block (R) " hinge block (L) Lower hinge tube joint (R) " hinge tube joint (L) Screw No. 6 x ¾ Hinge tube stud Stud screw Hinge tube (about 8 in, long)				.10 .45 .05 .10 1.20 .50 .50 .50 .90
hrew hrift ickle idelong idereal iege ienna iesta ieve ifting ight	T	15MC287 15MC1322 15MC1258 15MC1280 15MC1159- 15MC1274 15MC1279 15MC1278 15MC1277 15MC1263 15MC1277 15MC1263 15MC1271 17X222 15MC1279 15X440	Filler board " " screw 34 dla, x 10" tube Side frame tube bumpers Windshield to cowl filler strip Lower corner brace " hinge block (R) " hinge block (L) Upper hinge block (R) Lower hinge tube joint (R) " hinge tube joint (L) Screw No. 6 x ¾ Hinge tube stud Stud screw Hinge tube (about 8 in. long) Tube plug				.10 .45 .05 .10 .50 .50 .50 .90 .90
hrew hrift ickle idelong idereal iege ienna iesta ieve igtifting ight ignal ignet	T	15MC287 15MC1322 15MC1280 15MC1280 15MC1274 15MC1294 15MC1274 15MC1298 15MC1278 15MC1278 15MC1271 15MC1263 15MC1271 15MC1263 15MC1271 15MC1263 15MC1270 15MC1270 15MC1270 15MC1270 15MC1270 15MC1270	Filler board " " screw 34 dia. x 10" tube Side frame tube bumpers Windshield to cowl filler strip Lower corner brace " hinge block (R) " hinge block (L) Upper hinge block (L) Lower hinge tube joint (R) " hinge tube joint (L) Screw No. 6 x ½ Hinge tube stud Stud screw Hinge tube (about 8 in. long) Tube plug Upper hinge tube joint Lower cross tube (½ dia. x 48 in.)				.10 .45 .05 .10 1.20 .50 .50 .50 .90 .90
hrew hrift ickle ddelong ddereal ieege ienna iesta ieve ifting ight ignal ignet illy illy illyrian	TPS	15MC287 15MC1322 15MC1258 15MC1280 15MC1274 15MC1274 15MC1279 15MC1278 15MC1278 15MC1277 15MC1271 17X222 15MC1271 17X222 15MC1270 15MC1270 15MC1270 15MC1270 15MC1270 15MC1270 15MC1270 15MC1270 15MC1270 15MC1270 15MC1270	Filler board " " screw ½ dia, x 10" tube Side frame tube bumpers Windshield to cowl filler strip Lower corner brace " hinge block (R) " hinge block (L) Upper hinge block (L) Lower hinge block (L) Lower binge block (L) Lower hinge tube joint (R) " hinge tube joint (L) Screw No. 6 x ½ Hinge tube stud Stud screw Hinge tube (about 8 in. long) Tube plug Upper hinge tube joint Lower cross tube (½ dia, x 48 in.) " glass shoe				.10 .45 .05 .10 1.20 .50 .50 .50 .50 .90 .90
hrew hrift ckle delong dereal eege eenna eesta eeve fting ght gnal gnal ignet	TPS	15MC287 15MC1322 15MC1280 15MC1280 15MC1274 15MC1299 15MC1274 15MC1298 15MC1278 15MC1278 15MC1271 15MC1263 15MC1271 15MC1263 15MC1271 15MC1263 15MC1270 15MC1263 15MC1270 15MC1263 15MC1270 15MC1263 15MC1270 15MC1263 15MC1270 15MC1270 15MC1270 15MC1270 15MC1270 15MC1270 15MC1270 15MC1270 15MC1270	Filler board " screw 4 dia. x 10" tube Side frame tube bumpers Windshield to cowl filler strip Lower corner brace " hinge block (R) " hinge block (L) Upper hinge block (L) Lower hinge tube joint (R) " hinge tube joint (R) " hinge tube joint (L) Screw No. 6 x ¾ Hinge tube stud Stud screw Hinge tube (about 8 in. long) Tube plug Upper hinge tube joint Lower cross tube (¾ dia. x 48 in.) " glass side shoe (13 in.)				.10 .45 .05 .10 .50 .50 .50 .50 .50 .50 .50 .50 .50 .5
hrew hrift ickle idelong idereal iege ienna iesta ieve ifting ight ignal ignet idex illy ilurian ilvan	TPS	15MC1287 15MC1322 15MC1280 15MC1280 15MC1279 15MC1279 15MC1279 15MC1278 15MC1278 15MC1278 15MC1271 15MC1270 15MC1270 15MC1270 15MC120 15MC120 15MC120 15MC120 15MC120 15MC120 15MC120 15MC120 15MC120 15MC120 15MC120 15MC120 15MC1270	Filler board " screw 4 dia. x 10" tube Side frame tube bumpers Windshield to cowl filler strip Lower corner brace " hinge block (R) " hinge block (L) Upper hinge block (L) Lower hinge tube joint (R) " hinge tube joint (R) " hinge tube joint (L) Screw No. 6 x ¾ Hinge tube stud Stud screw Hinge tube (about 8 in. long) Tube plug Upper hinge tube joint Lower cross tube (¾ dia. x 48 in.) " glass side shoe (13 in.)				.10 .45 .05 .10 1.20 .50 .50 .50 .90 .90 .40
hrew hrift lckle ddelong ddereal iege eenna iesta leve ignal ignal ignet llex illy durian illyan	TPS	15MC287 15MC1322 15MC1280 15MC1280 15MC1159 15MC1274 15MC1294 15MC1278 15MC1278 15MC1278 15MC1278 15MC1278 15MC1279 15MC1263 15MC1271 15MC1263 15MC1270 15MC1263 15MC1270 15MC1264 15MC1270 15MC	Filler board " screw 4 dia. x 10" tube Side frame tube bumpers Windshield to cowl filler strip Lower corner brace " hinge block (R) " hinge block (L) Upper hinge block (L) Lower hinge tube joint (R) " hinge tube joint (L) Screw No. 6 x ½ Hinge tube stud Stud screw Hinge tube (about 8 in. long) Tube plug Upper hinge tube joint Lower coss tube (½ dia. x 48 in.) " glass side shoe (13 in.) " glass upper shoe Lower Glass				.10 .45 .05 .10 .50 .50 .50 .90 .90 .40 .70 1.50
hrew hrift lckle ddelong ddereal iege eenna iesta leve ignal ignal ignet llex illy durian illyan	TPS	15MC287 15MC1322 15MC1258 15MC1280 15MC1280 15MC1159 15MC1274 15MC1298 15MC1278 15MC1278 15MC1277 15MC1271 17X222 15MC1271 15MC1270 15MC12	Filler board " " screw 34 dia. x 10" tube Side frame tube bumpers Windshield to cowl filler strip Lower corner brace " hinge block (R) hinge tube joint (R) " hinge tube joint (L) Screw No. 6 x ¾ Hinge tube stud Stud screw Hinge tube (about 8 in. long) Tube plug Upper hinge tube joint Lower cross tube (¾ dia. x 48 in.) " glass shoe " glass shoe " glass shoe Use of the strip shoe Lower Glass Upper frame tube				.10 .45 .05 .10 .50 .50 .50 .90 .90 .40 .70 1.50
hrew hrift ickle idelong idereal iege iege ienna iesta	TPS	15MC287 15MC1322 15MC1258 15MC1280 15MC1280 15MC1159 15MC1274 15MC1298 15MC1278 15MC1278 15MC1277 15MC1271 17X222 15MC1271 15MC1270 15MC12	Filler board " " screw 34 dia. x 10" tube Side frame tube bumpers Windshield to cowl filler strip Lower corner brace " hinge block (R) " hinge block (L) Upper hinge block (L) Lower hinge block (L) Lower hinge block (L) Lower hinge tube joint (R) " hinge tube joint (L) Screw No. 6 x ¾ Hinge tube stud Stud screw Hinge tube (about 8 in. long) Tube plug Upper hinge tube joint Lower cross tube (¾ dia. x 48 in.) " glass side shoe (13 in.) " glass side shoe (13 in.) " glass Upper frame tube " tube plug				.10 .45 .05 .50 .50 .50 .50 .90 .90 .90 .40 .1.50 .30 .50
hrew hrift ickle idelong idereal idereal iege ienna iesta ie	TPS	15MC287 15MC1322 15MC1280 15MC1280 15MC1159- 15MC1274 15MC1290 15MC1278 15MC1278 15MC1278 15MC1278 15MC1271 15MC1263 15MC1271 15MC1263 15MC1270 15MC12	Filler board " " screw 34 dla. x 10" tube Side frame tube bumpers Windshield to cowl filler strip Lower corner brace " hinge block (R) " hinge block (L) Upper hinge block (L) Lower hinge tube joint (R) " hinge tube joint (L) Screw No. 6 x ¾ Hinge tube stud Stud screw Hinge tube (about 8 in. long) Tube plug Upper hinge tube joint Lower cross tube (¾ dia. x 48 in.) " glass side shoe (13 in.) " glass side shoe (13 in.) " glass upper shoe Lower Glass Upper frame tube " tube plug " frame inner joint Screw No. 6 x ¾ " glass " glass " glass side shoe (13 in.) " glass side shoe (13 in.) " glass side shoe (15 in.)				.10 .45 .05 .50 .50 .50 .50 .90 .90 .90 .1.50 .30 .50 .50 .50 .50 .50 .50 .50 .50 .50 .5
hrew hrift ickle idelong idereal idereal iege ienna iesta ie	TPS	15MC287 15MC1322 15MC1280 15MC1280 15MC1280 15MC1274 15MC1279 15MC1279 15MC1278 15MC1278 15MC1271 15MC1273 15MC1271 15MC1263 15MC1271 15MC1263 15MC1271 15MC1263 15MC1270 15MC1270 15MC1270 15MC1270 15MC1270 15MC1270 15MC1270 15MC1270 15MC1270 15MC1270 15MC1270 15MC1270 15MC1270 15MC1271 15MC1272 15MC1272 15MC1272 15MC1272 15MC1272 15MC1272 15MC1272 15MC1272 15MC1272 15MC1272 15MC1272	Filler board " " screw 3/4 dia, x 10" tube Side frame tube bumpers Windshield to cowl filler strip Lower corner brace " hinge block (R) " hinge block (L) Upper hinge block (L) Lower hinge block (L) Lower hinge block (L) Lower hinge tube joint (L) Screw No. 6 x ½ Hinge tube stud Stud screw Hinge tube (about 8 in. long) Tube plug Upper hinge tube joint Lower cross tube (½ dia, x 48 in.) " glass shoe " glass side shoe (13 in.) " glass upper shoe Lower Glass Upper frame tube " tube plug " frame inner joint Screw No. 6 x ¾ Upper frame tube " tube plug " frame inner joint Screw No. 6 x ¾ Upper frame tube " frame inner joint Screw No. 6 x ¾ Upper frame tube " frame inner joint Screw No. 6 x ¾ Upper frame tube " frame inner joint Screw No. 6 x ¾ Upper frame inner joint stud				.10 .45 .05 .50 .50 .50 .50 .90 .90 .90 .1.50 .30 .50 .50 .50 .50 .50 .50 .50 .50 .50 .5
hrew hrift ickle idelong idereal idereal iege ienna iesta ieve ifting ignal ignal ilius il	TPS	15MC287 15MC1322 15MC1280 15MC1280 15MC1159 15MC1274 15MC1294 15MC1278 15MC1278 15MC1278 15MC1278 15MC1271 15MC1263 15MC1271 15MC1263 15MC1271 15MC1260 15MC127	Filler board " " screw 34 dia. x 10" tube Side frame tube bumpers Windshield to cowl filler strip Lower corner brace " hinge block (R) hinge block (L) Upper hinge block (L) Lower hinge tube joint (R) " hinge tube joint (R) Screw No. 6 x ¾ Hinge tube joint (L) Screw No. 6 x ¾ Hinge tube stud Stud screw Hinge tube (about 8 in. long) Tube plug Upper hinge tube joint Lower cross tube (¾ dia. x 48 in.) " glass side " glass side shoe (13 in.) " glass side shoe (13 in.) " glass upper shoe Lower Glass Upper frame tube " tube plug " frame inner joint Screw No. 6 x ¾ Upper frame joint stud " " " screw " screw				.100 .455 .050 .500 .500 .500 .900 .400 .700 1.500 1.500 2.000
hrew hrift ickle ickle idelong idereal iege ienna iesta ieve iffting ight ignal iilex iilly ilurian ilivan ilivar immer immony	TPS TPS T TTPS	15MC287 15MC1322 15MC1280 15MC1280 15MC1299 15MC1274 15MC1299 15MC1278 15MC1278 15MC1278 15MC1273 15MC1273 15MC1271 17X222 15MC1270 15MC1270 15MC1270 15MC1270 15MC1270 15MC1270 15MC1270 15MC1270 15MC1270 15MC1272 15MC1283 15MC1283 15MC1283 15MC1272 15MC1283 15MC1273 15MC1281	Filler board " " screw ½ dia. x 10" tube Side frame tube bumpers Windshield to cowl filler strip Lower corner brace " hinge block (R) " hinge block (L) Upper hinge block (L) Lower hinge tube joint (R) " hinge tube joint (L) Screw No. 6 x ½ Hinge tube stud Stud screw Hinge tube (about 8 in. long) Tube plug Upper hinge tube (joint Lower cross tube (¾ dia. x 48 in.) " glass side shoe (13 in.) " glass upper shoe Lower Glass Upper frame tube tube plug Trame inner joint Screw No. 6 x ¾ Upper frame joint stud Lower Glass Upper frame tube Screw No. 6 x ¾ Upper frame joint stud Lower Glass L				.10 .45 .05 .10 1.20 .50 .50 .90 .90 .30 .1.50 .30 .50 .50 .90 .90 .90 .1.50 .50 .50 .90 .90 .90 .90 .90 .90 .90 .90 .90 .9
hrew hrift ickle idelong idereal idereal iege ienna iesta ieve ifting ignal ignal ility il	TPS TPS TPS	15MC287 15MC1322 15MC1280 15MC1280 15MC1159 15MC1274 15MC1293 15MC1278 15MC1278 15MC1278 15MC1277 15MC1271 15MC1271 15MC1271 15MC1271 15MC1270 15MC127	Filler board " " screw ½ dia. x 10" tube Side frame tube bumpers Windshield to cowl filler strip Lower corner brace " hinge block (R) " hinge block (L) Upper hinge block (L) Lower hinge tube joint (R) " hinge tube joint (L) Screw No. 6 x ½ Hinge tube stud Stud screw Hinge tube (about 8 in. long) Tube plug Upper hinge tube (joint Lower cross tube (¾ dia. x 48 in.) " glass side shoe (13 in.) " glass upper shoe Lower Glass Upper frame tube tube plug Trame inner joint Screw No. 6 x ¾ Upper frame joint stud Lower Glass Upper frame tube Screw No. 6 x ¾ Upper frame joint stud Lower Glass L				.10 .45 .05 .10 1.20 .50 .50 .50 .90 .90 .90 .150 .30 .50 .30 .50 .50 .90 .90 .90 .90 .90 .90 .90 .90 .90 .9
hrew hrift ickle idelong idereal idereal iege ienna iesta iesta iesta iesta iesta iesta iesta iithing ighal ignal iignal iignal iilur iilur iilur iilur iiman iilver iimilar iimmer iimony iimoom iimoom	TPS TPS TPS TPS TPS TPS TPS	15MC287 15MC1322 15MC1280 15MC1280 15MC1280 15MC1274 15MC1299 15MC1278 15MC1278 15MC1277 15MC1277 15MC1279 15MC1271 17X222 15MC1270 15MC1271 15MC1281 15MC1281 15MC1281	Filler board " " screw ½ dia. x 10" tube Side frame tube bumpers Windshield to cowl filler strip Lower corner brace " hinge block (R) " hinge block (L) Upper hinge block (L) Lower hinge tube joint (R) " hinge tube joint (L) Screw No. 6 x ½ Hinge tube stud Stud screw Hinge tube (about 8 in. long) Tube plug Upper hinge tube (joint Lower cross tube (¾ dia. x 48 in.) " glass side shoe (13 in.) " glass upper shoe Lower Glass Upper frame tube tube plug Trame inner joint Screw No. 6 x ¾ Upper frame joint stud Lower Glass Upper frame tube Screw No. 6 x ¾ Upper frame joint stud Lower Glass L				.10 .45 .05 .10 1.20 .50 .50 .50 .90 .90 .90 .150 .30 .50 .30 .50 .50 .90 .90 .90 .90 .90 .90 .90 .90 .90 .9
hrew hrift ickle idelong idereal idereal iege ienna iesta ieve ifting ignal ignal illex illvan ilvan ilvan ilvan immer immony imoom imper imple	TPS	15MC287 15MC1322 15MC1280 15MC1280 15MC1280 15MC1274 15MC1299 15MC1278 15MC1278 15MC1277 15MC1277 15MC1279 15MC1271 17X222 15MC1270 15MC1271 15MC1281 15MC1281 15MC1281	Filler board " " screw 34 dia. x 10" tube Side frame tube bumpers Windshield to cowl filler strip Lower corner brace " hinge block (R) " hinge block (L) Upper hinge block (L) Lower hinge block (L) Lower hinge tube joint (R) " hinge tube joint (L) Screw No. 6 x 34 Hinge tube stud Stud screw Hinge tube dabout 8 in. long) Tube plug Upper hinge tube joint Lower cross tube (34 dia. x 48 in.) " glass shoe " glass side shoe (13 in.) " glass side shoe (13 in.) " glass side shoe (13 in.) " glass supper shoe Lower Glass Upper frame tube " tube plug " frame inner joint Screw No. 6 x 34 Upper frame joint stud " " screw Hand Adjusting Screw Upper glass upper shoe " glass lower shoe " Upper Glass				.10 .45 .05 .10 .50 .50 .50 .50 .50 .50 .50 .50 .50 .5
hrew hritt hirit h	TPS	15MC287 15MC1322 15MC1280 15MC1280 15MC1280 15MC1274 15MC1299 15MC1278 15MC1278 15MC1278 15MC1273 15MC1273 15MC1273 15MC1270 15MC1271 15MC127	Filler board " screw 34 dia. x 10" tube Side frame tube bumpers Windshield to cowl filler strip Lower corner brace " hinge block (R) " hinge block (L) Upper hinge block (L) Lower hinge tube joint (R) hinge tube joint (L) Screw No. 6 x ¾ Hinge tube joint (L) Screw No. 6 x ¾ Hinge tube stud Stud screw Hinge tube (about 8 in. long) Tube plug Upper hinge tube joint Lower cross tube (¾ dia. x 48 in.) " glass shoe " glass side shoe (13 in.) " glass side shoe (13 in.) " glass upper shoe Lower Glass Upper frame tube " tube plug " frame inner joint Screw No. 6 x ¾ Upper frame type glass upper shoe Hand Adjusting Screw Upper Glass Upper Glass Upper Glass upper shoe " " " screw Hand Adjusting Screw Upper Glass lower shoe Upper Glass combits " " " Screw No. 6 x ¾ Upper glass upper shoe " glass lower shoe Upper Glass " " " " " Screw Them two joint " " " " " Screw Them two joint " " " " " Screw Them two joint " " " " " Screw Them two joint " " " " " Screw Them two joint " " " " " Screw Them two joint " " " " " Screw Them two joint " " " " " " Screw Them two joint " " " " " " " " " " " " " " " " " " "				1101 1202
thred threw thrift ickle ickle idelong idereal iege ienna iesta ieve ignal ignat ilturian il	TPS	15MC287 15MC1322 15MC1280 15MC1280 15MC1290 15MC1274 15MC1293 15MC1278 15MC1293 15MC1273 15MC1293 15MC1271 15MC1291 15MC1291 15MC1201 15MC1270 15MC127	Filler board " screw 34 dia. x 10" tube Side frame tube bumpers Windshield to cowl filler strip Lower corner brace " hinge block (R) " hinge block (L) Upper hinge block (L) Lower hinge tube joint (R) hinge tube joint (L) Screw No. 6 x ¾ Hinge tube joint (L) Screw No. 6 x ¾ Hinge tube stud Stud screw Hinge tube (about 8 in. long) Tube plug Upper hinge tube joint Lower cross tube (¾ dia. x 48 in.) " glass shoe " glass side shoe (13 in.) " glass side shoe (13 in.) " glass upper shoe Lower Glass Upper frame tube " tube plug " frame inner joint Screw No. 6 x ¾ Upper frame type glass upper shoe Hand Adjusting Screw Upper Glass Upper Glass Upper Glass upper shoe " " " screw Hand Adjusting Screw Upper Glass lower shoe Upper Glass combits " " " Screw No. 6 x ¾ Upper glass upper shoe " glass lower shoe Upper Glass " " " " " Screw Them two joint " " " " " Screw Them two joint " " " " " Screw Them two joint " " " " " Screw Them two joint " " " " " Screw Them two joint " " " " " Screw Them two joint " " " " " Screw Them two joint " " " " " " Screw Them two joint " " " " " " " " " " " " " " " " " " "				1101 1102
hrew hrift ickle ickle idelong idereal iege ienna iesta ieve iffing ignal ignal ignat illex illy illurian illver immlar immer immony imoom imper imple imulate	TPS	15MC287 15MC1322 15MC1280 15MC1280 15MC1280 15MC1274 15MC1299 15MC1278 15MC1278 15MC1278 15MC1273 15MC1273 15MC1273 15MC1270 15MC1271 15MC127	Filler board " " screw 4 dia. x 10" tube Side frame tube bumpers Windshield to cowl filler strip Lower corner brace " hinge block (R) " hinge block (L) Upper hinge block (L) Lower hinge tube joint (R) " hinge tube joint (L) Screw No. 6 x ¼ Hinge tube stud Stud screw Hinge tube (about 8 in. long) Tube plug Upper hinge tube joint Lower cross tube (½ dia. x 48 in.) " glass shoe " glass side shoe (13 in.) " glass side shoe (13 in.) " glass side shoe (13 in.) " glass upper shoe Lower Class Upper frame tube " tube plug " screw Upper glass upper shoe Upper glass upper shoe " glass lower shoe Upper Glass " frame tube joint				.1014 .454 .455 .505 .505 .505 .505 .505 .50

When possible, order through Thomas Dealer

GROUP 15—BODY—TOURING CAR

BODY-TOURING CAR

Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Selling Price
Sinful Singe		15MC1290 15MC1288 14X343 10X425 21X217	WINDSHIELD—Continued Stay rod lower tube " " lower end " " end bolt " " end bolt nut " " end bolt washer				\$0.75
Single Sirloin Sirup Situate Skate Skunk Slack Slack Slack Slaye	T TPS TPS TPS TPSR TPSR TPSR T	15MC438 15MC152 17X25 24X11 17X27 15MCA251 15MC254 15MC270 15MC1245 15MC1245 15MC1246 15MC258	Top Complete Top strap snap eye Footman loop Screw Top strap assembly (rear) (front) Storm curtain (set) Top envelope with straps Prop nut (leather covered) Siip Covers (set)				\$150.0 .2 1.2 1.7 24.0 15.0 .0 .0 .75.0

BODY—PHAETON

Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Selling Price
-			BODY				
Sloop	P	15MCA4118	Body, fully equipped				\$700.0
Slothful		15MC399	Front Seat Cushion (right)	233351353			15.7
Slouch		15MC3100	" (left)				15.7
Sloven		15MC349	Rear seat cushion				24.0
Slums		15MC3196	Foredoor with upholster and paint				50.0
Slush	P	15MC3102	" less upholster and paint				30.0
Smack		15MC1341	ninge (upper)				1.7
Smart		15MC1342	ninge (lower)				2.1
Smartly		15MC3197	Rear Door (right) with upholster and paint		5		50.0
Smash		15MC3103	" (right) less upholster and paint				30.0
Smatter		15MC3198 15MC3104	" (left) with upholster and paint " (left) less upholster and paint				50.0
Smear Smelt		15MC3104 15MC1343	" " hinge (upper-right)				30.0
Smirk		15MC1343	" (upper-left)				1.3
Smith		15MC1345	" " (lower-right)				2.1
Smoke		15MC1346	" " (lower-left)				2.
Snipe		15MC167	Front Top Iron	2222222	2222		
Snivel		15MC198	Center top iron				
Sober	P	15MC1116	Tonneau Cocoa Mat				5.2
Sociable	PS	15MC411	Cowl with all fittings. Same as for tour car (Toe board lug changes for surrey)				54.0
			FENDER				
Socket	P	15MCA3183	Rear Fender (right) with irons and paint				\$ 12.0
Sodden	P	15MCA3184	" (left) with irons and paint				12.0
Soggy	PSR	15MC440	" iron (right)				1.7
Soiree	PR	15MC441	" iron (left) (See touring car for other parts.)				1.7
			WINDSHIELD				
Solace	PS	15MCA492	Windshield Assembly (fitted)				\$ 58.5
Solder	PS	15MCA4124	Windshield assembly less filler board				50.0
			TOP				
Solemn	P	15MC439	Top complete		1		\$140.0
Sooth		15MC271	Top envelope				14.0
Soprano		15MC255	Storm curtains				22.0
Sordes		15MC259	Slip Covers (set)				65.0
	1-200		TOOL BOX				
Corment	P	16MCA45	Rear tool box assembly				\$ 15.0
Tornado	P	16MC137	Box corner brace				.2
Torpedo	PR Li.	16MC138	" shim				.2
Corpor	P	16MC145	" strap				.1

When ordering parts use Code Word

GROUP 15—BODY—TOURING CAR BODY—PHAETON

BODY—PHAETON

Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Selling Price
			TRUNK RACK				
Torrefy Torrent	P	16MCA313 16MC148	Trunk Rack Assembly " arm (right)				\$ 15.00
Torrid Torsion	P PR	16MC149 15MC490	" (left) License tag bracket (stamping)				2.00

BODY—SURREY

Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Sellin Price
			BODY				
ound	S	15MCA4119	Body Fully Equipped				\$650.0
ource	0	15MC3109	Front seat cushion (R)				15.
outh		15MC3109 15MC3110 15MC350 15MC3199					15.
uvenir		15MC350	Rear seat cushion				24.
ace		15MC3199	Foredoor with upholster and paint				50.
ade are	S	15MC3111	" less upholster and paint Door strap				30.
arse		15MC3111 15MC1320 15MC3200	Rear Door (right) with upholster and paint				50.
ear		15MC3112	Rear Door (right) with upholster and paint " (right) less upholster and paint " "				30.
ecie		15MC3113	" (left) less upholster and paint				30.
ecify	S	15MC3201 15MC1120	(left) with uphoister and paint				50.
ider ike	5	15MC1120	Front Top Iron Center top iron				
ine		15MC1121	Rear bow separator iron				1.
irit	S	15MC1164	Rear bow separator iron Tonneau Cocoa Mat				4.
ite	S	15MC260	Slip Covers (set) Floor Board Assembly (front) " mat (cork)				65.
lice	S	15MCA3141	Floor Board Assembly (front)				4.
lit oke	9	15MC1192 15MC1193	Board moulding				
OKC		23X21	" dowel screw				1000
tan		15MC153	" lock				
		17X222	" lock screw				
			FLOOR BOARD				
	0	1535043150	Floor Board Assemble (see		-		00
onge	SSS	15MCA3159 15MC1243	Floor Board Assembly (rear) " mat (cork)				\$8.
ort	S	15MC1243	Board moulding				1.
		17X14	" moulding screw				
eadlery		2MC1115	Gasoline valve floor plate				
		17X222	" screw				
			TOE BOARD				
			m n 11 11				06
ouse	S	15MCA3142 15MC1242	Toe Board Assembly				\$6.
ree		15MC1242 15MC1195	" " mat " " moulding				
		17X14	" moulding screw				
ring		15MC1240	Board brass strip				
		17X21	" screw				
			RUNNING BOARD APRON				
ortful	S	15MC340	Running Board Apron (right)				\$5.
ortive	SSS	15MC341	Running Board Apron (right) " (left)				5.
rod	S	15MCA453	Running Board Assembly (R)		****		5.
ruce		15MCA454	" " (right)			20.	5.
ume unk		15MC364 15MC365	" (left)				1.
urn		15MC1153	" mat				
urt	SSS	15MC1154	Moulding (inner-right)				
utter	5	15MC1155	" (inner-left)				
uab	3	15MC164 17X22	" (outside) " screw 4 x 3/4				
		TIALL	FENDER				
11	CD	1535013105					£15
uall uander	SR SR	15MCA3185 15MCA3186	Front Fender (right) with iron and paint " (left) with iron and paint				\$15. 15.
uander	SR	15MC457	" iron (right)				2.
uash	SR	15MC458	" " (left)				2.
ueak	SR	15MC1190	" " filler (rear)				.0

When possible, order through Thomas Dealer

GROUP 15—BODY—PHAETON—SURREY

BODY—SURREY

Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Sellin
			FENDERContinued				
Squeeze	SR	15MC269	Front fender iron filler (front)				\$ 0.1
			See touring car for standard parts.				
Squint	S	15MCA3189 15MCA3190	Rear Fender (right) with irons and paint " (left) with irons and paint				13.0
Squirm Soggy	PSR	15MC440	" " iron (right)				1.3
Stable	S	15MC482	" iron (left)				4.0
Stack	SR	15MC1143	angle from (fromt-right)				
Stage	SR	15MC1144	" angle iron (front-left) See touring car for standard parts.				
7%	** 1		TIRE IRON				
Stagger	S	15MC480	Tire Iron (right)				\$6.
Stagnant		15MC481	" " (left)				6.
Staid		15MC3149	bracket (lower)				5.
		3X38 10X11	" bracket bolt Tire iron bracket bolt nut				
Stake		15MC3148	Tire Bracket (upper)				4.
Stalk		15MC1210	Tire iron hinge pin				
Stalwart		15MC3150	Tire Iron Reinforcement (R)				1.
Stammer		15MC3151 3X315	Bolt (L)				1.
		10X15	" nut				
Stampede		15MC1211	Tire Bracket Bolt				
Stanch		15MC1212	" screw bolt nut				:
Stand Stanza		15MC1213 15MC1208	" iron strap loop				
Staple		15MC1209	" iron strap loop pin				
Starboard		15MC274	" iron bracket strap (long)				1.
Stare		15MC275 17X51	" iron bracket strap (short) Bracket screw				1.
		17.51	TOP				
-				A COMPANY			
Startle	S	15MC443	Top Complete				\$130.
Spine Stead	S	15MC1121 15MC4103	Rear bow separator iron Top Envelope				1. 12.
Steak	S	15MC256	Storm Curtains (set)				20.
			TAIL LAMP				
Torsion	S	16MCA226	Tail Lamp Assembly				\$ 3.
Cortoise	S	15MC267	" bracket				1.
		3X224	" bracket bolt and nut				
	,		TOOL BOX				
Torture	S	16MCA414	Rear Tool Box Assembly				\$18.
Fotal		16MC175	" " hinge				
Totter		16MC229 16MC230	Cap board support				
Touch		16MC230 16MC319	Box corner brace " cap board				
Tough	S	15MC3152	License Tag Bracket				
-0-	The state of the state of	3X224	" bolt and nut				

BODY-RUNABOUT

Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Selling Price
			BODY				
Steam	R	15MCA4120	Body Fully Equipped				\$650.00
Stearine		15MC3123	" foredoor less upholster and paint				30.00
Steel		15MC3202 15MC3119	" foredoor with upholster and paint Seat cushion				50.00 24.00
Stern		151/103119	Seat cusnion				24.00
*			RUNNING BOARD				
Stevedore	R	15MCA450	Running Board Assembly (right)				\$4.00
Steward	R	15MCA456	" " (left)				4.00
Stick	R	15MC223	(right)				1.25
Stickle Stigma	R R	15MC224 15MC1132	(left)				1.25
Septipes	R	15MC1132	" mat " moulding (front and rear)				.35
Stile	R	15MC166	" moulding (front and rear)				.40

When ordering parts use Code Word

GROUP 15—BODY—SURREY—RUNABOUT

BODY—RUNABOUT

Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Selling Price
			RUNNING BOARD—Continued				
Stilts	R	15MC1137	Fender bracket (right-rear)				\$ 0.4
ting	R	15MC1138	" (left-rear)				.4
		14X29	Board bolt				
		10X41	" " nut				3
tingy	R	15MC225	Running Board Apron (right)				2.7
tipend	R	15MC226	(left)				2.7
		15X413	Screw 10-32 x 5/8 machine				
		17X35	" 4 x ½ wood				
			FENDER				
			Note—See surrey for front fenders.				
tipulate	R	15MCA3187	Rear Fender (right) with irons and paint				\$17.5
tirrup	R	15MCA3188	" (left) with irons and paint				17.5
oggy	PSR	15MC440	" iron (right)				1.7
oiree	PR	15MC441	tron (left)				1.7
itch	R	15MC1141	angle fron (K)				.3
tithy	R	15MC1142	angle from (L)				.3
		15350101	See touring car for standard parts.				
tock toical	R R	15MC494	Rear fender iron (front-right) " (front-left)				1.5
oicai	R	15MC495 14X37	Screw (Front-left)				1.5
		10X43	Screw nut				
		10243	WINDSHIELD				
ole	R	15MCA493	Windshield Assembly (fitted)				\$58.50
tone	R	15MCA4125	Windshield assembly, less filler board		2000	3100	50.0
-							-
			TOP				
cood	R	15MC451	Top Complete				\$110.0
orm		15MCA4109	Bow socket assembly (right)				3.7
out		15MCA4110	" " (left)				3.7
raight		15MC1248	Bow separator iron				1.50
ranger	R	15MCA297	Top bow separator (right)				1.2
rangle	R	15MC298	" (left)				1.25
rap		15MC4121	Top Envelope				10.50
ratum		15MC257	Storm Curtains (set)				16.00
raw	R	15MC261	Slip Covers (set) Rear Tool Box Assembly				40.00
race	K	16MCA48	All parts same as for phaeton.				15.00
rack		16MC131	All parts same as for phaeton.				4.25
rack		16M312	Tool Roll Only				3.50
lauc		10111312	All tools same as used on touring car.				3.50

BODY-LIMOUSINE

Code Word	Style of Body	Symbol Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Selling Price
Stress String Extreme Stroke Strophe Suasion Subdue Subjoin Sublimate	tring 15M237 17X219 Extreme 16MC37 trophe Li. 15MC461 sussion Li. La. 16MC224 subdue Li. La. 16MC225 subdue Li. La. 15MX254	Body (vestibule limousine) Berline type Pillar Handles Screw Lighting Battery 6V-40A box Body (foredoor limousine) with cab sides Pillar Lamp (right) " (left) " " bracket (right) " " (left) " " screw		28	151E	\$1.00 10.00 13.50 13.50 .60	
Sublime Submerge Submit Suborn	Li. La. Li. La. Li. La. Li. La.	15MCA3203 15MCA3204 15MX383 15M384	NOTE—See touring car for front fenders. Rear fender (right) with iron and paint (left) with iron and paint Rear Fender Iron (right) (left) TOOL BOX Rear Tool Box Assembly				\$12.00 12.00 1.90 1.90

When possible, order through Thomas Dealer

GROUP 15—BODY—RUNABOUT—LIMOUSINE

EQUIPMENT

Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Sellin
			LAMPS (Gas)				
	T	16350407					014
able ableau	1	16MCA27 16MCA212	Head lamp (right) " (left)				\$14
aboo		16MCA28	Side lamp (right)				5
acit		16MCA28 16MCA213	" (left)				5
ackle	TPR	16MCA29	Tail lamp				3
actics	On 1st	15MC23	Front lamp horn (inside)				1
action	30 cars	15MC24 15MCA176	" " (outside) Head Lamp Stay Rod Assembly				1
aupore		16X23	Rod end set screw				-
78							
	10.00		LAMP BRACKETS (Set)				
arefy		15MC356	Head lamp bracket (R)				\$2
ascal		15MC357 15MC371	Side large baselant (B)				2
catter cathe		15MC217	Side lamp bracket (R)				1
ailor	TP	15MC3146	Tail lamp bracket				î
			PREST-O-LITE TANK				
alent		16MA33	Prest-O-Lite Tank (Style B) Prest-O-Lite Tank Casing Assembly				\$25
allow		16MCA35	Prest-O-Lite Tank Casing Assembly				6
almud		16MC33 16MC34	Casing (front)				3
ambor amper		16MC34 16MC119	" (rear) " packing washer				3
andem		16MC116	" nad (front)				
angent		16MC117 16MC118	" (front)				
angle		16MC118	" (rear)				
ankard		16MCA23 3X215	Prest-O-Lite Tank Clamp Assembly				
		3X215 27X17	Clamp bolt Prest-O-Lite Tank Tubing (Brass) ⁵ / ₃₂ x No. 18				
			ga. x 126 in.				
		27X18	Tubing (brass) 1/4 x No. 20 BG x 44 in.				
aper		16M138 15X413	Tube clip				
		15X414	" " screw " screw				
		10X35	" " screw nut				
		28X14	" rubber hose				
apioca		16M136	" bushing with retainer				
xtol		16M137					,
ardy		16MCA320 16MC111	Prest-O-Lite Gas Regulating Valve Assembly				3
arget arry		16MC112	Regulator valve tee				
artar		16MC147	" tee gasket				
assel		16MC114	" stem				
attoo		16MC178	bracket				
avern awny		16MC16 16MC120	" connection cone				
awny		5X14	" solderless connection				
		14X311	Attaching screw				
		15X45	" "				
		10X33	" nut				
			HORN				
errier	/	16MCA18	Horn and Tube Assembly				\$9
erse		16MC233	Horn only				5
		16MC1109	" screen				
ertiary		16MC186	" reed " tube 42 in long				
estament		16MC187 16MC188	tube 42 m. long				1
ester		15X412	" bulb attaching bolt				1
		10X31	" attaching bolt nut				
		17X312	Bulb to body screw				
	m		TOOL BOX				
esty	TPS	16MCA41 16MC38	Rear Tool Box				\$15
ether	IFS	17X11	Box support strap Screw				
		3X54	Bolt				
		10X53	Square nut				
		10X415	Nut				
	T	16MC39	Corner brace				
orturo	TP	17X13 16MC129	Screw Por bings				
exture	1P	17X15	Box hinge Screw				
		3X53	Bolt				
	TPS	16MC128	Box shim				
hallow	TPS	15M17	" handle				
		15X428	SCIEW				
		10X31	" " nut				

When ordering parts use Code Word


GROUP 16—EQUIPMENT

EQUIPMENT

Code Word	Style of Body	Symbol Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Sellin
			TOOL BOX—Continued				
hank		16MC22	Box cover lining (felt)				\$2.2
hatch	TP	16M162	Box cover lining (felt) "lock (Yale No. 521) "lock spacer				2.0
		16M161	" lock spacer				.0
		17X119	Screw				
heater		16MC132	Brace wrench clip				.1
heca		16MC133	Tire remover clip				.2
heft		16MC184	Jack handle clip				.1
heine		16MC134 16MC135	Jack handle clip Upper clip for brace Lower clip for brace				.1
heir		16M198	Down band hala plate				.1
heism heme		16M199	Box hand hole plate				.0
neme		24X11	" plate cleat" " footman loop				.0
hemis		16MC141	Pump strap				.1
hence		16MC142	Jack strap				.1
heology		16MC143	Grease can strap				.1
heopathy		16MC155	" " support (short) " support (long)				.0
heorem		16MC156	" " support (long)				.1
heory		16MC157	Tire pump support				.0
here hermal		16MC158 16MC159	Auto jack support				.0
nermai hesis		16MC159	" " handle support				.0
hespian		16M163	Box cleat				.0
hews		16M165	" side support				.2
hick	TPS	16MXA43	Side Tool Box with tools complete				33.0
hieve		16MCA322	" " painted, with trays and fittings				
			ready for tools		76	50T	12.7
high		16M224	Lower tray				.5.5
himble		16MX227	Drawer		76	53T	1.4
hine		16MX321 16MC166	Upper tray		70		.0
hink hird		16MX182	Upper tray spacer handle				.1
hirst		16M142	Oil pump clip (pozzle end)				.1
histle		16M143	Oil pump clip (nozzle end) " " (handle end)				.1
hole		16M144	Hub cap wrench clip Hammer clip				.1
horax		16M145	Hammer clip		76		.1
horn		16M120	Box lock (Yale No. 0500)			60T	1.5
hose		16M141	" cover support " strips		76	61T	.1
hough		16M215	" strips				
		3X211 21X31	Attaching bolts and nuts " " washer				
		ZIROI					
			TOOL EQUIPMENT	1000	-		
bjure		5MC130	Spark plugs with switch nuts		28	26A	\$1.0
blative		5M16	gaskets				.0
howel		16M11	File handle		76	71T	1.0
hrash		16M13	12-in. Coe auto wrench		76	72T	1.0
hread hree		16M14 16M15	34 in. cold chisel No. 23 Williams wrench		76	73T	.2
hrift		16M16	No. 27 Williams wrench		76	74T	.4
hrive		16M17	No. 27 Williams wrench No. 31 Williams wrench		76	75T	. 6
		16M19	Q in half-round file		76	76T 77T	.2
		16M110	No. 100 universal gas pliers		76		.2
hrone							
hrone hrove		16M111	Valve poppet puller		76	78T	
hrone hrove hrum		16M111 16M112	Valve poppet puller 8-in. B. S. adjusting wrench		76	79T	1.0
hrone hrove hrum hrust		16M111 16M112 16M117	No. 100 universal gas pliers Valve poppet puller 8-in. B. S. adjusting wrench 3\(cape \) chisel		76 76	79T 80T	.1
hrone hrove hrum hrust hule		16M111 16M112 16M117 16M118	Valve poppet puller 8-in. B. S. adjusting wrench % cape chisel 4-in. Champion screw-driver		76 76 76	79T 80T 81T	.1
hrone hrove hrum hrust hule hump		16M111 16M112 16M117 16M118 16M119	Valve poppet puller 8-in. B. S. adjusting wrench 3c cape chisel 4-in. Champion screw-driver No. 28 Williams wrench		76 76 76 76	79T 80T 81T 82T	.1
hrone hrove hrum hrust hule hump hwack		16M111 16M112 16M117 16M118 16M119 16M176	% cape chisel 4-in. Champion screw-driver No. 28 Williams wrench No. 725 Williams wrench		76 76 76 76 76	79T 80T 81T 82T 83T	.1
hrone hrove hrum hrust hule hump hwack hyme		16M111 16M112 16M117 16M118 16M119 16M176 16M22	% cape cnisel 4-in. Champion screw-driver No. 28 Williams wrench No. 725 Williams wrench Auto hammer		76 76 76 76 76 76	79T 80T 81T 82T	.1
hrone hrove hrum hrust hule hump hwack hyme llusion		16M111 16M112 16M117 16M118 16M119 16M176	% cape chise! 4-in. Champion screw-driver No. 28 Williams wrench No. 725 Williams wrench Auto hammer ½-pint oil can Noera oil squirt gun		76 76 76 76 76 76 76 76	79T 80T 81T 82T 83T 84T 85A 86T	.1 .3 .5 1.0 1.2
hrone hrove hrum hrust hule hump hwack hyme llusion ickle		16M111 16M112 16M117 16M118 16M119 16M176 16M22 16M23 16M24 16M25	5% cape chise! 4-in. Champion screw-driver No. 28 Williams wrench No. 725 Williams wrench Auto hammer 4/-pint oil can Noera oil squirt gun 8-in. Champion screw-driver		76 76 76 76 76 76 76 76	79T 80T 81T 82T 83T 84T 85A 86T 87T	.1 .3 .5 .3 1.0 1.2 .5
hrone hrove hrove hrum hrust hule hump hwack hyme llusion ickle idings		16M111 16M112 16M117 16M118 16M119 16M176 16M22 16M23 16M24 16M25 16M25	5% cape chise! 4-in. Champion screw-driver No. 28 Williams wrench No. 725 Williams wrench Auto hammer 4/-pint oil can Noera oil squirt gun 8-in. Champion screw-driver		76 76 76 76 76 76 76 76	79T 80T 81T 82T 83T 84T 85A 86T	.1 .3 .5 .3 1.0 1.2 .5 .6
hrone hrove hrove hrum hrum hrust hule hump hwack hyme llusion ickle idings iderce		.16M111 16M112 16M117 16M118 16M119 16M176 16M22 16M23 16M24 16M25 16M26 16M26	5% cape chise! 4-in. Champion screw-driver No. 28 Williams wrench No. 725 Williams wrench Auto hammer 45-pint oil can Noera oil squirt gun 8-in. Champion screw-driver Spark plug wrench Valve and bub can wrench	W-686	76 76 76 76 76 76 76 76 76	79T 80T 81T 82T 83T 84T 85A 86T 87T 88T	.1 .3 .5 .3 1.0 1.2 .5 .6 .4
hrone hrove hruwe hrust hule hump hwack hyme llusion ickle idings ierce iger imber		.16M111 16M112 16M117 16M118 16M119 16M176 16M22 16M23 16M24 16M25 16M26 16MC222 16MX26	5% cape chise! 4-in. Champion screw-driver No. 28 Williams wrench No. 725 Williams wrench Auto hammer 45-pint oil can Noera oil squirt gun 8-in. Champion screw-driver Spark plug wrench Valve and bub can wrench		76 76 76 76 76 76 76 76 76 76	79T 80T 81T 82T 83T 84T 85A 86T 87T 88T	.1 .3 .5 .3 1.0 1.2 .5 .6 .4
hrone hrove hrowe hrum hrust hule hump hwack hyme llusion ickle iddings ierce iger imber imbrel		.16M111 16M112 16M117 16M118 16M119 16M123 16M23 16M24 16M25 16M26 16MC222 16MX226 16MX226	5% cape chise! 4-in. Champion screw-driver No. 28 Williams wrench No. 725 Williams wrench Auto hammer 45-pint oil can Noera oil squirt gun 8-in. Champion screw-driver Spark plug wrench Valve and bub can wrench	W-686	76 76 76 76 76 76 76 76 76 76 76	79T 80T 81T 82T 83T 84T 85A 86T 87T 88T	.1 .3 .5 .3 1.0 1.2 .5 .6 .4 .5 .3
hrone hrove hrove hrum hrust hule hump hwack hyme llusion ickle idings ierce iger imbrel imbrel imely		16M111 16M112 16M117 16M118 16M119 16M22 16M23 16M24 16M25 16M26 16M26 16M26 16M26 16M31	% cape chise! 4-in. Champion screw-driver No. 28 Williams wrench No. 725 Williams wrench Auto hammer ½-pint oil can Noera oil squirt gun 8-in. Champion screw-driver Spark plug wrench Valve and hub cap wrench Clutch spring adjusting spanner Auto jack with handle	W-686	76 76 76 76 76 76 76 76 76 76 76	79T 80T 81T 82T 83T 84T 85A 86T 87T 88T 90T 91T	.1 .3 .5 .3 1.0 1.2 .5 .6 .4 .5
hrone hrove hrum hrust hule hump hwack hyme llusion ickle idings ierce iger imber imber imbrel imid		16M111 16M117 16M118 16M119 16M176 16M22 16M23 16M24 16M25 16M26 16MC22 16MX226 16MX226 16MX31 16M32	% cape chise! 4-in. Champion screw-driver No. 28 Williams wrench No. 725 Williams wrench Auto hammer ½-pint oil can Noera oil squirt gun 8-in. Champion screw-driver Spark plug wrench Valve and hub cap wrench Clutch spring adjusting spanner Auto jack with handle	W-686	76 76 76 76 76 76 76 76 76 76 76	79T 80T 81T 82T 83T 84T 85A 86T 87T 88T	1.00 .11 .33 .55 .33 1.00 1.22 .55 .60 .44 .55 .33 4.00 .11
hrone hrove hrum hrust hule hump hwack hyme llusion ickle idings ierce iger imber imber imbrel imely imid incture		16M111 16M117 16M118 16M119 16M176 16M22 16M22 16M25 16M25 16M26 16M26 16M26 16M26 16M32 16M32 16M31 16M32 16M31 16M32 16M33 16M34 16M34	% cape chise! 4-in. Champion screw-driver No. 28 Williams wrench No. 725 Williams wrench Auto hammer //-pint oil can Noera oil squirt gun 8-in. Champion screw-driver Spark plug wrench Valve and hub cap wrench Clutch spring adjusting spanner Auto jack with handle "" handle Tire repair kit (furnished with tires) "" pump (furnished with tires)	W-686	76 76 76 76 76 76 76 76 76 76 76	79T 80T 81T 82T 83T 84T 85A 86T 87T 88T	.1 .3 .5 .3 1.0 1.22 .5 .6 .4 .5 .3 4.0 .1
hrone hrove hrum hrust hule hump hwack hyme llusion ickle idings ierce iger imber imber imely imid incture inge		16M111 16M112 16M117 16M118 16M119 16M122 16M22 16M24 16M25 16M26 16M26 16M26 16M31 16M31 16M31 16M31 16M32 16M31 16M32	% cape chise! 4-in. Champion screw-driver No. 28 Williams wrench No. 725 Williams wrench Auto hammer ½-pint oil can Noera oil squirt gun 8-in. Champion screw-driver Spark plug wrench Valve and hub cap wrench Clutch spring adjusting spanner Auto jack with handle "" handle Tire repair kit (furnished with tires) "pump (furnished with tires) "Alve jack assembly	W-686	76 76 76 76 76 76 76 76 76 76 76	79T 80T 81T 82T 82T 83T 84T 85A 86T 87 88T 90T 91T	.11 .3 .5 .3 1.0 1.2 .5 .6 .4 .5 .3 4.0 .1
hrone hrove hrum hrust hule hump hwack hyme llusion ickle idings ierce iger imber imber imid incture inge	TPS	16M111 16M112 16M117 16M118 16M19 16M122 16M22 16M24 16M25 16M26 16M26 16M26 16M31 16M31 16M32 16M31 16M32 16M31 16M32 16M31 16M31 16M31 16M31 16M31 16M31	% cape chise! 4-in. Champion screw-driver No. 28 Williams wrench No. 725 Williams wrench Auto hammer ½-pint oil can Noera oil squirt gun 8-in. Champion screw-driver Spark plug wrench Valve and hub cap wrench Clutch spring adjusting spanner Auto jack with handle "" handle Tire repair kit (furnished with tires) "pump (furnished with tires) "Alve jack assembly	W-686	76 76 76 76 76 76 76 76 76 76 76	79T 80T 81T 82T 83T 84T 85A 86T 87T 88T	.1 .3 .5 .3 1.0 1.2 .5 .6 .4 .5 .3 4.0 .1
hrone hrove hrum hrust hule hump hwack hyme llusion ickle idings ierce iger imber imbel imely imid incture inge inker inkle		16M111 16M112 16M117 16M118 16M19 16M122 16M22 16M24 16M25 16M26 16M26 16M26 16M31 16M31 16M32 16M31 16M32 16M31 16M32 16M31 16M31 16M31 16M31 16M31 16M31	% cape chise! 4-in. Champion screw-driver No. 28 Williams wrench No. 725 Williams wrench Auto hammer ½-pint oil can Noera oil squirt gun 8-in. Champion screw-driver Spark plug wrench Valve and hub cap wrench Clutch spring adjusting spanner Auto jack with handle "" handle Tire repair kit (furnished with tires) "pump (furnished with tires) "Alve jack assembly	W-686	76 76 76 76 76 76 76 76 76 76 76	79T 80T 81T 82T 83T 84T 85A 86T 87T 88T	.1 .3 .5 .3 1.0 1.2 .5 .6 .4 .5 .3 4.0 .1
hrone hrove hrum hrust hule hump hwack hyme llusion ickle ddings derce iger imbrel imely imid incture inker inker ippet	TPS	16M111 16M112 16M117 16M118 16M119 16M176 16M22 16M23 16M24 16M25 16M26 16M22 16M31 16M32 16M32 16M32 16M32 16M32 16M32 16M31 16M32 16M30 16M30 16M30 16M26 16M26 16M26 16M26 16M30 16M26 16M30 16M26 16M26 16M26 16M26 16M26	% cape chise! 4-in. Champion screw-driver No. 28 Williams wrench No. 725 Williams wrench Auto hammer y-pint oil can Noera oil squirt gun 8-in. Champion screw-driver Spark plug wrench Valve and hub cap wrench Clutch spring adjusting spanner Auto jack with handle "" handle Tire repair kit (furnished with tires) " pump (furnished with tires) Valve jack assembly Auto cover Gas and oil filler cap wrench with handle "" " " " " wrench "" " handle	W-686	76 76 76 76 76 76 76 76 76 76	79T 80T 81T 82T 83T 84T 85A 86T 87T 90T 91T	.1 .3 .5 .3 1.0 1.2 .5 .6 .4 .5 .3 4.0 1.0 1.0 1.0 1.0 1.0 1.0 1.0 1.0 1.0 1
hrob hrone hrove hrove hrum hrust hule hump hwack hyme llusion ickle iddings ierce iger imbrel imtel imtel imtel inge incture inge inkle injepet ipstaff irade	TPS	16M111 16M112 16M117 16M118 16M119 16M176 16M22 16M23 16M24 16M25 16M26 16M26 16M26 16M31 16M32 16M32 16M32 16M30 16M60130 16M6130 16M6130 16M6170 16M6169	% cape chise! 4-in. Champion screw-driver No. 28 Williams wrench No. 725 Williams wrench Auto hammer y-pint oil can Noera oil squirt gun 8-in. Champion screw-driver Spark plug wrench Valve and hub cap wrench Clutch spring adjusting spanner Auto jack with handle "" handle Tire repair kit (furnished with tires) " pump (furnished with tires) Valve jack assembly Auto cover Gas and oil filler cap wrench with handle "" " " " " wrench "" " handle	W-686	76 76 76 76 76 76 76 76 76 76 76	79T 80T 81T 82T 83T 84T 85A 86T 87T 88T	.1 .3 .5 .3 1.0 1.2 .5 .6 .4 .5 .3 4.0 1.0 1.0 1.0 1.0 1.0 1.0 1.0 1.0 1.0 1
hrone hrum hrust hule hump hwack hyme llusion ickle idings ierce ger imber imber imid incture inge inker inker inkle	TPS	16M111 16M112 16M117 16M118 16M118 16M119 16M176 16M23 16M23 16M25 16M25 16M25 16M26 16M31 16M31 16M32 16M31 16M32 16M31 16M30 16MC130 16MC130 16MC130 16MC170 16MC1101	% cape chise! 4-in. Champion screw-driver No. 28 Williams wrench No. 725 Williams wrench Auto hammer y-pint oil can Noera oil squirt gun 8-in. Champion screw-driver Spark plug wrench Valve and hub cap wrench Clutch spring adjusting spanner Auto jack with handle "" handle Tire repair kit (furnished with tires) " pump (furnished with tires) Valve jack assembly Auto cover Gas and oil filler cap wrench with handle "" " " " " wrench "" handle Tire rim tool "" handle Tire rim tool "" handle	W-686	76 76 76 76 76 76 76 76 76 76	79T 80T 81T 81T 82T 84T 85A 86T 87T 90T 91T	.11 .33 .55 .33 1.00 1.22 .55 .66 .44 .53 4.00 .11 2.55 1.66 5.00 1.00 1.00 1.00 1.00 1.00 1.00 1.00
hrone hrove hrum hrust hule hwack hyme llusion lickle ierce iger imber imber imber imid incture inkle jipstaff irade irade irade irade irade irade irsussuse	TPS	16M111 16M112 16M117 16M118 16M119 16M176 16M22 16M23 16M24 16M25 16M26 16M26 16M26 16M31 16M32 16M31 16M31 16M31 16M301 16M31 16M51	% cape chise! 4-in. Champion screw-driver No. 28 Williams wrench No. 725 Williams wrench Auto hammer y-pint oil can Noera oil squirt gun 8-in. Champion screw-driver Spark plug wrench Valve and hub cap wrench Clutch spring adjusting spanner Auto jack with handle Tire repair kit (furnished with tires) " pump (furnished with tires) Valve jack assembly Auto cover Gas and oil filler cap wrench with handle " " " " wrench " " " handle Tire rim tool " " " handle Tire rim tool " " " " handle " " " " " " " " handle " " " " " " " " " " " " " " " " " " "	W-686	76 76 76 76 76 76 76 76 76 76	79T 80T 81T 82T 83T 84T 85A 86T 87T 90T 91T	.1 .3 .5 .3 1.0 1.2 .5 .6 .4 .5 .3 4.0 .1
hrone hrum hrust hule hump hwack hyme llusion ickle idings ierce ger imber imber imid incture inge inker inker inkle	TPS	16M111 16M112 16M117 16M118 16M118 16M119 16M176 16M23 16M23 16M25 16M25 16M25 16M26 16M31 16M31 16M32 16M31 16M32 16M31 16M30 16MC130 16MC130 16MC130 16MC170 16MC1101	% cape chise! 4-in. Champion screw-driver No. 28 Williams wrench No. 725 Williams wrench Auto hammer y-pint oil can Noera oil squirt gun 8-in. Champion screw-driver Spark plug wrench Valve and hub cap wrench Clutch spring adjusting spanner Auto jack with handle "" handle Tire repair kit (furnished with tires) " pump (furnished with tires) Valve jack assembly Auto cover Gas and oil filler cap wrench with handle "" " " " " wrench "" handle Tire rim tool "" handle Tire rim tool "" handle	W-686	76 76 76 76 76 76 76 76 76 76	79T 80T 81T 81T 82T 84T 85A 86T 87T 90T 91T	.11 .33 .55 .33 1.00 1.22 .55 .66 .44 .53 4.00 .11 2.55 1.66 5.00 1.00 1.00 1.00 1.00 1.00 1.00 1.00

When possible, order through Thomas Dealer

GROUP 16—EQUIPMENT



Automotive Research Library

EQUIPMENT

Code Word	Style of Body	Symbol	Name of Part	Foreign Symbol	Illus- trated on Page	No. on Plate	Selling Price
Toady Toesin Tinge Toggle Toilet		16MC191 16MC192 16MXA320 16MX223 16MCA1100 16M114	TOOL EQUIPMENT—Continued Connecticut timer adjusting wrench file Valve Jack Assembly voke v screw with handle screw handle		76 76 76	105T 106T 107T	\$0.10 .20 1.60 .55 1.00
Token Tolerate Tolerance Tolerable Tomahawk Tomboy Tomentose Tomfool	T T T T T T T	16MCA312 16MC214 16MC215 16MC123 16MC124 16MC125 16MC126 16MC127 10X44 21X23	TRUNK RACK Trunk Rack Assembly " " arm (R) " " " (L) " " " clip (R) " " clip (L) Clip strap or link " filler (outside) " filler (inside) " nut " lock washer				\$15.00 2.00 2.00 60 .60 .10 .35 .35
Tongs Tongue Tonic		16MC223 16M140 16MC1103	Speedometer and Tube, Warner-K-60 mi. Shaft apron plate Shaft 78 in.				\$75.00 .20 7.00
Tonnage Tonsil Tonsure Tontine Tooth		16MC1104 16MC1105 16MC1106 16MC1107 16MC1108	Drive gear 100 tooth Driven pinion Bearing bracket U-clip Bearing at end of shaft	7777777			1.50 1.00 1.50 .10 4.00
Sepicole Topaz Toper	T	15MC1140 15MCA3206 3X24 21X31 15MC1238	Speedometer bracket License Tag Bracket (rear) assembly bolt Plain washer Front License Tag Hanger				.40
		15X47 15X412 10X33	No. 14—24 x ½ screw No. 14—24 x ¾ screw Nut TIRE BRACKETS (Set)				
Serapiao }	TPR Li. La. TP	15M214 15MF41	Running board tire bracket Front tire bracket				\$1.50 1.75
Serbare Serasker	TP TP Li. La.	15MF42 15M142	Rear tire bracket Tire bracket strap				1.75

When possible, order through Thomas Dealer

GROUP 16—EQUIPMENT

	-		Name and Descri	iption		Pr	100
X11 X12	¼ diameter		BALLS Steel—High D	uty		per 100	0 \$0.5
AIL	98 diameter		BEARINGS			100	J 1.4
			Annular Ball Bea	rings			
	No.	Type			dth		
X23 X24	206 209	Silent	1.1811 1.7716		299 180		\$3.6
K26	212	"	2.3622	4.3307 .86	561	* 44	8.4
K27	203 307				724		2
X31 X32	308		1.5748	3.1496 .82 3.5433 .90	268	- "	5.
(41	406	"	1.1811	3.5433 .90	055	"	6.
			Timken Roller Be				
61 61A	Complete with	following cone a	and cup			each	\$5.
61B	Cup only, No	. 2320				**	1.
62 62A	Complete with	375	and cup			"	7.
62B	Cup only, No.	3720				"	4.
63 63A	Cone only No	336	and cup				5.
63B	Cup only, No	. 3320					2.
64 64A	Complete with	following cone a	and cup			1.	9.
64B	Cup only, No	. 3920				"	3.
65 65A	Cone only No	. 435	and cup			"	7. 5.
65B	Cup only, No	. 4320	:			**	2.
611 611A	Complete with	following cone a	and cup				5.
611B	Cup only, No.	312				"	1.
612 612A	Complete with	following cone a	and cup			**	5.
611B	Cup only, No	. 312				**	1.
613 613A	Complete with	following cone a	and cup			**	6.
	Cone only, 140	. T					
013B	Cup only, No	. 412				**	2.1
614							5.
614A 614B							5. 3 1
614A 614B 615							5. 3 1 9
614A 614B 615 615A							2.0 5.3.1.1 96.0
614A 614B 615 615A							2.0 5.3.1.1 96.0
614A 614B 615 615A	Complete with Cone only, No Cup only, No Complete with Cone only, No Cup only, No	3650	and cup				2.0 5.3.1.1 96.0
614 614A 614B 615 615A 615B	Come only, No Cup only, No Complete with Cone only, No Cup only, No Cup only, No Size	. 3650	and cup	h Nut			2.0 5.1 3.3 1.8 9.3 6.0 3.3
614 614A 614B 615 615A 615B	Come only, No Cup only, No Complete with Cone only, No Cup only, No Cup only, No Size	. 3650	and cup	h Nut		doz.	2.0 5.1 3.1 9.3 6.0 3.3
614 614A 614B 615 615A 615B	Come only, No Cup only, No Complete with Cone only, No Cup only, No Cup only, No Size	Length 3 ½ 4 2	and cup	h Nut		doz.	2 5 3 1 9 6 3
614 614A 614B 615 615A 615B	Cone only, No Cup only, No Size Size Si	3550	and cup	h Nut		doz.	2 5 3 1 9 6 3
614 614A 614B 615 615A 615B	Come only, No Cup only, No Complete with Cone only, No Cup only, No Cup only, No Size	Length 3 ½ 4 2	and cup	h Nut		doz.	2 5 3 1 9 6 3
6614 6614A 6614B 6615A 6615B	Cone only, No Cup only, No Size Size Si	Solid	BOLTS Carriage Bolt with	h Nut		doz.	2.0 5 3 1.8 9 6.0 3 \$0
614 614A 614B 614B 615 615A 615B 22 24 210 211 215 224	Cone only, No Cup only, No Size \$\frac{1}{6} - 18 \frac{1}{6} - 18 \frac{1}{6	. 3650	BOLTS Carriage Bolt with A. L. A. M. B Length Head to Nut	h Nut		doz	2.5.3.1.9.6.3.3.
614 614B 614B 615 615A 615B 22 24 2210 2211 2215 2224	Cone only, No Cup only, No Size	3650 3620	BOLTS Carriage Bolt with A. L. A. M. B Length Head to Nut	h Nut		doz	2.5.3.1.1.96.1.3\$0\$
614 614A 614B 615 615A 615B 22 24 210 2211 2215 2224	Cone only, No Cup only, No Size \$\frac{1}{6} - 18 \$\frac{1}{6} - 1	Joseph Jo	BOLTS Carriage Bolt with A. L. A. M. B. Length Head to Nut 2½ 1½	h Nut		doz	2.1 5.3.1 1.9.6.1 3 \$0
614 614A 614B 615 615A 615B 22 24 210 2211 215 224	Cone only, No Cup only, No Size \$\frac{1}{6} - 18 \$\frac{1}{6} - 24 \$\frac{1}{6} - 26 \$\frac{1}{6} - 2	Slowing cone Slow	BOLTS Carriage Bolt with A. L. A. M. B Length Head to Nut 2 1/4 1 1/6 1 1	h Nut		doz	2.1 5.3 1.1 9.0 6.1 3 \$0
614 614A 614B 615 615A 615B 22 24 2210 2211 215 2224 31 34 38 39 310 311	Come only, No Cup only, No Size \$\frac{1}{6} - 18 \$\frac{1}{6} - 24 \$\frac{1}{6} - 20 \$\frac{1}{6} - 20 \$\frac{1}{6} - 20	. 3650	BOLTS Carriage Bolt with A. L. A. M. B Length Head to Nut 1/2 2/4 1/8 1/8 1/9 2/2	h Nut		doz	\$0
614 614B 614B 615 615A 615B 22 24 210 2211 2215 2224 31 334 339 3310 3311 3315	Come only, No Cup only, No Size \$\frac{1}{6} - 18 \$\frac{1}{6} - 24 \$\frac{1}{6} - 20 \$\frac{1}{6} - 20 \$\frac{1}{6} - 20	Joseph State Control of the Control	BOLTS Carriage Bolt with A. L. A. M. B Length Head to Nut 1/4 1/4 1/8 1/8 1/8 1/8 1/8 1/8 1/8 1/8 1/8 1/8	h Nut		doz	\$0.4
614 614B 614B 615A 615B 222 24 2210 2215 2224 31 33 338 339 310 3311 3318 3320	Cone only, No Cup only, No Size \$\frac{1}{4} - 18 \$\frac{1}{4} - 24 \$\frac{1}{4} - 20 \$\frac{1}{4} - 24 \$\f	Solution	BOLTS Carriage Bolt with A. L. A. M. B Length Head to Nut 1/4 1/4 1/8 1/8 1/8 1/8 1/8 1/8 1/8 1/8 1/8 1/8	h Nut		doz	\$0.4
614 614B 615A 615B 222 24 210 211 215 2224 31 33 33 31 33 31 33 32 32 32 32	Come only, No Cup only, No Size \$\frac{1}{8} - 18 \$\frac{1}{8} - 24 \$\frac{1}	Solution	BOLTS Carriage Bolt with A. L. A. M. B Length Head to Nut 1/4 1/4 1/8 1/8 1/8 1/8 1/8 1/8 1/8 1/8 1/8 1/8	h Nut		doz	\$0.4
6014 6014B 6015A 6015A 6015B 222 2210 2211 2212 2313 3313 3310 3310	Come only, No Cup only, No Size \$\begin{array}{cccccccccccccccccccccccccccccccccccc	Solution	BOLTS Carriage Bolt with A. L. A. M. B. Length Head to Nut 24 11/6 1 11 15/2 2 2 3 18/4 2 3/4 17/6 2 3/4 17/6 2 3/4 3 4/4 3 4/4	h Nut		doz.	\$0.3
6614 66148 66158 66158 66158 66158 66158 3222 224 2211 2215 2224 331 334 339 3310 3313 3313 332 3232 324 328 328 328 328 328 328 328	Come only, No Cup only, No Size \$\[\frac{1}{6} - 18 \\ \frac{1}{6} - 24 \	Solution	BOLTS Carriage Bolt with A. L. A. M. B Length Head to Nut 2 ½ 1 ½ 2 ½ 2 ½ 2 ½ 4 ½ 4 ½ 4 ½ 4 ½ 4 ½ 4 ½ 4 ½ 4 ½ 4 ½ 4	h Nut		doz	\$0.4 \$0.4 \$0.4 \$0.4 \$0.4 \$0.4 \$0.4 \$0.4
6614 6614A 6614B 6615A 6615S 6	Come only, No Cup only, No Size \$\[\begin{align*}	Solution	BOLTS Carriage Bolt with A. L. A. M. B. Length Head to Nut 2 ¼ 1 ½ 2 ½ 1 ½ 2 ½ 1 ½ 2 ½ 1 ½ 2 ½ 1 ½ 2 ½ 1 ½ 2 ½ 1 ½ 2 ½ 1 ½ 2 ½ 1 ½ 2 ½ 1 ½ 1 ½ 2 ½ 1 ½ 1 ½ 2 ½ 1 ½ 1 ½ 2 ½ 1 ½ 1 ½ 2 ½ 1 ½ 1 ½ 1 ½ 2 ½ 1 ½ 1 ½ 1 ½ 1 ½ 1 ½ 1 ½ 1 ½ 1 ½ 1 ½ 1	h Nut		doz.	2.0 5.1 1.8 9.3 3.3 2.2 3.3 2.2 2.2 2.2 3.3 1.0 6.0 4.4 4.5 5.0 6.0 6.0 6.0 6.0 6.0 6.0 6.0 6.0 6.0 6
6614 6614B 6614B 6615B 6615A 6615B 222 224 2210 2211 2215 2224 33 33 33 33 33 33 33 33 32 32 32 32 33 33	Size \$\frac{1}{6} - 18 \$\frac{1}{6} - 24 \$\frac	Length 3½	BOLTS Carriage Bolt with A. L. A. M. B Length Head to Nut 1 1 1 1/4 1 1/4 2 1/4 1 1/4 2 1/4 1 1/4 2 1/4 1 1/4 2 1/4 1 1/4 2 1/4 1 1/4 2 1/4 1 1/4 2 1/4 3 1/4 3 1/4 3 1/4 3 1/4 3 1/4 3 1/4 3 1/4 3 1/4 3 1/4 3 1/4 3 1/4	h Nut		doz	\$0.4 \$0.4 \$0.4 \$0.4 \$0.4 \$0.4 \$0.4 \$0.4
6614 6614B 6614B 6615B 6615A 6615B 222 224 2210 2211 2215 2224 33 33 33 33 33 33 33 33 32 32 32 32 33 33	Come only, No Cup only, No Size \$\[\begin{align*}	Sacon Saco	BOLTS Carriage Bolt with A. L. A. M. B Length Head to Nut 1/2 1/3 1/3 2/3 1/3 2/3 1/3 2/3 3/4 3/3 3/4 3/4 3/4 3/4 3/4 3/4 3/4 3	Hexagon Hexagon In the state of the state		doz.	\$0.4 \$0.4 \$0.4 \$0.4 \$0.4 \$0.4 \$0.4 \$0.4
6614 6614B 6614B 6615B 6615A 6615B 222 224 2210 2211 2215 2224 33 33 33 33 33 33 33 33 32 32 32 32 33 33	Size \$\frac{1}{6} - 18 \$\frac{1}{6} - 24 \$\frac	Sacon Saco	BOLTS Carriage Bolt with A. L. A. M. B Length Head to Nut 2 % 1 % 2 % 2 % 2 % 3 % 2 % 3 % 3 % 3 % 3 % 4 % 3 % 4 % 3 % 4 % 3 % 4 % 3 % 4 % 4 % 3 % 4 % 4 % 4 % 4 % 4 % 4 % 4 % 4 % 4 % 4	Hexagon Hexagon In the state of the state		doz	2.0 5.1 1.8 9.3 3.3 2.2 2.2 2.2 2.2 2.2 2.2 2.3 3.1 1.0 4.4 4.4 4.9 9.5 6.6 6.6 6.6 6.6 6.6 6.6 6.6 6.6 6.6 6
(613B 61614 61614 61615A 61615B 61615 6155 61615B 61615 6155 61615B 61615 6161	Size \$\frac{1}{6} - 18 \$\frac{1}{6} - 24 \$\frac	Sacon Saco	BOLTS Carriage Bolt with A. L. A. M. B Length Head to Nut 1/2 1/3 1/3 2/3 1/3 2/3 1/3 2/3 3/4 3/3 3/4 3/4 3/4 3/4 3/4 3/4 3/4 3	Hexagon Hexagon In the state of the state		doz	2.0 5.1 1.8 9.3 3.3 2.2 3.3 2.2 2.2 2.2 3.3 1.0 6.0 4.4 4.5 5.0 6.0 6.0 6.0 6.0 6.0 6.0 6.0 6.0 6.0 6

Symbol		1	Name and Descrip	otion		P	rice
			BOLTS-Continu	ed			
			Step Bolt				
	-	Length	Dia. of				
X52	Size 15—18	Under Head	Head 1 1/4			doz.	\$0.45
	16		cial Hexagon Hea	d Rolt			
		Body	Length				
	Thread	Diameter	Under He	ad	Hexagon		
X71	5 24	3/8	2		16	doz.	\$0.80
			COCK				
			Oil Shut Off Co	ck			
X13	Tap ¼ pipe, both e	ande	Hole			each	\$0.65
A13	74 pipe, both 6		1/4 -	Diag Coals		each	\$0.00
	Threads	Carbure	tor Water Jacket Hole	Pipe Cock			
X14	3/8 pipe		3 drill			each	\$0.60
	78		Brass Pet Cock				
X21	Size		Pipe Thread		The state of the s	each	\$0.25
X22	1/4 3/8		1/4—18 3/8—18			"	.25
			NUT				
		So	derless Connection	n Nut			
	Тар	Hole	Hex.		ngth		
X14 X15 X16	1/8 straight pip 5/8—20	9/8	1/2 3/4	1	13 16 7	44	\$0.05
X16	34 Brigg stand	ard ½	3/4 7/8		1/2	- "	.10
		N	IPPLE OR BUSH	ING			
		5	Solderless Connect	tion			
X17	Тар	Thread	Hole	Hex.	Length		\$0.10
X17	1/8 pipe	1/8 straight pipe	3 drill	1/2	3/4	each	\$0.10
			GREASE CUP				
			Bowen-Wing Ca				
X11	Style 800	No. 00	Capacity	Compression Plain	1/6	each	\$0.35
X13	800 800	000	½ oz. ¼ oz.	Ratchet	18	"	.35
X14 X31	Hex. shank	000	½ oz. ¼ oz.	Ratchet Ratchet	1 8 1 8 1 8 1 8 1 8 1 8 1 8 1 8 1 8 1 8	"	.60
K32	" "	00	½ oz.	Ratchet	1/8	**	.70
			OILER				
	D.		Bay State				
X11	Dia. 3/8	Length				each	\$0.05
			KEY				
			Straight				
K11	1/8 x 1/4 x 1 i	n. long	Straight		A	doz.	\$0.35
K12 K15	1/8 x 1/4 x 1 in 1/5 x 1/5 x 1/5 x 1/5 x 1/5 in 1/4 x 1/4 x 1/8 in 1/4 x 1/5 in 1/6	n. "			***************************************	" "	.75 .40
X16	1/4 x 5/16 x 2 5/16 is	n. "				"	.70
			Woodruff Key				
K 21	No.	Dia.	Thickness			doz.	\$0.30
K22	3 5	1/2 5/8 5/8 7/8	1/8			doz.	.35
K23 K26	6	/8	32 316 1/4			6.6	.35
X27 X28	15	1 3/4	14 5 32				.60
-20	9	74					.43
			NUTS				
			stle A. L. A. M.	Nut			
X11	Size 3/8—24	Thickness	Hex.		Material Steel	doz.	\$0.40
X13 X14	1/2-20	1322 166 2332 267 267 267 267	3/4		50cci	"	.50
X15	%-18 5-24	32 32 64	15 16 1/2			- 44	.35
0X16	5/8-11		1 16		"	**	.80

When possible, order through Thomas Dealer

Symbol		N	lame and Description		P	rice
			NUTS—Continued			
		D	ouble Chamfered Nut			
	Size	Thickness	Hex	Material		
10X21	3/8-16	1/4	5/8	Steel	doz.	\$0.2
10X22	7-14	5 16 14	16	44	**	.3
10X23 10X24	½-20 ½-20	3/4	3/4 3/4	"	44	.3
10X27	$\frac{7}{18}$ —14	3/8 1/4 1/4	11	**	**	.3
10X211	⁷ / ₁₆ —14 ³ / ₈ —16 L. H.	1/4	116 5/8	"	. 44	.2
		1	Machine Screw Nut			
	Size	Thickness	Hex.	Material		
10X31	14—24 14—24	† 3 16	1/2	Brass	doz.	
10X33 10X35	14—24 10—32	* ************************************	1/2	Steel	gross	s .c
10X35	6-32	1/8 3	3/8 5-6 1-6 1-6 1-6 1-6 8		**	.4
10X36 10X38	3/8—16 5—40	32 11 39	16	**	doz.	.3
10X312	5-40	32	16	Brass	"	.2
10X313	20—16	1e				.4
			Faced Nut			
1077.11	Size	Thickness	Hex.	Material		
10X41 10X42	5-18 5-24	16	19 32 1/2	Steel	doz.	\$0.2
10X43	3/16	84	11	"	**	3
10X43 10X44	3/8-24	21 64	16	" (P- DI)	**	
10X45	1/2-20	7 16 35	1 6 9 6 4 5 6 6 7 6 7 6 7 6 7 6 7 6 7 6 7 6 7 6 7	" (Br. Pl.)	each	
10X46 10X47	5/8—18 1/4—20	64	16		doz.	- 5
10X48	1/4-28	74	3/8	"	**	
10X49	$\frac{7}{16}$ —20	3/8	3/8 11/6 1/8	"	**	.4
10X410 10X412	½—13 5—18	1/2	7/8	Brass	44	.(
10X412 10X413	16-18 12-13	16	39	Steel	**	.0
10X415	5-18		19	"	**	
10X417		16	1 ½	"	"	.8
0X421 0X422	7 ₆ —14	3/8	16		"	
0X423	3/16	16	13 16 11 16		11	:
10X424	3/8-24	21	16 9 16	" (Br. Pl.)	"	.3
10X425	3/8—16		16 11 16	" (Br. Pl.)	**	.3
0X61	5 24		Wing or Thumb Nut		doz.	00.1
10201	5 24	J. H. W. Style	B		doz.	\$0.3
	0.	(D) 1 1	Special Castle Nut Hex.	Material		
0X71	Size	Thickness		Steel	doz.	\$0.8
10X71 10X73 10X75	3/4—10 9—18	9 16 1/ ₂	1 1/4	"	**	.6
10X75	7/0-14	1/2	1 1/2	"	"	.9
10X76 10X77		17 32	312 9 16 34			.8
0X78	3/8—16 1/2—20	3/8	16	Brass	44	.6
0X78 0X79	1/2-20	13 32 8/8	13	Nickel steel	44	.7
0X712	5/8—16	5/8	116	Steel	**	.8
			Faced Nut			
OTTO	Size	Thickness	Hex.	Material		
0X81 0X82	5/8—18 5/8—18	16	15	Steel (deilled)	doz.	\$0.6
0X82 0X83	%-18 ½-20	16 3/8 3/4	1/8 3/4	" (drilled)	**	.6
	75 20	74	PINS	(dritted)=====		
	Dodu	T amost to form	Clevis Pin	Head		
	Body Size	Length from Head to Hole	Cotter	Diam		
1X11	.499	1 1/4	1/8 x 3/4	5/8	doz.	\$0.6
1X14	.499	1	1/8 X 3/4	5/8 5/8	**	.6
1X17 1X112	.499	1 16 58	1/8 X 3/4	5/8 3/8	**	.6
14112	.248	7/8	16 X ½	78		.4
	D:		Straight Pin			
17/12	Dia.	Length	Material		doz.	000
1X43 1X45	1/4 3-	1 3/8 1 3/8	Steel		44	\$0.2
1X48	3 16 1/4	3/4			4 1	.1
1X410	3 16	5/8	Brass		44	.2
1X416	3 16 3 16 1/8 3 16	116 5/8	Steel		"	.1
1X417 1X421	78	9/8 3/8	Brass		44	.1
1X422			Steel		**	.1
1X424	.083	5/8	Iron Wire		"	.1
			Lock Pin			
1X61	.248 diameter	x 15 long Stee	•		4	\$0.3

When ordering parts use Code Word

ymbol		Name	e and Description			Pı	rice
		PI	NS—Continued				
		Sne	cial Clevis Pin				
1X71	1/ diameter x &	under head, slotted a				doz.	\$0.6
12.71	74 diameter x 16		A. L. A. M. Pin				
	Body Len	gth from	Dia.				
Wor	Dia. Head	to Hole Cotter 1.039 32 x 34				doz	\$0.5
1X81	.465	1.039 $\frac{3}{32} \times 3$				402.	Ψ0.0.
		Tilliatas	SCREWS				
	0:	Dia. Head	Head Cap Screw Material				
4X14	Size 1/4—20 x 5/8	Dia. Head	Steel			doz.	\$0.4
4X18	10-32 x 2	3/8 5 16 3/8	"			**	.5
4X19	½—28 x 5/8	3/8 FN-4					.4
	0.		Head Cap Screw Material				
X23	Size 1/4—20 x 1 5/8	Dia. Head	Steel			doz.	\$0.6
1X26	16-18 x 1	5/2				**	.6
1X29 1X211	5 16 16 18 x 1 3/8 3/8 16 x 1 1/2	5/8 3/4				**	.7
tA211	%-10 x 1 ½		n Hond Can Screw				
		Length	n Head Cap Screw	2-			
	Size	Under Head	Hex.	Materia	1		- 5
X31	1/4-20	3/4	16	Steel		doz.	\$0.3
X33 X34	5 16—18 5 18—18	1 3/4	1/2			4.6	.4
X35	3 ₈ —16	3/4	1/2 16 16 16 16 16 18 18	"		**	.4
X36	3/8—16 3/6—16	1	16	"			.5
X37 X38	3/8—16 3/8—16	1 1/4 1 1/2	16 9			**	.5
X311	1/4-20	1	16	"		- 66	.3
X314 X315	5 18 18 18	1 ½ 1 ½	1/2 1/2			**	.4
X316	5 —18	1 1/4	1/2	Brass		**	.6
X321	5 16—18	1 3/4	1/2 1/2	Steel		44	.5
X323 X328	5—24 5—18	3/4 7/8	1/2	**		**	.4
X332	₃₀ —18	1 16	1/2	"		"	.4
X335	1/2—13 3/2—24	1 3/4	3/4 9			**	.6
X337 X338	3/8—24 3/8—16	1/8	16 9 16			4.6	.4
X339	5-24		1/2	"	(Hd.Br.Pl.)	66	.4
X340 X341	3/8—24 1/4—20	7/8	16 J.		(Hd.Br.Pl.)		.4
X342	3/8—16	11/8	16 9 16	"		"	.5
X343	3/8-16	1 ½ 1 ½ 1 ½ 1 ½ 1 ½ 1 ½	3/4 1		(Br. Pl.)		.6
X344	5 18						
***			Head Cap Screw	Steel		doz.	\$0.3
X67 X612	3/8—16 3/8—16	1 34 1 1/8		**		64	.3
X613	3/8—16	3/4		"		44	.3
		Drilled	Head Cap Screw				
X71	3/8—16	1		Steel		doz.	\$0.4
X71 X72 X73	1/4—20 1/4—20	1 3/4				**	.4
X74	3/8-16	11/		**		44	.6
X75	5 16—18	5/0		* "		44	.4
X79 X710	3/8—16 3/8—16	3 ¹ / ₄ 3 ¹ / ₄		**		**	.5
X711	9 16—12	3 1/4		"		each	.1
	HALLS	Slotted	Head Cap Screw				
X82	5—18 ½—28	7/8 5/8		Steel		doz.	\$0.4
X83	1/4-28		Mashina Paras C				.3
wa.	44 20		Machine Brass Screw	Brass		doz.	\$2.5
X21	14—20	Franch I	Iead Machine Screw	Drass	·	uoz.	Ψ2.5
.V22	14—24		read Machine Screw	Brass		doz.	\$3.6
X32 X319	14—24 20—16	1 ½ 1 3/8		Diass		"	.6
			lead Machine Screw				
5X45	14—24			Steel		gross	\$0.5
5X45 5X46	6-32	1/4				**	.7
X47 X48	14—24 14—24	1/2		Brass Steel		44	.5
5X49	10-24	3/4 1/4 1/2 1/2 3/8 3/4		"		**	.4
5X412	14—24 10—32	3/4 5/8		Brass Steel		"	.8
5X413						44	


When possible, order through Thomas Dealer

Symbol			Name and Descript	cion	ART THE	Pr	ice
			SCREWS—Continu	ed		-	
		Ro	ound Head Machine	Screw			
		Lengtl Under He					
	Size	Under He	ead		terial teel	gross	\$0.40
15X415 15X419	10—32 10—32	1 1/8		5	**	44	.65
15X427	14-24	1/2		n		**	.50
15X428 15X435	14—24 14—20	1 1/4		B	rass		1.25
15X437	5-40	1 1 1 6		В	rass	"	.50
15X438	14—20 14—20	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1		S	teel	**	.55
5X439 5X440	14—20	1/2		В	rass		.7
5X441	10-32	* 1/2			"	**	.50
			SET SCREW				
cV10	10—32	Hea	dless-Cup Point Se			per 25	\$0.20
6X12 6X13	3/8—16	3/8 1/2				" 25	.35
6X17	10-32	3/4				" 25	.25
		Square	Head Cup Point S	Set Screw			
6X21	3/8-16	1				per 25	\$0.2
6X23 6X25	1/4—24 1/8—14	1 1/8				" 25 " 25	.20
6X29	7-14	1 3/4				" 25	.4.
			SPRINGS			1	
			Helical Spring				
8X11	3 dia. x 9 fr	ree length .0215 st	eel wire			each	\$0.05
			Circular Lock Spri				
OWa-	Inside Dia.	Dia.	Wire Hook	Material		3	ec 11
8X21	1/8	.065	No	Spring steel		doz.	\$0.10
			STUDS				
	-		Plain Stud				
	O' T 11	Leng	gth of Threads				
9X12	Size Length	Tight End	Nut End			doz.	\$0.35
9X13	3/8—16 x 1 1/8 1/2—13 x 2 1/2	3/4	5/8 7/8	*		"	.85
9X15 9X16	3/8—16 x 1 1/8 3/8—16 x 7/16	118 34 9 16 111	5/8	- /		**	.35
9210	%-10 X 16	16	WIRE				
			Circular Lock Win	re			
	Inside Dia.	Dia. Wire	Hook	Material			00.00
0X31 0X34	1 18 1 7	3 32 3	3/6	Spring steel		66	\$0.20
0X37	1 76 3 1/8 1 76	32 32 33 32 32 32	1/4 3/8 1/2			"	.25
0X39	1 7 6	3 32	1/2			"	.20
			WASHERS				
	1.5		Dust Washer				
1X14	Dia. Inside	Dia. Outside	Thickness	Material No. 4 Felt		doz.	\$0.25
1X15	134	2	3 16 3 32	No. 4 Felt		"	.30
		P	lain-Untempered V	Vasher			
	01		Dia.				
1X31	Size	11	tside Thickne 5/8 .049	ss Material Steel		per 100	\$0.65
1X32	5 16 5 16 3/8 1/2	11 312 330 330 330 330 330 330 330 330 330 33	$\frac{3}{16}$.083	"		" 100	.80
21X36 21X37	3/8	13 32 17	13 16 7/8 .065			" 100	70 .70
1X37 1X321	5/8	17 32 21 32	$\frac{7}{32}$.125	"		" 100	
			ecial-Plain Steel V	Vasher			
1X51	21 I. D. x 1,3		finished			doz.	\$0.15
			CLEVIS				
			Tapped Clevis				
	Тар	Slot Pin H	ole Dia.				
2X12	1/2-20		1/2			each	\$0.35
			ROD END				
2X41	Complete for	¼ diameter rod	Ball			each	\$0.25
2X42	Ball only					- 11	.10
2X43 2X44	" cup plug Body	only				**	.05
	Dody						.10

When ordering parts use Code Word

Symbol	Name and Description	Pric	е .
23X21	DOWEL AND PLATE Size fa Brass	doz.	\$1.15
	NIPPLES		
	Solderless Connection Nipple Pipe Thread Str. Thread Hole Hex. Length		
23X514	1/s pipe 3 1/2 31	each	\$0.05
23X515 23X516	14 58-20 14 34 143 36 34-Brigg 38 78 158		.10
25/1010			.13
	HOSE CLAMPS		
23X72	Type Size Inside Dia. Width Sherman 2 23% 7%	each	\$0.15
23X73	Sherman 2 23/8 7/8		.15
	ELBOWS		
	Brass Elbow		
23X92		each	\$0.20
23X97	7a —24 thread ¼ hole with taper, flanged for soldering to gasoline tank		.10
23X98	1/8 pipe thread and 1/8 straight thread for solderless connection		.10
	LOOP		
	Footman Loop		
24X11	For strap 1 ¼ wide	each	\$0.10
	TERMINALS		
	Wire Terminal		
24X21 24X24	Rubber and brass elbow for magneto		\$0.50
	PACKING		100
	Garlock No. 333 Packing		
	Inside Dia. Outside Dia. Width Chamfer		
24X43 24X47	$\begin{array}{cccccccccccccccccccccccccccccccccccc$	doz.	
24X48	2 2 3 16 Double		1.25
	CABLE		
25X41	Bosch Cable for Magneto	per foot	\$0.15
	TURNBUCKLE		00.40
25X91	3/8—16	each	\$0.40
	CABLE		
	Packard Cable		
26X11	Size ³ / ₁₆	per foot	\$0.10
	WIRE		
	Insulated Wire		
26X24	No. 24—10 Strand—cotton covered	per foot	\$0.05
	TUBING		
	Annealed Brass Tubing		
27X17	52 outside diameter, No. 18 B. W. G. 14 outside diameter, No. 20 B. W. G.	per foot	\$0.05
27X18	Rubber Tubing		.03
28X14	3 I. D. x 16 wall Goodrich No. 10 grade	per foot	\$0.10
	10 10 300		100

When possible, order through Thomas Dealer



Automotive Research Library